

Scilab Textbook Companion for
Microwave Engineering
by M. Kulkarni¹

Created by
Karan Bhargava
B.Tech
Electronics Engineering
Uttarakhand Technical University
College Teacher
Vatsalya Sharma
Cross-Checked by
Madhu N. Belur

July 30, 2019

¹Funded by a grant from the National Mission on Education through ICT,
<http://spoken-tutorial.org/NMEICT-Intro>. This Textbook Companion and Scilab
codes written in it can be downloaded from the "Textbook Companion Project"
section at the website <http://scilab.in>

Book Description

Title: Microwave Engineering

Author: M. Kulkarni

Publisher: Umesh Publications, New Delhi

Edition: 1

Year: 2011

ISBN: 81-88114-26-X

Scilab numbering policy used in this document and the relation to the above book.

Exa Example (Solved example)

Eqn Equation (Particular equation of the above book)

AP Appendix to Example(Scilab Code that is an Appednix to a particular Example of the above book)

For example, Exa 3.51 means solved example 3.51 of this book. Sec 2.3 means a scilab code whose theory is explained in Section 2.3 of the book.

Contents

List of Scilab Codes	4
3 Transmission Lines	5
4 Microwaves Transmission Lines	14
5 Cavity Resonators	35
6 Microwave Components	39
7 Microwave Measurements	47
8 Microwave Tubes and Circuits	50
9 Solid State Microwave Devices	65

List of Scilab Codes

Exa 3.1	Program to find value of terminating impedance of lossless transmission line	5
Exa 3.2	Calculate the characteristic impedance and attenuation constant and phase constant of transmission line and Calculate power delivered to load if line length is 500 km	5
Exa 3.3	Calculate phase velocity of the wave that propagates on line	7
Exa 3.4	Calculate Current drawn from generator and Magnitude and phase of load current and Power delivered to load	7
Exa 3.5	Calculate VSWR and reflection coefficient .	8
Exa 3.6	Determine point of attachment and length of stub	9
Exa 3.7	Calculate terminating impedance	10
Exa 3.8	Determine the VSWR and Position of 1st Vmin to Vmax and Vmin and Vmax and Impedance at Vmin and Vmax	10
Exa 3.9	Determine in dB the reflection loss and transmission line and return loss	11
Exa 3.10	Calculate the characteristic impedance and phase velocity	12
Exa 4.1	Calculate the inductance per unit length and capacitance per unit length and characteristic impedance and velocity of propagation . . .	14
Exa 4.2	Calculate the attenuation and phase constants and phase velocity and relative permittivity and power loss	15

Exa 4.3	Calculate the breakdown power of air filled coaxial cable	16
Exa 4.4	Calculate characteristic impedance and velocity of propagation	16
Exa 4.5	Calculate characteristic impedance and effective dielectric constant and velocity of propagation	17
Exa 4.6	Calculate ratio of circular waveguide crosssectional area to rectangular waveguide crosssection	18
Exa 4.7	Calculate breadth of rectangular waveguide	19
Exa 4.8	Calculate the cutoff wavelength and guide wavelength and group and phase velocities	20
Exa 4.9	Calculate the possible modes and cutoff frequencies and guide wavelength	20
Exa 4.10	Calculate the required size of guide and frequencies that can be used for this mode of propagation	21
Exa 4.11	Find all modes that can propagate at 5000MHz	22
Exa 4.12	Calculate the cutoff wavelength and cutoff frequency and wavelength in guide	23
Exa 4.13	Calculate the frequency of the wave	24
Exa 4.14	Calculate the guide wavelength and phase constant and phase velocity for dominant mode	25
Exa 4.15	Calculate what modes propagate at free space wavelength of 10 cm and 5 cm	26
Exa 4.16	Determine the characteristic wave impedance	27
Exa 4.17	Determine the diameter of waveguide and guide wavelength	28
Exa 4.18	Show TE01 mode propagates under given conditions	29
Exa 4.19	Calculate the amount of attenuation if signal of frequency is 6GHz	29
Exa 4.20	Calculate the maximum power handling capacity	30
Exa 4.21	Calculate the maximum power	31
Exa 4.22	Calculate the peak value of electric field occurring in the waveguide	32

Exa 4.23	Calculate the breakdown power of air filled rectangular waveguide for dominant mode	32
Exa 4.24	Calculate the breakdown power of circular waveguide	33
Exa 5.1	Determine the minimum distance between two end plates	35
Exa 5.2	Calculate the lowest frequency of a rectangular cavity resonator	35
Exa 5.3	Calculate the resonant frequency of a circular cavity resonator	36
Exa 5.4	Calculate the resonant frequency of a circular cavity resonator	37
Exa 6.2	Find the distance that the position of port 1 should be shifted	39
Exa 6.3	Determine the scattering parameters for 10 dB direction coupler	40
Exa 6.4	Determine the powers in the remaining ports	41
Exa 6.5	Determine the powers in the remaining ports	41
Exa 6.6	Determine the powers reflected at port 3 and power divisions at other ports	42
Exa 6.7	Calculate the scattering matrix	43
Exa 6.9	Calculate the scattering matrix	43
Exa 6.10	Calculate the scattering matrix	44
Exa 6.11	Calculate the directivity and coupling and isolation	45
Exa 6.12	Calculate the value of VSWR	46
Exa 6.13	Calculate the phase shift of the component	46
Exa 7.1	Calculate the SWR of the transmission line	47
Exa 7.2	Calculate the SWR of the main waveguide	48
Exa 7.3	Calculate the SWR of the waveguide	48
Exa 7.4	Calculate the value of reflected power	49
Exa 8.1	Calculate the dc electron velocity and dc phase constant and plasma frequency and reduced plasma frequency and dc beam current beam density and instantaneous beam current density	50
Exa 8.2	Calculate the input rms voltage and output rms voltage and power delivered to load	51

Exa 8.3	Calculate the input power in watts and output power in watts and efficiency	52
Exa 8.4	Calculate the electron velocity and dc transit time and input voltage for maximum output voltage and voltage gain in dB	52
Exa 8.5	Calculate the input microwave voltage and voltage gain and efficiency of amplifier and beam loading conductance	53
Exa 8.6	Calculate the value of repeller voltage and beam current necessary to give gap voltage of 200V and electronic efficiency	55
Exa 8.7	Calculate the efficiency of reflex klystron and total output power in mW and power delivered to load	56
Exa 8.8	Calculate the Hull cutoff voltage and cutoff magnetic flux density if beam voltage is 6000V and cyclotron frequency in GHz	56
Exa 8.9	Calculate the Axial phase velocity and Anode voltage at which TWT can be operated for useful gain	57
Exa 8.10	Calculate the electron velocity and dc transit time and input voltage for maximum output voltage and voltage gain in dB	58
Exa 8.11	Calculate the dc electron velocity and dc phase constant and plasma frequency and reduced plasma frequency and dc beam current beam density and instantaneous beam current density	59
Exa 8.12	Calculate the gap transit angle	60
Exa 8.13	Calculate the input rf voltage and voltage gain and efficiency	61
Exa 8.14	Calculate the cyclotron angular frequency and cutoff voltage and cutoff magnetic flux . . .	62
Exa 8.15	Calculate the input power and output power in watts and efficiency	63
Exa 8.16	Calculate the repeller voltage and beam current necessary to give gap voltage of 200V .	63

Exa 9.1	Calculate i repeller voltage Vr ii beam current necessary to give gap voltage of 200V	65
Exa 9.2	Determine threshold electric field	65
Exa 9.3	Calculate the power gain in dB and power gain if it is USB converter	66
Exa 9.4	Calculate the critical voltage and breakdown voltage and breakdown electric field	67
Exa 9.5	Calculate the power gain in dB and power gain if it is USB converter	67
Exa 9.6	Calculate the power gain in dB	68
Exa 9.7	Calculate the minimum voltage needed to GUNN effect	68
Exa 9.8	Calculate the rational frequency and critical velocity of diode	69
Exa 9.9	Calculate the resonant frequency and efficiency	70
Exa 9.10	Calculate the drift time of carrier and oper- ating frequency of diode	70
Exa 9.11	Calculate the breakdown voltage and break- down electric field	71
Exa 9.12	Calculate the maximum power gain and noise figure and bandwidth	72
Exa 9.13	Calculate the equivalent noise resistance and gain and noise figure and bandwidth	73

Chapter 3

Transmission Lines

Scilab code Exa 3.1 Program to find value of terminating impedance of lossless transmission line.

```
1 //Caption:Program to find value of terminating
   impedance of lossless transmission line.
2 //Exa:3.1
3 clc;
4 clear;
5 close;
6 //Given:
7 Z_ch=100; //in ohms
8 S=5; //VSWR (unitless)
9 Z=Z_ch*S;
10 printf("\n\n\t The terminating impedance = %d ohms "
   ,Z);
```

Scilab code Exa 3.2 Calculate the characteristic impedance and attenuation constant

```

1 //Caption: Calculate the characteristic impedance ,
   attenuation constant , phase constant of
   transmission line Calculate power delivered to
   load , if line length=500 km.
2 //Exa:3.2
3 clc;
4 clear;
5 close;
6 e=2.718;
7 //Given:
8 R=8; //in ohm/kilometer
9 L=2*10^-3; //in henry/kilometer
10 C=0.002*10^-6; //in farad/kilometer
11 G=0.07*10^-6; //second/kilometer
12 f=2000; //in hertz
13 //Since [w=2*(pi)*f] & [Zch={(R+jwL)/(G+jwC)}^0.5]
14 w=2*pi*f; //in radians
15 Z_ch={(R+i*w*L)/(G+i*w*C)}^0.5; //computing
   characteristic impedance
16 disp(Z_ch,"Characteristic impedance (in ohms) =");
17 y={(R+i*w*L)*(G+i*w*C)}^0.5;
18 a=real(y); //attenuation constant
19 b=imag(y); //phase constant
20 disp(a,"Attenuation constant (in NP/km) =");
21 disp(b,"Phase constant (in radian/km) =");
22 V_in=2; //in volts
23 l=500; //in kilometers
24 Z_in=Z_ch; //Since line terminated at its char. imped
   . so , Z_in=Z_ch=Z(load)
25 I_s=V_in/Z_in;
26 Imag=[[{{real(I_s)}^2}+{{imag(I_s)}^2}]^0.5]*10^3; //in
   milliampere
27 Iang=atan(imag(I_s)/real(I_s))*(180/pi); //in
   degrees
28 I=Imag*e^-1.99; //I=Is*e^-yl
29 //P(power delivered)=I*I*REAL(Z_ch)
30 P=I*I*real(Z_ch);
31 disp(P,"Power delivered to load (in microwatt =");

```

Scilab code Exa 3.3 Calculate phase velocity of the wave that propagates on line

```
1 //Caption : Calculate phase velocity of the wave that
    //propogates on line as given in example 3.2
2 //Exa:3.3
3 clc;
4 clear;
5 close;
6 w=4*pi*10^3; //in rad/sec
7 b=0.02543; //in rad/km
8 V_p=w/b; // phase velocity
9 disp(V_p," Phase velocity (in km/sec) =");
```

Scilab code Exa 3.4 Calculate Current drawn from generator and Magnitune and phase

```
1 //Caption : Calculate (a)-Current drawn from generator
    . (b)-Magnitune & phase of load current. (c)-
    Power delivered to load .
2 //Exa: 3.4
3 clc;
4 clear;
5 close;
6 f=37.5*10^6; //frequency (in hertz)
```

```

7 wl=(3*10^8)/f; // wavelength (in meters)
8 Z_l=100; // in ohms
9 Z_o=200; // in ohms
10 l=5*wl/4; // length of line (in meters)
11 b=2*pi/wl;
12 //At generator end,
13 Z_i=Z_o*(Z_l+%i*Z_o*tan(b*l))/(Z_o+%i*Z_l*tan(b*l));
14 V_s=200*Z_i/(200+Z_i);
15 I_s=200/(200+Z_i);
16 disp(real(I_s),"Current drawn from generator (in amps
)=");
17 //for a lossless line , P(avg)*I_input=P(avg)*I_load
18 P_avg=V_s*I_s; // in watts
19 disp(real(P_avg),"Power delivered to load (in watts
)=");
20 //Real(Vs*Is)=Real(Vs*I_load)
21 I_load=(P_avg/Z_l)^0.5; // in amps
22 disp(real(I_load),"Current flowing in load (in amps
)=");

```

Scilab code Exa 3.5 Calculate VSWR and reflection coefficient

```

1 //Caption : Calculate VSWR & reflection coefficient .
2 //Exa: 3.5
3 clc;
4 clear;
5 close;
6 Z_o=50; // in ohms
7 f=300*10^6; // in Hz
8 Z_l=50+%i*50; // in ohms
9 wl=(3*10^8)/f; //wavelength (in meters)

```

```

10 P=[(Z_1-Z_o)/(Z_1+Z_o)];
11 P_mag={(real(P)^2)+(imag(P)^2)}^0.5;
12 P_ang=atan(imag(P)/real(P))*180/%pi; //in degrees
13 S={1+P_mag}/{1-P_mag};
14 disp(P,"Reflection coefficient =");
15 disp(P_mag,"Magnitude of reflection coefficient =");
16 disp(P_ang,"Angle (in degree) =");
17 disp(S,"VSWR =");

```

Scilab code Exa 3.6 Determine point of attachment and length of stub

```

1 //Caption : Determine point of attachment & length of
   stub .
2 //Exa 3.6
3 clc;
4 clear;
5 close;
6 Z_1=100; //in ohms
7 Z_o=600; //in ohms
8 f=100*10^6; //in Hz
9 wl=(3*10^8)/f;
10 //Position of stub is :
11 m=((Z_1*Z_o)/(Z_1-Z_o))^0.5;
12 pos={wl/(2*pi})*atan((Z_1/Z_o)^0.5); //in meters
13 l={wl/(2*pi})*{atan(m)}; //in meters
14 disp(pos,"Position of stub (in meters) =");
15 disp(abs(l),"Length of stub (in meters) =");

```

Scilab code Exa 3.7 Calculate terminating impedance

```
1 //Caption : Calculate terminating impedance .
2 //Exa: 3.7
3 clc;
4 clear;
5 close;
6 Z_o=50;
7 S=3.2;
8 X_min=0.23; //in terms of wavelength (wl))
9 //So :
10 Z_1=Z_o*[[1-%i*S*tan(2*%pi*X_min)]/[S-%i*tan(2*%pi*
X_min)]]; //in ohms
11 Z_lmag=[(real(Z_1)^2)+(imag(Z_1)^2)]^0.5;
12 Z_lang=atan(imag(Z_1)/real(Z_1));
13 disp("The load impedance");
14 disp(Z_lmag,"magnitude (in ohms) =");
15 disp(Z_lang*180/%pi,"angle (in degrees) =");
```

Scilab code Exa 3.8 Determine the VSWR and Position of 1st Vmin to Vmax and Vmin a

```
1 //Caption : Determine :( a)VSWR; ( b) Position of 1st Vmin
& Vmax; ( c)Vmin & Vmax; ( d)Impedance at Vmin &
Vmax.
```

```

2 //Exa: 3.8
3 clc;
4 clear;
5 close;
6 Z_o=50; //in ohms
7 Z_l=100; //in ohms
8 f=300*10^3; //in Hz
9 P_l=50*10^-3; //in watts
10 wl=(3*10^8)/f;
11 p=(Z_l-Z_o)/(Z_l+Z_o);
12 S=(1+abs(p))/(1-abs(p));
13 disp(S,"VSWR =");
14 //Since real Zl > Zo ,
15 pos=wl/4;
16 disp("First Vmax is located ---->at the load ");
17 disp("First Vmin is located at ---->(wavelength/4)= ")
    );
18 disp(pos,"( in meters)");
19 V_max=(P_l*Z_l)^0.5;
20 V_min=V_max/S;
21 disp(V_max,"Vmax (in volts) =");
22 disp(V_min,"Vmin (in volts) =");
23 disp(Z_o/S,"Zin at Vmin (in ohms) =:");
24 disp(Z_o*S,"Zin at Vmax (in ohms) =");

```

Scilab code Exa 3.9 Determine in dB the reflection loss and transmission line and

```

1 //Caption:Determine in dB: (a)-reflection loss , (b)-
    transmission line (c)-return loss .
2 //Exa: 3.9
3 clc;

```

```

4 clear;
5 close;
6 Z_o=600; //in ohm
7 Z_s=50; //in ohm
8 l=200; //in meter
9 Z_l=500; //in ohm
10 p=(Z_l-Z_o)/(Z_l+Z_o);
11 ref_los=10*(log(1/(1-(abs(p))^2)))/(log(10)); //in dB
12 disp(ref_los," Reflection loss (in dB) =");
13 //attenuation loss= 0 dB
14 //Transmisson loss = (attenuation loss)+(reflection
   loss) = (reflection loss)
15 tran_los=ref_los;
16 disp(tran_los," Transmisson loss (in dB) =");
17 ret_los=10*((log(abs(p)))/(log(10)));
18 disp(ret_los," Return loss (in dB) =");

```

Scilab code Exa 3.10 Calculate the charcterstic impedance and phase velocity

```

1 //Caption: Calculate the charcterstic impedance &
   phase velocity
2 //Exa:3.10
3 clc;
4 clear;
5 close;
6 e=2.718;
7 f=1000; //in Hz
8 l=10000; //in meters
9 Z_sc=(2631+%i*1289); //in ohms
10 Z_oc=(221-%i*137); //in ohms
11 Z_o=[Z_sc*Z_oc]^0.5;

```

```
12 Z_mag=[real(Z_o)^2+imag(Z_o)^2]^0.5;
13 Z_ang=[atan((imag(Z_o))/real(Z_o))]*180/%pi;
14 disp(Z_mag,"Characteristic impedance (in ohms) =");
15 disp(Z_ang,"Angle (in degrees) =");
16 x=[(Z_oc/Z_sc)^0.5];
17 //x=tanh(v*1)
18 //As, tanh(t)=[e^t-e^-t]/[e^t+e^-t]
19 v=(261+%i*2988)/1;
20 a=real(v);
21 b=imag(v);
22 disp(2*%pi*f/b,"Phase velocity (in meter per sec.) =
");
```

Chapter 4

Microwaves Transmission Lines

Scilab code Exa 4.1 Calculate the inductance per unit length and capacitance per unit length.

```
1 //Caption : Calculate ( i )-inductance per unit length ,( ii )-capacitance per unit length ,( iii )-characteristic impedance ,( iv )-velocity of propagation
2 //Exa:4.1
3 clc;
4 clear;
5 close;
6 //Given:
7 d=0.49; //in cm
8 D=1.1; //in cm
9 e_r=2.3;
10 c=3*10^8; //in meter/second
11 L=2*(10^-7)*log(D/d); //in Henry/meter
12 C=55.56*(10^-12)*(e_r)/log(D/d); //in farad/meter
13 R_o=(60/sqrt(e_r))*log(D/d); //in ohms
14 v=c/sqrt(e_r); //in meter/second
15 disp(L,'Inductance per unit length (in H/m) =');
16 disp(C,'Capacitance per unit length (in F/m) =');
17 disp(R_o,'Characteristic Impedance (in ohms) =');
18 disp(v,'Velocity of propagation (in m/s)=');
```

Scilab code Exa 4.2 Calculate the attenuation and phase constants and phase velocity.

```
1 //Caption : Calculate the attenuation , phase constants  
    , phase velocity , relative permittivity , power loss .  
2 //Exa:4.2  
3 clc;  
4 clear;  
5 close;  
6 R=0.05; //in ohms  
7 G=0;  
8 l=50; //in meter  
9 e=2.3; //dielectric constant  
10 c=3*10^8; //in m/s  
11 L=2*(10^-7); //from Exa:4.1  
12 C=1.58*(10^-10); //from Exa:4.1  
13 P_in=480; //in watts  
14 f=3*10^9; //in hertz  
15 Z_o=sqrt(L/C);  
16 a=R/Z_o;//in Np/m  
17 b=2*pi*f*sqrt(L*C); //in rad/m  
18 V_p=1/sqrt(L*C);  
19 e_r=(c/V_p)^2;  
20 P_loss=P_in*2*l;  
21 disp(a, 'Attenuation ( in Np/m ) =');  
22 disp(b, 'Phase constant ( in rad/m ) =');  
23 disp(V_p, 'Phase velocity ( in m/s ) =');  
24 disp(e_r, 'Relative permittivity =');  
25 disp(P_loss, 'Power loss ( in watts ) =');
```

Scilab code Exa 4.3 Calculate the breakdown power of air filled coaxial cable

```
1 //Caption: Calculate the breakdown power of air
      filled coaxial cable at 9.375 GHz.
2 //Exa:4.3
3 clc;
4 clear;
5 close;
6 //Given:
7 a=2.42; //in cm
8 x=2.3; //x=(b/a)
9 P_bd=3600*a^2*log(x); //in kilowatts
10 disp(P_bd, 'Breakdown Power (in kW) =');
11
12 //answer in book is wrongly written as 398 kW.
```

Scilab code Exa 4.4 Calculate characteristic impedance and velocity of propagation

```
1 //Caption: Calculate characteristic impedance &
      velocity of propagation .
2 //Exa:4.4
3 clc;
4 clear;
5 close;
```

```

6 b=0.3175; //in cm
7 d=0.0539; //in cm
8 c=3*10^8; //in m/s
9 e_r=2.32;
10 Z_o=60*log(4*b/(%pi*d))/sqrt(e_r); //in ohms
11 V_p=c/sqrt(e_r); //in m/s
12 disp(Z_o,'Characteristic impedance (in ohms) =');
13 disp(V_p,'Velocity of propagation (in m/s) =');

```

Scilab code Exa 4.5 Calculate characteristic impedance and effective dielectric con

```

1 //Caption: Calculate characteristic impedance &
   effective dielectric constant & velocity of
   propagation
2 //Exa:4.5
3 clc;
4 clear;
5 close;
6 e_r=9.7;
7 c=3*10^8; //in m/s
8 r_1=0.5; //when ratio : (W/h)=0.5
9 r_2=5; //when ratio : (W/h)=5
10 //For W/h ratio=0.5
11 e_eff_1=(e_r+1)/2+((e_r-1)/2)*[1/{sqrt(1+12*(1/r_1))
   +0.04*(1-r_1)}];
12 Z_o_1=60*log(8/r_1+r_1/4)/sqrt(e_eff_1);
13 v_1=c/sqrt(e_eff_1);
14 disp("For W/h=0.5 ,");
15 disp(e_eff_1,'Effective dielectric constant =');
16 disp(Z_o_1,'Characteristic impedance (in ohms) =');
17 disp(v_1,'Velocity of propagation (in m/s) =');

```

```

18 //For W/h ratio=5
19 e_eff_2=(e_r+1)/2+((e_r-1)/2)*[1/{sqrt(1+12*(1/r_2))
}];
20 Z_o_2=120*%pi*[1/{r_2+1.393+0.667*log(1.444+r_2)}]/
sqrt(e_eff_2);
21 v_2=c/sqrt(e_eff_2);
22 disp("For W/h=5,");
23 disp(e_eff_2,'Effective dielectric constant =');
24 disp(Z_o_2,'Characteristic impedance (in ohms) =');
25 disp(v_2,'Velocity of propagation (in m/s) =');

```

Scilab code Exa 4.6 Calculate ratio of circular waveguide crosssectional area to rectangular waveguide cross-section

```

1 //Caption: Calculate ratio of circular waveguide
   cross-sectional area to rectangular waveguide
   cross-section
2 //Exa:4.6
3 clc;
4 clear;
5 close;
6 //For TE Wave propagated:
7 //for Rectangular , taking (a=2b)
8 r=100; //assume
9 //for TE11, wavelength=2*pi*r/1.841
10 //for TE10, wavelength=2a
11 a=(2*pi*r/1.841)/2;
12 ar_rec_TE=(a)*(a/2);
13 ar_cir_TE=%pi*r^2;
14 ratio_TE=(ar_cir_TE)/(ar_rec_TE);
15 disp(ratio_TE,'Ratio of Circular & Rectangular coss-
   section area (in TE) =');

```

```
16 //For TM Wave propagated:  
17 //for Rectangular , taking (a=2b)  
18 //for TE01, wavelength=2.6155*r  
19 //for TE11, wavelength=4b/sqrt(5)  
20 b=(2.6155*r)/1.78885;  
21 ar_rec_TM=(b)*(b);  
22 ar_cir_TM=%pi*r^2;  
23 ratio_TM=(ar_cir_TM)/(ar_rec_TM);  
24 disp(ratio_TM,'Ratio of Circular & Rectangular coss-  
section area (in TM) =');
```

Scilab code Exa 4.7 Calculate breadth of rectangular waveguide

```
1 //Caption : Calculate breadth of rectangular waveguide  
2 //Exa:4.7  
3 clc;  
4 clear;  
5 close;  
6 f=9*10^9; //in Hz  
7 c=3*10^10; //in cm/s  
8 wl_g=4; //in m  
9 wl_o=c/f;  
10 wl_c=[sqrt(1-((wl_o/wl_g)^2))/wl_o]^-1;  
11 b=wl_c/4;  
12 disp(b,'Breadth of rectangular waveguide (in cm) =')  
;
```

Scilab code Exa 4.8 Calculate the cutoff wavelength and guide wavelength and group

```
1 //Caption : Calculate the cutoff wavelength , guide  
    wavelength , group & phase velocities  
2 //Exa:4.8  
3 clc;  
4 clear;  
5 close;  
6 a=10; //in cm  
7 c=3*10^10; //in cm/s  
8 wl_c=2*a; //in cm  
9 f=2.5*10^9; //in Hz  
10 wl_o=c/f;  
11 wl_g=wl_o/(sqrt(1-(wl_o/wl_c)^2)); //in cm  
12 V_p=c/(sqrt(1-(wl_o/wl_c)^2));  
13 V_g=c^2/V_p;  
14 disp(wl_c, 'Cut-off wavelength (in cm) =');  
15 disp(wl_g, 'Guide wavelength (in cm) =');  
16 disp(V_p, 'Phase velocity (in cm/s) =');  
17 disp(V_g, 'Group velocity (in cm/s) =');
```

Scilab code Exa 4.9 Calculate the possible modes and cutoff frequencies and guide

```

1 //Caption: Calculate (i)-possible modes,( ii)-cut-off
   frequencies ,( iii)-guide wavelength
2 //Exa:4.9
3 clc;
4 clear;
5 close;
6 //For TE mode:
7 a=2.5; //in cm
8 b=1; //in cm
9 f=8.6*10^9; //in Hz
10 c=3*10^10; //in cm/s
11 wl_o=c/f;
12 wl_c_1=2*b; //for TE01
13 wl_c_2=2*a; //for TE10
14 disp( 'Only TE10 mode is possible');
15 f_c=c/wl_c_2;
16 wl_c_3=2*a*b/sqrt(a^2+b^2); //for TE11 & TM11
17 wl_g_TE10=wl_o/(sqrt(1-(wl_o/wl_c_2)^2)); //for TE10
18 disp(f_c,'Cut-off frequency (in Hz) =');
19 disp(wl_g_TE10,'Guide wavelength for TE10 (in cm) =' );
20 //For TM mode:
21 disp('TM11 also propagates');
22 wl_c_TM11=wl_c_3;
23 wl_g_TM11=wl_o/(sqrt(1-(wl_o/wl_c_2)^2)); //for TM11
24 disp(wl_g_TM11,'Guide wavelength for TM11 (in cm) =' );

```

Scilab code Exa 4.10 Calculate the required size of guide and frequencies that can

```

1 //Caption: Calculate (i)-required size of guide ,( ii)-
   frequencies that can be used for this mode of
   propagation

```

```

2 //Exa:4.10
3 clc;
4 clear;
5 close;
6 wl_c=10; //in cm
7 c=3*10^10; //in cm/s
8 r=wl_c/(2*pi/1.841); //in cm
9 area=%pi*r^2; //in sq. cm
10 f_c=c/wl_c;
11 disp(r,'Radius of circular waveguide(in cm) =');
12 disp(area,'Area of cross-section of circular
    waveguide(in cm) =');
13 disp('Frequency above');
14 disp(f_c);
15 disp('can be propagated');

```

Scilab code Exa 4.11 Find all modes that can propagate at 5000MHz

```

1 //Caption:Find all modes that can propagate at 5000
    MHz.
2 //Exa:4_11
3 clc;
4 clear;
5 close;
6 a=4; //in cm
7 b=3; //in cm
8 f=5*10^9; //in Hz
9 c=3*10^10; //in cm/s
10 wl_o=c/f;
11 //For TE waves:
12 wl_c_TE01=2*b; //for TE01

```

```

13 wl_c_TE10=2*a; //for TE10
14 wl_c_TE11=2*a*b/sqrt(a^2+b^2); //for TE11
15 if(wl_c_TE01>wl_o)
16     disp('TE01 can propagate');
17 else
18     disp('TE01 cannot propagate');
19 end
20 if(wl_c_TE10>wl_o)
21     disp('TE10 can propagate');
22 else
23     disp('TE10 cannot propagate');
24 end
25 if(wl_c_TE11>wl_o)
26     disp('TE11 can propagate');
27 else
28     disp('TE11 cannot propagate');
29 end

```

Scilab code Exa 4.12 Calculate the cutoff wavelength and cutoff frequency and wave

```

1 //Caption :Find all modes that can propagate at 5000
MHz.
2 //Exa:4_11
3 clc;
4 clear;
5 close;
6 a=4; //in cm
7 b=3; //in cm
8 f=5*10^9; //in Hz
9 c=3*10^10; //in cm/s
10 wl_o=c/f;

```

```

11 //For TE waves:
12 wl_c_TE01=2*b; //for TE01
13 wl_c_TE10=2*a; //for TE10
14 wl_c_TE11=2*a*b/sqrt(a^2+b^2); //for TE11
15 if(wl_c_TE01>wl_o)
16     disp('TE01 can propagate');
17 else
18     disp('TE01 cannot propagate');
19 end
20 if(wl_c_TE10>wl_o)
21     disp('TE10 can propagate');
22 else
23     disp('TE10 cannot propagate');
24 end
25 if(wl_c_TE11>wl_o)
26     disp('TE11 can propagate');
27 else
28     disp('TE11 cannot propagate');
29 end

```

Scilab code Exa 4.13 Calculate the frequency of the wave

```

1 //Caption: Calculate ( i )-cutoff wavelength ,( ii )-
           cutoff frequency ,( iii )-wavelength in guide
2 //Exa:4.12
3 clc;
4 clear;
5 close;
6 c=3*10^10; //in cm/s
7 d=4; //in cm
8 r=d/2; //in cm

```

```

9 wl_c=2*pi*r/1.841; //in cm
10 f_c=c/wl_c;
11 f_signal=5*10^9; //in Hz
12 wl_o=c/f_signal;
13 wl_g=wl_o/sqrt(1-(wl_o/wl_c)^2);
14 disp(wl_c,'Cut-off wavelength (in cm) =');
15 disp(f_c,'Cut-off frequency (in Hz) =');
16 disp(wl_g,'Guide wavelength (in cm) =');

```

Scilab code Exa 4.14 Calculate the guide wavelength and phase constant and phase v

```

1 //Caption: Calculate (i)-guide wavelength,(ii)-phase
    constant,(iii)-phase velocity for dominant mode
2 //Exa:4.14
3 clc;
4 clear;
5 close;
6 c=3*10^10; //in cm/s
7 a=5; //in cm
8 b=2.5; //in cm
9 wl_o=4.5; //in cm
10 //For TE10 mode:
11 wl_c=2*a;
12 wl_g=wl_o/sqrt(1-(wl_o/wl_c)^2);
13 V_p=c/sqrt(1-(wl_o/wl_c)^2);
14 w=2*pi*c/wl_o;
15 w_c=2*pi*c/wl_c;
16 b=sqrt(w^2-w_c^2)/c;
17 disp(wl_g,'Guide wavelength (in cm) =');
18 disp(b,'Phase constant =');
19 disp(V_p,'Phase velocity (in cm/s) =');

```

```
20
21 // answer in book is wrongly written as guide
22 // wavelength =7.803 cm
22 // answer in book is wrongly written as Phase
22 // velocity = 5.22*10^10 cm/s
```

Scilab code Exa 4.15 Calculate what modes propagate at free space wavelength of 10 cm

```
1 //Caption : Calculate what modes propagate at free
2 // space wavelength of ( i ) 10 cm , ( ii ) 5 cm
3 //Exa:4.15
4 clc;
5 clear;
6 close;
7 c=3*10^10; //in cm/s
8 wl_c_TE10=16; // Critical wavelength of TE10
9 wl_c_TM11=7.16; // Critical wavelength of TM11
10 wl_c_TM21=5.6; // Critical wavelength of TM21
11 //For ( i ) : 10 cm
12 wl_o=10; //in cm
13 disp(wl_o,'For free space wavelength ( in cm ) = ');
14 if(wl_c_TE10>wl_o)
15     disp('    TE10 can propagate ');
16 else
17     disp('    TE10 cannot propagate ');
18 end
19 if(wl_c_TM11>wl_o)
20     disp('    TM11 can propagate ');
21 else
22     disp('    TM11 cannot propagate ');
22 end
```

```

23 if(wl_c_TM21>wl_o)
24     disp('      TM21 can propagate');
25 else
26     disp('      TM21 cannot propagate');
27 end
28 //For (ii): 5 cm
29 wl_o=5;//in cm
30 disp(wl_o,'For free space wavelength (in cm) =');
31 if(wl_c_TE10>wl_o)
32     disp('      TE10 can propagate');
33 else
34     disp('      TE10 cannot propagate');
35 end
36 if(wl_c_TM11>wl_o)
37     disp('      TM11 can propagate');
38 else
39     disp('      TM11 cannot propagate');
40 end
41 if(wl_c_TM21>wl_o)
42     disp('      TM21 can propagate');
43 else
44     disp('      TM21 cannot propagate');
45 end

```

Scilab code Exa 4.16 Determine the characteristic wave impedance

```

1 //Caption: Determine the characteristic wave impedance
2 //Exa:4.16
3 clc;
4 clear;
5 close;

```

```

6 c=3*10^10; //in cm/s
7 f=10*10^9; //in Hz
8 a=3; //in cm
9 b=2; //in cm
10 n=120*pi;
11 wl_o=c/f;
12 wl_c=2*a*b/sqrt(a^2+b^2);
13 Z_TM=n*sqrt(1-(wl_o/wl_c)^2);
14 disp(Z_TM, 'Characteristic impedance (in ohms) =');
15
16 //answer in book is wrongly written as 61.618 ohms

```

Scilab code Exa 4.17 Determine the diameter of waveguide and guide wavelength

```

1 //Caption : Determine the diameter of waveguide &
           guide wavelength
2 //Exa:4.17
3 clc;
4 clear;
5 close;
6 c=3*10^10; //in cm/s
7 f=6*10^9; //in Hz
8 f_c=0.8*f;
9 wl_c=c/f_c;
10 D=1.841*wl_c/%pi;
11 wl_o=c/f;
12 wl_g=wl_o/sqrt(1-(wl_o/wl_c)^2);
13 disp(D, 'Diameter of waveguide (in cm) =');
14 disp(wl_g, 'Guide wavelength (in cm) =');

```

Scilab code Exa 4.18 Show TE01 mode propagates under given conditions

```
1 //Caption:Show TE01 mode propagates under given
   conditions
2 //Exa:4.18
3 clc;
4 clear;
5 close;
6 a=1.5; //in cm
7 b=1; //in cm
8 e_r=4; //dielectric
9 c=3*10^10; //in cm/s
10 wl_c=2*b;
11 f_c=c/wl_c;
12 f_imp=6*10^9; //impressed frequency (in Hz)
13 wl_air=c/f_imp;
14 //Inserting dielectric:
15 wl_dielec=wl_air/sqrt(e_r);
16 if(wl_dielec>wl_c)
17     disp('      TE01 can propagate');
18 else
19     disp('      TE01 cannot propagate');
20 end
```

Scilab code Exa 4.19 Calculate the amount of attenuation if signal of frequency is

```

1 //Caption: Calculate the amount of attenuation if
    signal of frequency is 6GHz
2 //Exa:4.19
3 clc;
4 clear;
5 close;
6 u=4*pi*10^-7;
7 e=8.85*10^-12;
8 c=3*10^10; //in cm/s
9 f=6*10^9; //in Hz
10 a=1.5; //in cm
11 b=1; //in cm
12 //For TE10 mode:
13 m=1;
14 n=0;
15 wl_c=2*a;
16 f_c=c/wl_c;
17 t_1=(m*pi/a)^2;
18 t_2=(n*pi/b)^2;
19 t_3=((2*pi*f)^2)*u*e;
20 a=sqrt(t_1+t_2-t_3); //in neper/m
21 disp(a*20*log(10), 'Attenuation (in dB/m) =');

```

Scilab code Exa 4.20 Calculate the maximum power handling capacity

```

1 //Caption: Calculate the maximum power handling
    capacity
2 //Exa:4.21
3 clc;
4 clear;
5 close;

```

```

6 c=3*10^10; //in cm/s
7 f=9*10^9; //inHz
8 a=3; //in cm
9 b=1; //in cm
10 E_max=3000; //in V/cm
11 wl_o=c/f;
12 wl_c=2*a; //in TE10
13 wl_g=ceil (wl_o/sqrt(1-(wl_o/wl_c)^2));
14 P_max=(6.63*10^-4)*E_max^2*a*b*(wl_o/wl_g);
15 disp(P_max/1000,'Maximum power for rectangular
waveguide (in kilowatts)=');

```

Scilab code Exa 4.21 Calculate the maximum power

```

1 //Caption : Calculate the maximum power
2 //Exa:4.21
3 clc;
4 clear;
5 close;
6 c=3*10^10; //in cm/s
7 f=9*10^9; //inHz
8 E_max=300; //in V/cm
9 d=5;
10 wl_o=c/f;
11 //For TE11
12 wl_c=d*pi/1.841;
13 wl_g=wl_o/sqrt(1-(wl_o/wl_c)^2);
14 P_max=0.498*E_max^2*d^2*(wl_o/wl_g);
15 disp(P_max,'Maximum power (in watts) =');

```

Scilab code Exa 4.22 Calculate the peak value of electric feild occuring in the wa

```
1 //Caption:Calculate the peak value of electric feild  
          occurring in the waveguide  
2 //Exa:4.22  
3 clc;  
4 clear;  
5 close;  
6 c=3*10^10; //in cm/s  
7 f=30*10^9; //inHz  
8 a=1; //in cm  
9 b=1;  
10 P_max=746; //in watts  
11 wl_o=c/f;  
12 wl_c=2*a;  
13 Z=120*%pi/sqrt(1-(wl_o/wl_c)^2);  
14 E_max=sqrt(P_max*4*Z/(a*b/10000));  
15 disp(E_max/1000,'Peak value of electric field (in kV  
/m) =');
```

Scilab code Exa 4.23 Calculate the breakdown power of air filled rectangular waveg

```
1 //Caption:Calculate the breakdown power of air  
          filled rectangular waveguide for dominant mode at
```

```

    9.375 GHz.
2 //Exa:4.23
3 clc;
4 clear;
5 close;
6 //Given:
7 c=3*10^10; //in cm/s
8 a=2.3; //in cm
9 b=1; //in cm
10 f=9.375*10^9; //in Hz
11 wl_o=c/f;
12 P_bd_TE11=597*2.3*1*{1-{wl_o/(2*a)}^2}^0.5;
13 disp(P_bd_TE11, 'Breakdown power for dominant mode (
    in kW) =');

```

Scilab code Exa 4.24 Calculate the breakdown power of circular waveguide

```

1 //Caption: Calculate the breakdown power of circular
   waveguide
2 //Exa:4.24
3 clc;
4 clear;
5 close;
6 //Given:
7 d=5; //in cm
8 c=3*10^10; //in cm/s
9 f=9*10^9; //inHz
10 //Dominant mode is TE11:
11 wl_o=c/f;
12 wl_c=%pi*d/1.841;
13 f_c=c/wl_c;

```

```
14 P_bd_TE11=1790*(d/2)^2*[1-{f_c/f}^2]^0.5;  
15 disp(P_bd_TE11/1000, 'Breakdown power (in kW) =');
```

Chapter 5

Cavity Resonators

Scilab code Exa 5.1 Determine the minimum distance between two end plates

```
1 //Caption : Determine the minimum distance between two
   end plates
2 //Exa:5.1
3 clc;
4 clear;
5 close;
6 //Given:
7 a=3; //in cm
8 c=3*10^10; //in cm/s
9 f=10*10^9; //in Hz
10 P_01=2.405;
11 d=%pi/sqrt(f^2*4*pi^2/c^2-(P_01/a)^2);
12 disp(d, 'Minimum distance (in cm) =');
```

Scilab code Exa 5.2 Calculate the lowest frequency of a rectangular cavity resonator

```

1 //Caption: Calculate the lowest frequency of a
    rectangular cavity resonator
2 //Exa:5.2
3 clc;
4 clear;
5 close;
6 //Given:
7 c=3*10^10; //in cm/s
8 a=2; //in cm
9 b=1; //in cm
10 d=3; //in cm
11 disp('Dominant mode is TE101');
12 m=1;
13 n=0;
14 p=1;
15 f=(c/2)*[(m/a)^2+(n/b)^2+(p/d)^2]^0.5;
16 disp(f/10^9, 'Lowest resonant frequency (in GHz) =');

```

Scilab code Exa 5.3 Calculate the resonant frequency of a circular cavity resonator

```

1 //Caption: Calculate the resonant frequency of a
    circular cavity resonator
2 //Exa:5.3
3 clc;
4 clear;
5 close;
6 //Given:
7 d=12.5; //diameter (in cm)
8 c=3*10^10; //in cm/s
9 l=5; //length (in cm)
10 a=d/2;

```

```

11 //For TM012 mode:
12 n=0;
13 m=1;
14 p=2;
15 P=2.405;
16 f=(c/(2*pi))*[(P/a)^2+(p*pi/d)^2]^0.5;
17 disp(f/10^9, 'Resonant frequency (in GHz) =');
18
19 //Answer in book is wrongly given as 6.27GHz

```

Scilab code Exa 5.4 Calculate the resonant frequency of a circular cavity resonator

```

1 //Caption: Calculate the resonant frequency of a
           circular cavity resonator
2 //Exa:5.4
3 clc;
4 clear;
5 close;
6 //Given:
7 c=3*10^10; //in cm/s
8 a=3; //in cm
9 b=2; //in cm
10 d=4; //in cm
11 //For TE101:
12 m=1;
13 n=0;
14 p=1;
15 f=(c/2)*[(m/a)^2+(n/b)^2+(p/d)^2]^0.5;
16 disp(f/10^9, 'Resonant frequency (in GHz) =');

```

Chapter 6

Microwave Components

Scilab code Exa 6.2 Find the distance that the position of port 1 should be shifted .

```
1 //Caption:Find the distance that the position of  
    port 1 should be shifted .  
2 //Exa:6.2  
3 clc;  
4 clear;  
5 close;  
6 Beeta=34.3; //in rad/m  
7 // S=[0 ,0.5*%e^(%i*53.13);0.5*%e^(%i*53.13) ,0];  
8 // S'=[0 ,0.5*%e^(%i*53.13-x);0.5*%e^(%i*53.13-x) ,0];  
9 //For S12& S21 to be real ,  
10 x=53.5; //in degrees  
11 x_rad=53.5*pi/180;  
12 l=x_rad/Beeta;  
13 disp(l*100 , 'Distance ( in cm)=');
```

Scilab code Exa 6.3 Determine the scattering parameters for 10 dB direction coupler

```
1 //Caption : Determine the scattering parameters for 10
   dB direction coupler
2 //Exa:6.3
3 clc;
4 clear;
5 close;
6 D=30; //in dB
7 VSWR=1;
8 C=10;
9 //p1_p4 = p1/p4
10 p1_p4=10^(C/-10);
11 S_41=sqrt(p1_p4);
12 S_14=S_41;//As matched & lossless
13 S_31=S_41^2/10^(D/10);
14 S_11=(VSWR-1)/(VSWR+1);
15 S_22=S_11;
16 S_44=S_11;
17 S_33=S_11;
18 S_21=sqrt(1-0.1-10^-4);
19 S_12=S_21;
20 S_34=sqrt(1-0.1-10^-4);
21 S_43=S_34;
22 S_24=sqrt(1-0.1-S_34^2);
23 S_42=S_24;
24 S_23=S_41;
25 S_32=S_23;
26 S_13=S_31;
27 S=[S_11,S_12,S_13,S_14;S_21,S_22,S_23,S_24;S_31,S_32
     ,S_33,S_34;S_41,S_42,S_43,S_44];
28 disp(S, 'Required Scattering Parameters are');
```

Scilab code Exa 6.4 Determine the powers in the remaining ports

```
1 //Caption : Determine the powers in the remaining
   ports
2 //Exa:6.4
3 clc;
4 clear;
5 close;
6 a_2=0;
7 a_3=0;
8 a_1=32; //in mW
9 b_1=(a_1/2^2)+(a_2/-2)+(a_3/sqrt(2));
10 b_2=(a_1/(-2)^2)+(a_2/-2)+(a_3/sqrt(2));
11 b_3=(a_1/2)+(a_2/sqrt(2))+(a_3/-sqrt(2));
12 disp(b_1, 'Power at port1(in mW)=');
13 disp(b_2, 'Power at port2(in mW) =');
14 disp(b_3, 'Power at port3(in mW) =');
```

Scilab code Exa 6.5 Determine the powers in the remaining ports

```
1 //Caption : Determine the powers in the remaining
   ports
2 //Exa:6.5
3 clc;
```

```

4 clear;
5 close;
6 b_1=20;
7 b_2=20;
8 p_1=abs((60-50)/(60+50));
9 p_2=abs((75-50)/(75+50));
10 P_1=b_1*(1-p_1^2)/2;
11 P_2=b_2*(1-p_2^2)/2;
12 disp(P_1,'Power in port1 (in mW) =');
13 disp(P_2,'Power in port2 (in mW) =');

```

Scilab code Exa 6.6 Determine the powers reflected at port 3 and power divisions at other ports.

```

1 //Caption : Determine the powers reflected at port 3 &
             power divisions at other ports .
2 //Exa:6.6
3 clc;
4 clear;
5 close;
6 p_1=0.5;
7 p_2=0.6;
8 p_4=0.8;
9 b_1=0.6566;
10 b_2=0.7576;
11 b_3=0.6536;
12 b_4=0.00797;
13 a_1=p_1*b_1;
14 a_2=p_2*b_2;
15 a_3=1; //in Watts
16 a_4=p_4*b_4;
17 disp(b_1^2,'Power at port 1 (in W)=');

```

```
18 disp(b_2^2,'Power at port 2(in W)=') ;
19 disp(b_3^2,'Power at port 3(in W)=') ;
20 disp(b_4^2,'Power at port 4(in W)=') ;
```

Scilab code Exa 6.7 Calculate the scattering matrix

```
1 //Caption : Calculate the scattering matrix .
2 //Exa:6.7
3 clc;
4 clear;
5 close;
6 In_loss=0.5; //in dB
7 S_21=10^(-In_loss/20);
8 Isolation=30; //in dB
9 S_12=10^(-Isolation/20);
10 S_11=0;
11 S_22=0;
12 S=[S_11,S_12;S_21,S_22];
13 disp(S,'Scattering matrix =');
```

Scilab code Exa 6.9 Calculate the scattering matrix

```
1 //Caption : Calculate the scattering matrix .
2 //Exa:6.9
3 clc;
```

```

4 clear;
5 close;
6 VSWR=1;
7 In_loss=0.5; //in dB
8 S_21=10^(-In_loss/20);
9 Isolation=20; //in dB
10 S_12=10^(-Isolation/20);
11 S_23=S_12;
12 S_31=S_12;
13 S_32=S_21;
14 S_13=S_21;
15 p=(VSWR-1)/(VSWR+1);
16 S_11=p;
17 S_22=p;
18 S_33=p;
19 S=[S_11,S_12,S_13;S_21,S_22,S_23;S_31,S_32,S_33];
20 disp(S,'Scattering matrix =');

```

Scilab code Exa 6.10 Calculate the scattering matrix

```

1 //Caption : Calculate the scattering matrix .
2 //Exa:6.10
3 clc;
4 clear;
5 close;
6 In_loss=0.5; //insertion loss (in dB)
7 C=20; //in dB
8 D=35; //in dB
9 Pi_Pf=10^(C/10);
10 Pi=90; //in Watts
11 Pf=Pi/Pi_Pf;

```

```

12 Pf_Pb=10^(D/10);
13 Pb=Pf/Pf_Pb;
14 P_rec=(Pi-Pf-Pb); //Power received (in Watts)
15 P_rec_dB=10*log(Pi/P_rec)/log(10);
16 P_rec_eff=P_rec_dB-In_loss; //Effective power
    received (in dB)
17 disp(P_rec_eff, 'Effective power received (in dB)=');

```

Scilab code Exa 6.11 Calculate the directivity and coupling and isolation

```

1 //Caption: Calculate (i)-directivity ,( ii)-coupling ,
    ( iii)-isolation
2 //Exa:6.11
3 clc;
4 clear;
5 close;
6 S_13=0.1;
7 S_14=0.05;
8 C=-20*log(S_13)/log(10);
9 D=20*log(S_13/S_14)/log(10);
10 I=C+D;
11 disp(C, 'Coupling (in dB) =');
12 disp(D, 'Directivity (in dB)) =');
13 disp(I, 'Isolation (in dB) =');

```

Scilab code Exa 6.12 Calculate the value of VSWR

```
1 //Caption : Calculate the value of VSWR
2 //Exa:6.12
3 clc;
4 clear;
5 close;
6 D=3.5; //distance of seperation (in cm)
7 w_l=2*D; //wavelength
8 d2_d1=2.5; //d2-d1 (in m)
9 S=w_l/(%pi*d2_d1*10^-1);
10 disp(S, 'VSWR =');
```

Scilab code Exa 6.13 Calculate the phase shift of the component

```
1 //Caption : Calculate the phase shift of the component
2 //Exa:6.13
3 clc;
4 clear;
5 close;
6 w_l=7.2; //wavelength (in cm)
7 x=10.5-9.3;
8 Phase_shift=(2*%pi*x)/(w_l);
9 disp(Phase_shift*180/%pi, 'Phase Shift (in degree) =' );
```

Chapter 7

Microwave Measurements

Scilab code Exa 7.1 Calculate the SWR of the transmission line

```
1 //Caption : Calculate the SWR of the transmission line
2 //Exa:7.1
3 clc;
4 clear;
5 close;
6 //Given:
7 c=3*10^10; //in cm/s
8 a=4; //in cm
9 b=2.5; //in cm
10 f=10*10^9; //in Hz
11 d=0.1; //distance between 2 minimum power points (in
cm)
12 //For TE10 mode:
13 wl_c=2*a;
14 wl_o=c/f;
15 wl_g=wl_o/sqrt(1-(wl_o/wl_c)^2);
16 S=wl_g/(%pi*d);
17 disp(S, 'Voltage standing wave ratio =');
```

Scilab code Exa 7.2 Calculate the SWR of the main waveguide

```
1 //Caption : Calculate the SWR of the main waveguide
2 //Exa:7.2
3 clc;
4 clear;
5 close;
6 //Given:
7 P_i=300; //in mW
8 P_r=10; //in mW
9 p=sqrt(P_r/P_i);
10 S=(1+p)/(1-p);
11 disp(S, 'Voltage standing wave ratio =');
```

Scilab code Exa 7.3 Calculate the SWR of the waveguide

```
1 //Caption : Calculate the SWR of the waveguide
2 //Exa:7.3
3 clc;
4 clear;
5 close;
6 //Given:
7 P_i=2.5; //in mW
8 P_r=0.15; //in mW
```

```
9 p=sqrt(P_r/P_i);
10 S=(1+p)/(1-p);
11 disp(S,'Voltage standing wave ratio =');
```

Scilab code Exa 7.4 Calculate the value of reflected power

```
1 //Caption : Calculate the value of reflected power
2 //Exa:7.4
3 clc;
4 clear;
5 close;
6 //Given:
7 P_i=4.5; //in mW
8 S=2; //VSWR
9 C=30; //in dB
10 p=(S-1)/(S+1);
11 P_f=P_i/(10^(C/10));
12 P_r=p^2*P_i;
13 disp(P_r,'Reflected power (in watts) =');
```

Chapter 8

Microwave Tubes and Circuits

Scilab code Exa 8.1 Calculate the dc electron velocity and dc phase constant and p

```
1 //Caption: Calculate (i)-dc electron velocity ,(ii)-dc
   phase constant , (iii)-plasma frequency , (iv)-
   reduced plasma frequency for R=0.4, (v)-dc beam
   current beam density , (vi)-instantaneous beam
   current density
2 //Exa:8.1
3 clc;
4 clear;
5 close;
6 V_o=14.5*10^3; //in volts
7 I_o=1.4; //in A
8 f=10*10^9; //in Hz
9 p_o=10^-6; //in c/m^3
10 p=10^-8; //in c/m^3
11 v=10^5; //in m/s
12 R=0.4;
13 v_o=0.593*10^6*sqrt(V_o);
14 k=2*pi*f/v_o;
15 w_p=[1.759*10^11*(10^-6/(8.854*10^-12))]^0.5;
16 w_q=R*w_p;
17 J_o=p_o*v_o;
```

```

18 J=p*v_o+p_o*v;
19 disp(v_o,'Dc electron velocity (in m/s) =');
20 disp(k,'Dc phase constant (in rad/s) =');
21 disp(w_p,'Plasma frequency (in rad/s) =');
22 disp(w_q,'Reduced plasma frequency (in rad/s) =');
23 disp(J_o,'Dc beam current density (in A/sq. m) =');
24 disp(J,'Instantaneous beam current density (in A/sq.
m) =');
25
26 //Answer in book are wrongly written as: (Dc phase
constant =1.41* 10^8 rad/sec)

```

Scilab code Exa 8.2 Calculate the input rms voltage and output rms voltage and power delivered to load

```

1 //Caption: Calculate (i)-input rms voltage ,( ii)-
output rms voltage , ( iii)-power delivered to load
2 //Exa:8.2
3 clc;
4 clear;
5 close;
6 A_v=15; //in dB
7 P_i=5*10^-3; //in W
8 R_sh_i=30000; //in ohms
9 R_sh_o=40000; //in ohms
10 R_l=20000; //in ohms
11 V_i=sqrt(P_i*R_sh_i);
12 V_o=10^((A_v/20))*12.25;
13 P_out=V_o^2/R_l;
14 disp(V_i,'Input rms voltage (in volts) =');
15 disp(V_o,'Output rms voltage (in volts) =');
16 disp(P_out,'Power delivered to load (in watts) =');

```

Scilab code Exa 8.3 Calculate the input power in watts and output power in watts a

```
1 //Caption: Calculate (i)-input power in watts ,( ii)-
   output power in watts , ( iii)-efficiency
2 //Exa:8.3
3 clc;
4 clear;
5 close;
6 n=2;
7 V_o=300; //in volts
8 I_o=20*10^-3; //in A
9 V_i=40; //in volts
10 J=1.25; //J(X')
11 P_dc=V_o*I_o;
12 P_ac=2*V_o*I_o*J/(2*n*pi-%pi/2);
13 eff=(P_ac/P_dc)*100;
14 disp(P_dc,'Input power (in watts) =');
15 disp(P_ac,'Output power (in watts) =');
16 disp(eff,'Efficiency (in percent) =');
```

Scilab code Exa 8.4 Calculate the electron velocity and dc transit time and input

```
1 //Caption: Calculate (i)-electron velocity ,( ii)-dc
   transit time , ( iii)-input voltage for maximum
```

```

        output voltage ,( iv )-voltage gain in dB
2 //Exa:8.4
3 clc;
4 clear;
5 close;
6 V_o=900; //in volts
7 I_o=30*10^-3; //in A
8 f=8*10^9; //in Hz
9 d=0.001; //in m
10 l=0.04; //in m
11 R_sh=40*10^3; //in ohm
12 v_o=0.593*10^6*sqrt(V_o);
13 T_o=l/v_o;
14 Theeta_o=(2*pi*f)*T_o; //Transit angles between
    cavities (in radian)
15 Theeta_g=(2*pi*f)*d/v_o; //Average gap transit angle
    (in radian)
16 b=sin(Theeta_g/2)/(Theeta_g/2);
17 V_in_max=V_o*3.68/(b*Theeta_o);
18 //As, {J(X)/X=0.582}
19 A_r=b^2*Theeta_o*0.582*R_sh/(30*10^3*1.841);
20 disp(v_o,'Electron velocity (in m/s) =');
21 disp(T_o,'Dc Transit Time (in sec)=');
22 disp(V_in_max,'Maximum input voltage (in volts) =');
23 disp(A_r,'Voltage gain (in dB) =');

```

Scilab code Exa 8.5 Calculate the input microwave voltage and voltage gain and eff

```

1 //Caption : Calculate ( i )-i/p microwave voltage ,( ii )-
    voltage gain , ( iii )-efficiency of amplifier ,( iv )-
    beam loading conductance

```

```

2 //Exa:8.5
3 clc;
4 clear;
5 close;
6 V_o=1200; //in volts
7 I_o=28*10^-3; //in A
8 f=8*10^9; //inHz
9 d=0.001; //in m
10 l=0.04; //in m
11 R_sh=40*10^3; //in ohms
12 V_p_max=1200*3.68*0.593*10^6*sqrt(V_o)/(2*pi*f*l);
13 Theeta_g=(2*pi*f)*d/(0.593*10^6*sqrt(V_o)); //
    transit angle (in rad)
14 beeta=sin(Theeta_g/2)/(Theeta_g/2);
15 V_i_max=V_p_max/beeta;
16 Beeta_o=0.768;
17 J=0.582; //J(X)
18 A_v=(Beeta_o)^2*97.88*J*R_sh/(1200/(28*10^-3*1.841))
    ; //calculating voltage gain
19 eff=[0.58*[2*28*10^-3*J*Beeta_o*R_sh]/V_o]*100; //
    calculating efficiency
20 G_o=23.3*10^-6;
21 G_b=(G_o/2)*{Beeta_o^2-Beeta_o*cos(Theeta_g)}; //beam
    loading conductance
22 R_b=1/(G_b*1000); //beam loading resistance(in kilo
    ohms)
23 disp(V_i_max,'Input microwave voltage(in volts) =');
24 disp(A_v,'Voltage gain =');
25 disp(eff,'Effeciency of amplifier (in percentage) ='
    );
26 disp(R_b,'Beam loading resistance(in kilo ohms) =');
27
28 //Answer in book is wrongly given as: Voltage gain
    =17.034

```

Scilab code Exa 8.6 Calculate the value of repeller voltage and beam current necessary to give gap voltage of 200V.

```
1 //Caption : Calculate ( i )-value of repeller voltage  
    V_r , ( ii )-beam current necessary to give gap  
    voltage of 200V, ( iii )-electronic efficiency  
2 //Exa:8.6  
3 clc;  
4 clear;  
5 close;  
6 e_m_ratio=1.759*10^11; //(e/m)  
7 V_o=500; //in volts  
8 R_sh=20*10^3; //in ohms  
9 f=8*10^9; //inHz  
10 w=2*pi*f;  
11 n=2; //mode  
12 L=0.001; //spacing between repeller & cavity ( in m)  
13 x=0.023;  
14 volt_diff=sqrt(V_o*(x));  
15 V_r=volt_diff+V_o; //repeller volatge  
16 Beeta_o=1; //Assuming  
17 J=0.582;  
18 V_1=200; //given ( in volts )  
19 I_o=V_1/(R_sh*2*J);  
20 Theeta_o=2*pi*f*J*10^6*2*10^-3*sqrt(V_o)  
    /(1.579*10^11*(V_r+V_o));  
21 X=V_1*Theeta_o/(2*V_o); //X'  
22 j=0.84; //J(X')  
23 eff=[2*j/(2*pi*2-pi/2)]*100;  
24 disp(V_r,'Repeller voltage (in volts) =');  
25 disp(I_o,'Necessary beam current (in Amp. s) =');
```

```
26 disp(eff,'Effeciency (in percentage) =');
```

Scilab code Exa 8.7 Calculate the efficiency of reflex klystron and total output power

```
1 //Caption: Calculate (i)-efficiency of reflex  
klystron ,(ii)-total output power in mW, (iii)-  
power delivered to load  
2 //Exa:8.7  
3 clc;  
4 clear;  
5 close;  
6 P_dc_in=40; //in mW  
7 ratio=0.278; //V_1/V_o;  
8 n=1;  
9 X=ratio*(2*n*pi-%pi/2);  
10 J=2.35;  
11 eff=ratio*J*100; //in percentage  
12 P_out= 8.91*P_dc_in/100;  
13 P_load=3.564*80/100;  
14 disp(eff,'Effeciency (in percentage) =');  
15 disp(P_out,'Total power output (in mW) =');  
16 disp(P_load,'Power delivered to load (in mW) =');
```

Scilab code Exa 8.8 Calculate the Hull cutoff voltage and cutoff magnetic flux density

```

1 //Caption : Calculate ( i )-Hull cut-off voltage ,( ii )-
    cut-off magnetic flux density if beam voltage V_o
    is 6000V, ( iii )-cyclotron frequency in GHz
2 //Exa:8.8
3 clc;
4 clear;
5 close;
6 e_m_ratio=1.759*10^11; //(e/m)
7 R_a=0.15; //in m
8 R_o=0.45; //in m
9 B_o=1.2*10^-3; //in weber/m^2
10 V_o={(e_m_ratio)*B_o^2*R_o^2*[1-(R_a/R_o)^2]^2}/8;
11 //Given:
12 V=6000; //in volts
13 B_c=sqrt(8*V/e_m_ratio)/[[1-(R_a/R_o)^2]*(R_o)]; //in
    weber/m^2
14 w_c=(e_m_ratio)*B_o;
15 f_c=w_c/(2*pi); //in Hz
16 disp(V_o,'Cut-off voltage (in volts) =');
17 disp(B_c*10^5,'Cut-off magnetic flux density (in
    milli weber/sq. m) =');
18 disp(f_c*10^-9,'Cyclotron frequency (in GHz) =');
19
20 //Answer in book is wrongly given as: f_c=0.336Hz &
    V_o=50.666 kV

```

Scilab code Exa 8.9 Calculate the Axial phase velocity and Anode voltage at which

```
1 //Caption : Calculate ( i )-Axial phase velocity ,( ii )-
```

Anode voltage at which TWT can be operated for useful gain

```

2 //Exa:8.9
3 clc;
4 clear;
5 close;
6 e_m_ratio=1.759*10^11; //(e/m)
7 c=3*10^8; //in m/s
8 d=0.002; //diameter (in m)
9 pitch=(1/50)/100; //As, 50 turns per cm (in m)
10 circum=%pi*d;
11 v_p=c*pitch/circum;
12 V_o=v_p^2/(2*e_m_ratio);
13 disp(v_p, 'Axial phase velocity (in m/s) =');
14 disp(V_o, 'Anode Voltage (in kV) =');
15
16 //Answer in book is wrongly given as V_o=25.92 V

```

Scilab code Exa 8.10 Calculate the electron velocity and dc transit time and input

```

1 //Caption: Calculate (i)-electron velocity ,( ii )-dc
    transit time , ( iii )-input voltage for maximum
    output voltage ,( iv )-voltage gain in dB
2 //Exa:8.10
3 clc;
4 clear;
5 close;
6 V_o=900; //in volts
7 I_o=30*10^-3; //in A
8 f=8*10^9; //in Hz
9 d=0.001; //in m
10 l=0.04; //in m
11 R_sh=40*10^3; //in ohm

```

```

12 v_o=0.593*10^6*sqrt(v_o);
13 T_o=1/v_o;
14 Theeta_o=(2*pi*f)*T_o; //Transit angles between
    cavities (in radian)
15 Theeta_g=(2*pi*f)*d/v_o; //Average gap transit angle
    (in radian)
16 b=sin(Theeta_g/2)/(Theeta_g/2);
17 V_in_max=v_o*3.68/(b*Theeta_o);
18 //As, {J(X)/X=0.582}
19 A_r=b^2*Theeta_o*0.582*R_sh/(30*10^3*1.841);
20 disp(v_o,'Electron velocity (in m/s) =');
21 disp(T_o,'Dc Transit Time (in sec)=');
22 disp(V_in_max,'Maximum input voltage (in volts) =');
23 disp(A_r,'Voltage gain (in dB) =');

```

Scilab code Exa 8.11 Calculate the dc electron velocity and dc phase constant and

```

1 //Caption: Calculate (i)-dc electron velocity ,( ii)-dc
    phase constant , ( iii)-plasma frequency , ( iv)-
    reduced plasma frequency for R=0.5, (v)-dc beam
    current beam density , ( vi)-instantaneous beam
    current density
2 //Exa:8.11
3 clc;
4 clear;
5 close;
6 V_o=20*10^3; //in volts
7 I_o=2; //in A
8 f=10*10^9; //in Hz
9 p_o=10^-6; //in c/m^3
10 p=10^-8; //in c/m^3

```

```

11 v=10^5; //in m/s
12 R=0.5;
13 v_o=0.593*10^6*sqrt(V_o);
14 k=2*pi*f/v_o;
15 w_p=[1.759*10^11*(10^-6/(8.854*10^-12))]^0.5;
16 w_q=R*w_p;
17 J_o=p_o*v_o;
18 J=p*v_o-p_o*v;
19 disp(v_o,'Dc electron velocity (in m/s) =');
20 disp(k,'Dc phase constant (in rad/s) =');
21 disp(w_p,'Plasma frequency (in rad/s) =');
22 disp(w_q,'Reduced plasma frequency (in rad/s) =');
23 disp(J_o,'Dc beam current density (in A/sq. m) =');
24 disp(J,'Instantaneous beam current density (in A/sq.
m) =');

```

Scilab code Exa 8.12 Calculate the gap transit angle

```

1 //Caption: Calculate the gap transit angle
2 //Exa:8.12
3 clc;
4 clear;
5 close;
6 V_o=1000; //Anode voltage(in volts)
7 gap=0.002; //in m
8 f=5*10^9; //in Hz
9 L=2.463*10^-3; //length of drift region (in m)
10 u_o=5.93*10^5*sqrt(V_o); //in m/s
11 Theeta_g=2*pi*f*2*10^-3/u_o; //radians
12 disp(Theeta_g,'Transit angle(in radians) =');

```

Scilab code Exa 8.13 Calculate the input rf voltage and voltage gain and efficiency

```
1 //Caption : Calculate ( i ) - i/p rf voltage , ( ii ) - voltage  
    gain , ( iii ) - efficiency  
2 //Exa : 8.13  
3 clc;  
4 clear;  
5 close;  
6 V_o=1200; //in volts  
7 I_o=30*10^-3; //in A  
8 f=10*10^9; //in Hz  
9 d=0.001; //in m  
10 l=0.04; //in m  
11 R_sh=40*10^3; //in ohms  
12 v_o=0.593*10^6*sqrt(V_o);  
13 Theeta_o=2*pi*f*l/(20.54*10^6);  
14 X=1.84; //for maximum output power  
15 V_max=2*X*V_o/122.347;  
16 Theeta_g=122.347*10^-3/(4*10^-2);  
17 Beeta_i=sin(Theeta_g/2)/(Theeta_g/2);  
18 V_1_max=V_max/Beeta_i;  
19 J=0.58;  
20 Beeta_o=Beeta_i;  
21 I_2=2*I_o*J;  
22 V_2=Beeta_o*I_2*R_sh;  
23 A_v=V_2/V_1_max; //in dB  
24 eff=0.58*(V_2/V_o)*100; //in percentage  
25 disp(V_1_max, 'Input rf voltage (in volts) =');  
26 disp(A_v, 'Voltage gain (in dB) =');  
27 disp(eff, 'Maximum efficiency (in percentage) =');
```

28
29 // Answer in book is wrongly given as: $A_v=24.33$ dB

Scilab code Exa 8.14 Calculate the cyclotron angular frequency and cutoff voltage

```
1 //Caption: Calculate (i)-cyclotron angular frequency ,  
    (ii)-cut-off voltage , (iii)-cut-off magnetic  
    flux  
2 //Exa:8.14  
3 clc;  
4 clear;  
5 close;  
6 e_m_ratio=1.759*10^11; //(e/m)  
7 a=0.04;  
8 b=0.08;  
9 V_o=30*10^3; //in volts  
10 I_o=80; //in A  
11 B_o=0.01; //in weber/sq.m  
12 w=(e_m_ratio)*B_o;  
13 disp(w, 'Cyclotron angular frequency( in rad/s ) =');  
14 V_c={(e_m_ratio)*B_o^2*b^2*[1-(a/b)^2]^2}/8;  
15 disp(V_c, 'Cut-off voltage (in volts) =');  
16 B_c=sqrt(8*V_o/e_m_ratio)/[[1-(a/b)^2]*(b)]; //in  
    weber/m^2  
17 disp(B_c*10^3, 'Cut-off magnetic flux density (in  
    milli weber/sq . m) =');
```

Scilab code Exa 8.15 Calculate the input power and output power in watts and efficiency

```
1 //Caption: Calculate ( i )-input power ,( ii )-output  
    power in watts , ( iii )-efficiency  
2 //Exa:8.15  
3 clc;  
4 clear;  
5 close;  
6 n=2;  
7 V_o=280; //in volts  
8 I_o=22*10^-3; //in A  
9 V_i=30; //in volts  
10 J=1.25; //J(X')  
11 P_dc=V_o*I_o;  
12 P_ac=2*V_o*I_o*J/(2*n*pi-%pi/2);  
13 eff=(P_ac/P_dc)*100;  
14 disp(P_dc,'Input power ( in watts ) =');  
15 disp(P_ac,'Output power ( in watts ) =');  
16 disp(eff,'Efficiency ( in percent ) =');
```

Scilab code Exa 8.16 Calculate the repeller voltage and beam current necessary to

```
1 //Caption: Calculate ( i )-repeller voltage V_r ,( ii )-  
    beam current necessary to give gap voltage of 200
```

```

      V
2 //Exa:8.16
3 clc;
4 clear;
5 close;
6 e_m_ratio=1.759*10^11; //(e/m)
7 V_o=300; //in volts
8 R_sh=20*10^3; //in ohms
9 f=8*10^9; //inHz
10 w=2*pi*f;
11 n=2; //mode
12 L=0.001; //spacing between repeller & cavity (in m)
13 x=(e_m_ratio)*(2*pi*n-%pi/2)^2/(8*w^2*L^2);
14 volt_diff=sqrt(V_o/(x));
15 V_r=(volt_diff)+V_o; //repeller volatge
16 J=0.582;
17 V_1=200; //given (in volts)
18 I_o=V_1/(R_sh*2*J);
19 disp(V_r, 'Repeller voltage(in volts) =');
20 disp(I_o*10^3, 'Necessary beam current (in milliAmp.s
) =');
```

Chapter 9

Solid State Microwave Devices

Scilab code Exa 9.1 Calculate i repeller voltage Vr ii beam current necessary to g

```
1 //Caption : Calculate operating frequency of IMPATT  
    diode  
2 //Exa:9.1  
3 clc;  
4 clear;  
5 close;  
6 v_d=10^7*10^-2; // drift velocity (in m/s)  
7 L=2*10^-6; // drift length (in m)  
8 f=v_d/(2*L); //in Hz  
9 disp(f/10^9, 'Operating Frequency (in GHz) =' );
```

Scilab code Exa 9.2 Determine threshold electric field

```
1 //Caption : Determine threshold electric field  
2 //Exa:9_2
```

```
3 clc;
4 clear;
5 close;
6 f=10*10^9; //in Hz
7 L=75*10^-6; //Device length (in m)
8 V=25; //Voltage pulse amplified (in volts)
9 E_th=V/L;
10 disp(E_th, 'Threshold Electric field (in kV/cm) =');
```

Scilab code Exa 9.3 Calculate the power gain in dB and power gain if it is USB con

```
1 //Caption: Calculate ( i )-power gain in dB ,( ii )-power
   gain if it is USB converter .
2 //Exa:9.3
3 clc;
4 clear;
5 close;
6 f_s=2*10^9; //in Hz
7 f_p=12*10^9; //in Hz
8 R_i=16;
9 R_s=1000;
10 A_p=10*log((f_p-f_s)/f_s);
11 A_p_usb=10*log((f_p+f_s)/f_s);
12 disp(log(10), 'Power gain (in dB) =');
13 disp(A_p_usb, 'Power gain as USB converter (in dB) =');

```

Scilab code Exa 9.4 Calculate the critical voltage and breakdown voltage and breakdown electric field

```
1 //Caption : Calculate ( i )-critical voltage ,( ii )-
              breakdown voltage , ( iii )-breakdown electric field
2 //Exa:9.4
3 clc;
4 clear;
5 close;
6 E_s=12.5;
7 E_o=8.85*10^-12;
8 E=E_o*E_s;
9 N=3.2*10^22; //per cubic meter
10 L=8*10^-6; //in m
11 q=1.6*10^-19; //in coulombs
12 V_c=q*N*L^2/(2*E);
13 V_bd=2*V_c;
14 E_bd=V_bd/L;
15 disp(V_c/10^3, 'Critical voltage (in kV) =');
16 disp(V_bd/10^3, 'Breakdown Voltage (in kV) =');
17 disp(E_bd, 'Breakdown Electric field (in V/cm) =');
```

Scilab code Exa 9.5 Calculate the power gain in dB and power gain if it is USB con-

```
1 //Caption: Calculate ( i )-power gain in dB ,( ii )-power  
    gain if it is USB converter.  
2 //Exa:9.5  
3 clc;  
4 clear;  
5 close;  
6 N_a=2.5*10^16; //per cubic cm  
7 J=33; //in kA/cm^2  
8 q=1.6*10^-19;  
9 V_z=J/(q*N_a); //Avalanche zone velocity (in cm/s)  
10 disp(V_z, 'Avalanche zone velocity (in cm/s) =');
```

Scilab code Exa 9.6 Calculate the power gain in dB

```
1 //Caption: Calculate the power gain in dB  
2 //Exa:9.6  
3 clc;  
4 clear;  
5 close;  
6 R_neg=25; //in ohm  
7 R_load=50; //in ohm  
8 G=[- abs(R_neg)-R_load]/[- abs(R_neg)+R_load]^2;  
9 disp(G, 'Power gain =');
```

Scilab code Exa 9.7 Calculate the minimum voltage needed to GUNN effect

```
1 //Caption: Calculate the minimum voltage needed to  
    GUNN effect  
2 //Exa:9.7  
3 clc;  
4 clear;  
5 close;  
6 volt_grad=3.3*10^3; //voltage gradient  
7 L=5*10^-4; //in drift length  
8 V_min=volt_grad*L; //in volts  
9 disp(V_min,'Minimum voltage needed (in Volts) =');
```

Scilab code Exa 9.8 Calculate the rational frequency and critical velocity of diod

```
1 //Caption: Calculate the rational frequency &  
    critical velocity of diode.  
2 //Exa:9.8  
3 clc;  
4 clear;  
5 close;  
6 v_d=2*10^7; //in cm/s  
7 L=20*10^-4; //in cm  
8 f=v_d/L;  
9 disp(f*10^-9,'Natural frequency (in GHz) =');  
10 critical_field=3.3*10^3;  
11 V=L*critical_field;  
12 disp(V,'Critical voltage (in volts) =');
```

Scilab code Exa 9.9 Calculate the resonant frequency and efficiency

```
1 //Caption: Calculate the resonant frequency &
   efficiency .
2 //Exa:9.9
3 clc;
4 clear;
5 close;
6 L_p=0.5*10^-9; //in H
7 C_j=0.5*10^-12; //in F
8 V_bd=100; //breakdown voltage (in volts)
9 I_bias=100*10^-3; //bias current(in A)
10 I_rf_peak=0.8;
11 R_l=2;
12 f=1/(2*pi*sqrt(L_p*C_j));
13 eff={(0.5*I_rf_peak^2*R_l)/(V_bd*I_bias)}*100;
14 disp(f*10^-9, 'Resonant frequency (in GHz) =');
15 disp(eff, 'Efficiency (in percentage) =');
```

Scilab code Exa 9.10 Calculate the drift time of carrier and operating frequency of diode

```
1 //Caption: Calculate (i)-drift time of carrier ,(ii)-
   operating frequency of diode
2 //Exa:9.10
3 clc;
4 clear;
```

```
5 close;
6 L=2*10^-6; //drift length (in m)
7 v_d=10^5; //in cm/s
8 drift_time=L/v_d;
9 f=1/(2*drift_time);
10 disp(drift_time,'Drift time (in sec) =');
11 disp(f*10^-9,'Operating Frequency (in GHz)=');
```

Scilab code Exa 9.11 Calculate the breakdown voltage and breakdown electric field

```
1 //Caption : Calculate ( i )-breakdown voltage ,( ii )-
              breakdown electric field .
2 //Exa:9.11
3 clc;
4 clear;
5 close;
6 E_r=11.8;
7 E_o=8.85*10^-12;
8 N=3*10^21; //in per cubic meter
9 L=6.2*10^-6; //in meter
10 q=1.6*10^-19; //in coulombs
11 V_bd=q*N*L^2/(E_o*E_r);
12 E_bd=V_bd/L;
13 disp(V_bd,'Breakdown voltage (in volts) =');
14 disp(E_bd,'Breakdown electric field (in V/m) =');
```

Scilab code Exa 9.12 Calculate the maximum power gain and noise figure and bandwidth

```
1 //Caption: Calculate ( i )-maximum power gain in dBs  
    ,( ii )-noise figure F in dBs, ( iii )-bandwidth for  
    r=0.2  
2 //Exa:9.12  
3 clc;  
4 clear;  
5 close;  
6 ratio=8;  
7 r=0.2;  
8 r_Q=8;  
9 T_d=300; //in Kelvin  
10 T_o=300; //in Kelvin  
11 X=8;  
12 G=(ratio)*X/(1+sqrt(1+X))^2;  
13 G_in_dB=(10*log(G))/log(10); //gain  
14 disp(G_in_dB, 'Maximum Gain (in dB)=');  
15 F=[10*log(1+(2*T_d/T_o)*[(1/(r_Q))+(1/(r_Q)^2)])]/  
    log(10); //noise figure  
16 disp(F, 'Noise figure (in dB) =');  
17 B_W=2*r*sqrt(ratio); //bandwidth  
18 disp(B_W, 'bandwidth =');
```

Scilab code Exa 9.13 Calculate the equivalent noise resistance and gain and noise

```
1 //Caption : Calculate ( i )-equivalent noise resistance ,  
    ( ii )-gain , ( iii )-noise figure , ( iv )-bandwidth  
2 //Exa:9.13  
3 clc;  
4 clear;  
5 close;  
6 f_s=2*10^9; //in Hz  
7 f_p=12*10^9; //in Hz  
8 f_i=10*10^9; //in Hz  
9 f_d=5*10^9; //in Hz  
10 R_i=1*10^3; //in ohm  
11 R_g=1*10^3; //in ohm  
12 R_T_s=1*10^3; //in ohm  
13 R_T_i=1*10^3; //in ohm  
14 T_d=300; //in Kelvin  
15 T_o=300; //in Kelvin  
16 w_s=2*%pi*f_s;  
17 w_i=2*%pi*f_i;  
18 r=0.35;  
19 r_Q=10;  
20 r_d=300; //in ohm  
21 C=0.01*10^-12; //in Farad  
22 R=r^2/(w_s*w_i*C^2*R_T_i);  
23 a=R/R_T_s;  
24 g=((4*f_i*R_g*R_i*a)/(f_s*R_T_s*R_T_i*(1-a)^2)); //  
     gain  
25 Gain=[10*log(g)]/log(10); //gain in dB  
26 f={1+((2*T_d)/T_o)*[(1/r_Q)+(1/r_Q^2)]}; //noise  
     figure  
27 F=[10*log(f)]/log(10); //noise figure in dB  
28 B_W=(r/2)*sqrt(f_d/(f_s*Gain)); //bandwidth  
29 disp(a, 'Equivalent noise resistance ( in ohm ) =');  
30 disp(Gain, 'Gain ( in dB ) =');  
31 disp(F, 'Noise figure ( in dB ) =');  
32 disp(B_W, 'Bandwidth =');
```
