

Scilab Textbook Companion for
Electrical Machines 3rd Edition
by S. K. Bhattacharya¹

Created by
Devavarapu Hemanth Kumar
B TECH
Electrical Engineering
NIT Durgapur
College Teacher
Dr. Sankar Narayan Mahato
Cross-Checked by

July 31, 2019

¹Funded by a grant from the National Mission on Education through ICT,
<http://spoken-tutorial.org/NMEICT-Intro>. This Textbook Companion and Scilab
codes written in it can be downloaded from the "Textbook Companion Project"
section at the website <http://scilab.in>

Book Description

Title: Electrical Machines 3rd Edition

Author: S. K. Bhattacharya

Publisher: Tata McGraw - Hill Education, New Delhi

Edition: 3

Year: 2009

ISBN: 9780070669215

Scilab numbering policy used in this document and the relation to the above book.

Exa Example (Solved example)

Eqn Equation (Particular equation of the above book)

AP Appendix to Example(Scilab Code that is an Appednix to a particular Example of the above book)

For example, Exa 3.51 means solved example 3.51 of this book. Sec 2.3 means a scilab code whose theory is explained in Section 2.3 of the book.

Contents

List of Scilab Codes	4
2 Direct Current Machines	5
3 Transformers	32
4 Three Phase Induction Machines	61
5 Three Phase Synchronous Machines	92

List of Scilab Codes

Exa 2.4	Calculating average induced emf	5
Exa 2.5	Calculating useful flux per pole	6
Exa 2.6	Calculating emf generated on open circuit condition	6
Exa 2.7	calculate induced emf	7
Exa 2.8	calculating the speed and percentage increase in flux	8
Exa 2.9	Calculating electromagnetic torque	8
Exa 2.10	calculating the torque developed	9
Exa 2.11	calculating various parameters of dc motor .	10
Exa 2.12	calculating various parameters of dc machine	11
Exa 2.13	calculating speed of machine	11
Exa 2.14	calculating speed ratio of generator and motor working conditios	12
Exa 2.15	calculating flux and area of pole shoe and no load terminal voltage	13
Exa 2.16	calculate approximate time of commutation	14
Exa 2.17	calculate resistance	15
Exa 2.18	calculating resistance required in series . .	16
Exa 2.19	calculating resistance required in series and also the speedwhen torque is halved	17
Exa 2.20	calculating the speed of the motor	18
Exa 2.21	Calculate the fullyload speed of the motor .	19
Exa 2.22	Calculate the value of resistance	19
Exa 2.23	Calculate the speed	20
Exa 2.24	Calculate the fullyload speed of the motor .	21
Exa 2.25	Calculate the ampere turns for each commutating pole	22

Exa 2.26	Estimating the number of turns needed on each commutating pole	23
Exa 2.27	Calculating the efficiency of motor	24
Exa 2.29	Calculate the efficiency of machine when running as generator and motor	25
Exa 2.30	Calculating the efficiency of the generator at full load and at half load	26
Exa 2.31	Calculate the efficiency of machine	27
Exa 2.32	Calculate the appox efficiency of each machine	28
Exa 2.33	Calculate the appox efficiency of each machine	29
Exa 2.34	Calculate the efficiencies of the generator at full load	30
Exa 3.1	calculating number of turns and primary and secondary currents and value of flux	32
Exa 3.2	calculating number of primary and secondary turns	33
Exa 3.3	calculating induced emf and maximum flux density	34
Exa 3.4	calculating induced emf and maximum flux density	34
Exa 3.5	Calculating the current and power factor of the primary circuit	35
Exa 3.6	Calculating the value of primary current	36
Exa 3.7	Calculating the magnetising current and core loss and flux	37
Exa 3.8	Calculating the current and power factor of the primary circuit	38
Exa 3.9	Calculating magnetising current and primary current and primary power factor	39
Exa 3.10	Calculating primary current and primary power factor	40
Exa 3.11	Calculating equivalent impedance referred to primary	41
Exa 3.12	Calculating equivalent impedance referred to primary	42
Exa 3.13	Calculate current and power input	43
Exa 3.14	Calculate current and power input	44
Exa 3.15	Calculate percentage regulation	45

Exa 3.16	Calculating secondary voltage and voltage regulation	45
Exa 3.17	Calculating regulation	47
Exa 3.19	Calculating the efficiency and voltage regulation	47
Exa 3.20	Calculate voltage to be applied	48
Exa 3.21	Calculate circuit constants and efficiency . .	49
Exa 3.22	Calculate efficiency	51
Exa 3.24	Calculate efficiency of transformer	52
Exa 3.25	Calculate efficiency of transformer	53
Exa 3.26	Calculate efficiency of transformer	54
Exa 3.27	Calculate efficiency of transformer	55
Exa 3.28	Calculate current in different parts of winding of autotransformer	56
Exa 3.29	Calculate efficiency of transformer	57
Exa 3.30	Calculate efficiency of transformer	58
Exa 3.32	Calculate current in different parts of winding of autotransformer	59
Exa 4.1	to calculate synchronous speed and speed of rotor for slip condition	61
Exa 4.2	to find out rotor running at higher slip . . .	62
Exa 4.3	calculating slip and number of poles	63
Exa 4.4	Calculate frequency of rotor induced emf . .	64
Exa 4.5	Calculating the speed of running motor and its slip	64
Exa 4.6	Calculating the speed of rotating magnetic field	65
Exa 4.7	Calculate rotor current and phase difference .	66
Exa 4.8	Calculating the running speed and frequency of the rotor magnet current	67
Exa 4.9	Calculating the running speed and frequency of the rotor magnet current	67
Exa 4.10	Calculating the frequency of the rotor current .	68
Exa 4.11	Calculating the rotor current	69
Exa 4.12	Calculate power developed and efficiency . .	70
Exa 4.13	Calculating the rotor loss and rotor speed . .	70
Exa 4.14	Calculating standstill rotor reactance	71
Exa 4.15	Calculating new full load speed	72

Exa 4.16	Calculating starting torque	73
Exa 4.18	Calculating external resistance	74
Exa 4.20	Calculating full load rotor loss and rotor input and output torque	75
Exa 4.21	Calculating the slip and rotor copper loss and the output horse power and efficiency	75
Exa 2.22	Calculate the value of resistance	76
Exa 4.22	Calculating the slip and rotor speed and mechanical power developed and rotor copper loss per phase and resistance per phase	77
Exa 4.23	Calculating additional resistance required	78
Exa 4.24	Calculate speed of motor and maximum torque	79
Exa 4.25	Calculate starting current	80
Exa 4.26	Calculate starting line current and starting torque	81
Exa 4.28	Calculate starting torque	82
Exa 4.29	Calculate full load speed	83
Exa 4.30	Calculate full load rotor loss and rotor input and output torque	84
Exa 4.31	Calculate full load rotor loss and rotor input and output torque	85
Exa 4.32	Calculate full load efficiency	86
Exa 4.33	Calculating the rotor current at slip 3 percent and when the rotor develops maximum torque	87
Exa 4.34	Calculating the rotor current at slip 3 percent and when the rotor develops maximum torque	88
Exa 4.35	Calculate the circuit elements	89
Exa 5.1	To calculate distribution factor	92
Exa 5.2	To calculate distribution factor	93
Exa 5.3	To calculate pitch factor	93
Exa 5.4	To calculate the rms value of induced EMF	94
Exa 5.5	Calculating useful flux per pole	95
Exa 5.6	To calculate the frequency and induced EMF	96
Exa 5.7	Finding the number of armature conductors	97
Exa 5.8	To calculate induced EMF per phase	98
Exa 5.9	To find the voltage regulation	99
Exa 5.10	To calculate voltage regulation	100
Exa 5.11	To calculate internal voltage drop	101

Exa 5.12	To calculate percentage change in terminal voltage	102
Exa 5.13	To calculate regulation on full load power factor loading and lagging condition	103
Exa 5.14	To calculate terminal voltage for same excitation and load current at certain power factor leading	104
Exa 5.15	to find the power factor of alternator B	105
Exa 5.16	To calculate armature current and power factor	106
Exa 5.17	To determine KVA rating and power factor	107

Chapter 2

Direct Current Machines

Scilab code Exa 2.4 Calculating average induced emf

```
1 // Calculating average induced emf
2 // Chapter 2
3 // Example 2.4
4 // page 92
5 clear;
6 clc;
7 disp("example 2.4")
8 P=2           // number of poles
9 Z=400         // number of conductors
10 n=300        // speed in rpm
11 E=200        // voltage of generator
12 A=2          // number of parallel paths
13 N=1200       // number of turns in each field coil
14 phi=(E*60*A)/(Z*n*P)    // flux at the end of 0.15 sec
15 t=0.15        // time
16 printf("magnitude of flux at the end of 15sec is %f
      wb",phi)
17 e=N*(phi/t)
18 printf("\ninduced emf in the field coil= %d volts",e
      )
```

Scilab code Exa 2.5 Calculating useful flux per pole

```
1 // Calculating the current and power factor of the
   primary circuit
2 //Chapter 3
3 //Example 3.5
4 //page 206
5 clear;
6 clc;
7 disp("Example 3.5")
8 I2=300;.....//Secondary current
   in amperes
9 N1=1200;           //number of primary
   turns
10 N2=300;          //number of
   secondary turns
11 I0=2.5;           //load current in
   amperes
12 I1=(I2*N2)/N1;
13 phi0=acosd(0.2);
14 phi2=acosd(0.8);
15 I1c=(I1*cosd(phi2))+(I0*cosd(phi0));
16 I1s=(I1*sind(phi2))+(I0*sind(phi0));
17 I=sqrt(I1c^2+I1s^2);
18 phi=atand(I1s/I1c)
19 printf("primary power factor=%fdegrees",cosd(phi));
```

Scilab code Exa 2.6 Calculating emf generated on open circuit condition

```

1 //Calculating emf generated onopen circuit condition
2 //Chapter 2
3 //Example 2.6
4 //page 93
5 clear;
6 clc;
7 disp("example 2.5")
8 P=8           //number of poles
9 A=8           //number of parallel paths in the
               armature
10 Z=960          //number of conductors
11 N=400          //speed in rpm
12 phi=0.04        //flux per pole
13 E=(phi*Z*N*P)/(60*A)      //emf generated onopen
               circuit condition
14 printf("emf generated on open circuit condition , E=
               %d volts",E)

```

Scilab code Exa 2.7 calculate induced emf

```

1 //calculate induced emf
2 //Chapter 2
3 //Example 2.7
4 //page 97
5 clear;
6 clc;
7 disp("example 2.7")
8 disp("flux is constant")
9
10 E=180;.....//induced emf at 500rpm
11 N=500;.....//speed in rpm
12 K1=(E/N)
13 printf("K1=%f",K1)

```

```
14 E1=(K1*600)           //induced emf at 600rpm
15 printf("\n induced emf at 600rpm is=%d V",E1)
```

Scilab code Exa 2.8 calculating the speed and percentage increase in flux

```
1 // calculating the speed and percentage increase in
   flux
2 //Chapter 2
3 //Example 2.8
4 //page 97
5 clear;
6 clc;
7 disp("example 2.8")
8 disp("assuming constant flux")
9 E1=220;           //induced emf at N1 speed in volts
10 N1=750;          // speed
11 K1=(E1/N1)
12 E2=250;          //induced emf at speed N2
13 N2=E2/K1
14 printf("speed at induced emf of 250V =%d rpm",N2)
15 disp("when induced emf is 250V and speed 700 rpm")
16 E3=250;          //induced emf at N3 speed
17 N3=700;          //speed
18 ratio=(E3*N1)/(E1*N3)
19 Pi=(ratio-1)*100
20 printf("percentage increase in flux is %f percent",
Pi)
```

Scilab code Exa 2.9 Calculating electromagnetic torque

```

1 //Calculating electromagnetic torque
2 //Chapter 2
3 //Example 2.9
4 //page 98
5 clear;
6 clc;
7 disp("example 2.9")
8 E=200           //emf induced
9 I=15            //armature current
10 n=1200          //speed in rpm
11 omega=(2*3.14*n)/60;
12 printf("omega=%f \n",omega)
13 T=(E*I)/omega;
14 printf("electromagnetic torque=%f Nm",T)

```

Scilab code Exa 2.10 calculating the torque developed

```

1 //calculating the torque developed
2 //Chapter 2
3 //Example 2.10
4 //page 98
5 clear;
6 clc;
7 disp("Example 2.10")
8 n=10;           //number of turns in 1 coil
9 l=0.2;
10 d=0.2;          //diameter in metres
11 B=1;            //uniform magnetic field density
                  //in weber per m^2
12 N=1500;         //speed in rpm
13 r=(d/2);        //radius in metres
14 E=(B*l*((2*3.14*N)/60)*r*2*n);
15 printf("total induced emf=%f V",E)

```

```

16 R=4;           //total resistance in ohms
17 I=E/R;
18 printf("\nThe current through the armature coil when
         connected to the load ,I=%f A" ,I)
19 T=(E*I)/((2*3.14*N)/60)
20 printf("\ntorque=%f Nm" ,T)

```

Scilab code Exa 2.11 calculating various parameters of dc motor

```

1 //calculating various parameters of dc motor
2 //Chapter 2
3 //Example 2.11
4 //page 99
5 clear;
6 clc;
7 disp("Example 2.11")
8 V=230;           //armature voltage supply in volts
9 Ia=12;           //armature current in amperes
10 Ra=0.8;          //armature resistance in ohms
11 N=100;           //speed in radian per second
12 E=(V-(Ia*Ra))
13 printf("induced emf,E=%fV" ,E)
14 Te=(E*Ia)/N
15 printf("\nthe electromagnetic torque=%fNm" ,Te)
16 Pi=V*Ia
17 printf("\nelectrical input to the armature ,Pinput=
         %dW" ,Pi)
18 Pd=Te*N
19 printf("\nmechanical developed=%fW" ,Pd)
20 loss=(Ia^2*Ra)
21 printf("\narmature copper loss=%fW" ,loss)

```

Scilab code Exa 2.12 calculating various parameters of dc machine

```
1 //calculating various parameters of dc motor
2 //Chapter 2
3 //Example 2.11
4 //page 99
5 clear;
6 clc;
7 disp("Example 2.11")
8 V=230;           //armature voltage supply in volts
9 Ia=12;           //armature current in amperes
10 Ra=0.8;         //armature resistance in ohms
11 N=100;          //speed in radian per second
12 E=(V-(Ia*Ra))
13 printf(" induced emf ,E=%fV" ,E)
14 Te=(E*Ia)/N
15 printf("\nthe electromagnetic torque=%fNm" ,Te)
16 Pi=V*Ia
17 printf("\nelectrical input to the armature ,Pinput=%dW" ,Pi)
18 Pd=Te*N
19 printf("\nmechanical developed=%fW" ,Pd)
20 loss=(Ia^2*Ra)
21 printf("\narmature copper loss=%fW" ,loss)
```

Scilab code Exa 2.13 calculating speed of machine

```
1 //calculating speed of machine
```

```

2 //Chapter 2
3 //Example 2.13
4 //page 101
5 clear;
6 clc;
7 disp(" Example 2.13")
8 disp("At generator condition")
9 P=50000;           //power delivered in watts
10 V=250;            //voltage in volts
11 Ra=0.02;          //armature resistance in ohms
12 Rf=50;            //field resistance in ohms
13 If=V/Rf;          //field current in amperes
14 Ng=400;           //speed in generating condition
                     in rpm
15 printf(" field current , If=%dA" , If)
16 I1=P/V            //load current in amperes
17 printf("\nLoad current , If=%dA" , I1)
18 Ia=If+I1           //armature current in amperes
19 printf("\nAramture current , If=%dA\n" , Ia)
20 Eg=(V+(Ia*Ra))
21 disp("At motor condition")
22 Ia=(I1-If)
23 printf("Aramture current , If=%dA" , Ia)
24 Em=(V-(Ia*Ra))
25 printf("\nEm=%fV" , Em)
26 Nm=(Ng*Em)/Eg
27 printf("\nSpeed of the motor=%drpm" , Nm)

```

Scilab code Exa 2.14 calculating speed ratio of generator and motor working condit

```

1 //calculating speed ratio of generator and motor
   working conditios
2 //Chapter 2

```

```

3 //Example 2.14
4 //page 101
5 clear;
6 clc;
7 disp("Example 2.14")
8 V=250;           // voltage supply in volts
9 Ra=0.12;         //armature resistance in ohms
10 Rf=100;          //field resistance in ohms
11 Il=80;           //load current in amperes
12 If=V/Rf
13 printf("Field current , If=%f" ,If)
14 disp("When machine is generating")
15 Ia=Il+If
16 Eg=(V+(Ia*Ra))
17 printf("\nIa=%fA" ,Ia)
18 printf("\nEg=%fV" ,Eg)
19 disp("When machine is motoring")
20 Ia=Il-If
21 Em=(V-(Ia*Ra))
22 printf("\nIa=%fA" ,Ia)
23 printf("\nEm=%fV" ,Em)
24 ratio=Eg/Em
25 printf("\nRatio of speeds=%f" ,ratio)

```

Scilab code Exa 2.15 calculating flux and area of pole shoe and no load terminal v

```

1 // calculating flux , area of pole shoe and no-load
      terminal voltage
2 //Chapter 2
3 //Example 2.15
4 //page 102
5 clear;
6 clc;

```

```

7 disp("Example 2.15")
8 V=550;           //voltage supply in volts
9 P=16;            //number of poles
10 N=150;           //speed in rpm
11 Z=2500;          //number of armature conductors
12 A=16;
13 Power=1500000;    //power in watt
14 C1=25000;         //full-load copper loss
15 B=0.9;            //flux density in the pole
16 Ia=Power/V
17 printf("Full load current=%fA",Ia)
18 Ra=C1/(Ia^2)
19 printf("\nRa=%fohms",Ra)
20 E=V+(Ia*Ra)
21 printf("\nInduced emf=%fvolts",E)
22 phi=(E*60*A)/(Z*N*P)
23 printf("\nflux density=%fWb/m^2",B)
24 printf("\nflux=%fWb",phi)
25 area=(phi/B)
26 printf("\n Area of pole shoe=%fcm^2", (area*10000))

```

Scilab code Exa 2.16 calculate approximate time of commutation

```

1 //calculate approximate time of commutation
2 //Chapter 2
3 //Example 2.16
4 //page 103
5 clear;
6 clc;
7 disp("Example 2.16")
8 Cd=0.76;           //commutator diameter in metres
9 Cr=.38;             //commutator radius in metres
10 bw=1.5*10^(-2);      //brush width in metres

```

```

11 N=600;           // speed in rpm
12 n=10;           // speed in rps
13 V=Cr*(2*3.14*n);
14 printf("peripheral speed of commutator ,V=%fm/sec",V)
   ;
15 Tc=bw/V;
16 printf("\nTime of commutation=%fseconds",Tc)

```

Scilab code Exa 2.17 calculate resistance

```

1 // calculate resistance
2 //Chapter
3 //Example 2.17
4 //page 123
5 clear;
6 clc;
7 disp("Example 2.17")
8 V=240;           // supply voltage in volts
9 N=800;           // speed in rpm
10 Ia=2;           // armature current in amperes
11 Ra=0.4;         // armature resistance in ohms
12 Rf=160;         // field resistance in ohms
13 I11=30;         // line current in amperes
14 E=V-(Ia*Ra);   // induced emf in volts
15 disp("At no-load")
16 printf("E=%fV",E)
17 If=V/Rf;        // field current in amperes
18 printf("\nIf=%fA",If)
19 K1=E/(If*N);
20 printf("\nK1=%f",K1)
21 disp("At a load of 30A")
22 Ia1=(I11-If);
23 E1=V-(Ia1*Ra);

```

```

24 N1=950;           // speed in rpm
25 If1=E1/(K1*N1);
26 printf("If1=%fA\n", If1);
27 Rr=V/If1;
28 R=(Rr-Rf);
29 printf("\nExtra resistance required in the field
circuit ,R=%f ohms", R)

```

Scilab code Exa 2.18 calculating resistance required in series

```

1 // calculating resistance required in series
2 //Chapter 2
3 //Example 2.18
4 //page 124
5 clear;
6 clc;
7 disp("Example 2.18")
8 V=230;           // voltage supply in volts
9 Ia=20;           // armature current in
                  amperes
10 Ra=0.5;          // armature resistance in
                  ohms
11 E=V-(Ia*Ra);
12 printf("E=%dV", E)
13 disp("when extra resistance is added in the armature
circuit ,the speed is halved")
14 E2=E/2;
15 R=((V-E2)/Ia)-Ra;
16 disp("The load torque is constant")
17 printf("extra resistance in the armature circuit ,R=
%f ohms", R)
18 disp("The load torque directly proportional to
square of speed")

```

```

19 disp(" if N is halved , Ia is one-fourthed")
20 Ia2=Ia/4;
21 R=((V-E2)/Ia2)-Ra;
22 printf(" extra resistance in the armature circuit,R=
%fohms" ,R)

```

Scilab code Exa 2.19 calculating resistance required in series and also the speedw

```

1 // calculating resistance required in series and also
   the speed when torque is halved
2 // Chapter 2
3 // Example 2.19
4 // page 125
5 clear;
6 clc;
7 disp(" Example 2.19")
8 V=250;                      // voltage supply in volts
9 Ia=50;                       // armature current in
   amperes
10 Ra=0.3;                     // armature resistance in
   ohms
11 N=1000;
12 E=V-(Ia*Ra);
13 printf("E=%dV" ,E)
14 disp(" when extra resistance is added in the armature
   circuit when the speed is 800rpm")
15 N2=800;
16 E2=(E*N2)/N;
17 printf("\nE at 800rpm=%dV" ,E2)
18 R=((V-E2)/Ia)-Ra;
19 printf("\nextra resistance in the armature circuit,R=
%fohms" ,R)
20 disp(" if load is halved , Ia will be halved")

```

```
21 Ia2=Ia/2;
22 E1=V-(Ia2*(Ra+R));
23 printf("E1=%dV",E1)
24 N1=(N2*E1)/E2;
25 printf("\nN1=%frpm",N1)
```

Scilab code Exa 2.20 calculating the speed of the motor

```
1 //calculating the speed of the motor
2 //Chapter 2
3 //Example 2.20
4 //page 125
5 clear;
6 clc;
7 disp("Example 2.20")
8 I1=5;           //current in amperes at no-load
9 V=250;          //voltage in volts
10 Rf=250;         //field resistance in ohms
11 If1=V/Rf;       //field current in amperes
12 Ia1=I1-If1;     //armature current
13 Ra=0.2;          //armature resistance in
                  //ohms
14 disp("at a load current of 50A")
15 I12=50;          //load current in amperes
16 //armature reaction weakens by 3percent
17 If2=0.97;        //current in amperes
18 Ia2=I12-If2;
19 N1=1000;
20 E1=(V-(Ia1*Ra));
21 E2=(V-(Ia2*Ra));
22 N2=(N1*E2)/(0.97*E1);
23 printf("N2=%frpm",N2)
```

Scilab code Exa 2.21 Calculate the fullyload speed of the motor

```
1 //Calculate the fully-load speed of the motor
2 //Chapter 2
3 //Example 2.21
4 //page 126
5 clear;
6 clc;
7 disp("Example 2.21")
8 P=4; ..... //pole
9 V=500; ..... //shunt motor in volts
10 Ia=60; ..... //armature current in
    amperes
11 Ra=0.2; ..... //armature
    resistance in ohms
12 E=V-(Ia*Ra)-2;
13 printf("voltage drop across each brush=%fV",E)
14 phi=0.03; ..... //flux per
    pole in Wb
15 Z=720; ..... //total
    armature current in volts
16 A=2;
17 N=(E*60*A)/(phi*Z*P)
18 printf("\nfull load speed of the motor=%frpm",N)
```

Scilab code Exa 2.22 Calculate the value of resistance

```
1 //Calculate the value of resistance
```

```

2 //Chapter 2
3 //Example 2.22
4 //page 126
5 clear;
6 clc;
7 disp(" Example 2.22")
8 V=440;           //primary voltage in volts
9 Ia=50;           //armature current in amperes
10 Ra=0.2;          //armature resistance in ohms
11 N=600;           //speed in rpm
12 E=V-(Ia*Ra);    //emf induced in volts
13 %E=K*phi*N=K1*Ia*N
14 K1=E/(Ia*N);
15 //we have the relation T=Kt1*Ia^2, T1=Kt1*Ia1^2
16 //when torque is half, say torque be T1
17 //T1=T/2. r=T/T1
18 r=2;
19 Ia1=sqrt(Ia^2/r);
20 printf(" Ia1=%fA",Ia1);
21 //extra resistance R is introduced in the circuit
22 N1=400;
23 E1=(K1*Ia1*N1);
24 R=((V-E1)/Ia1)-Ra;
25 printf("\nvalue of extra resistance added=%fohms",R)

```

Scilab code Exa 2.23 Calculate the speed

```

1 //Calculate the speed
2 //Chapter 2
3 //Example 2.23
4 //page 127
5 clear;

```

```

6 clc;
7 disp(" Example 2.23")
8 V=200; //voltage in volts
9 Ia=20; //armature current in
          amperes
10 Ra=0.5; //armature resistance
            in ohms
11 Rse=0.2; //field winding
            resistance in ohms
12 E=V-(Ia*(Ra+Rse));
13 printf("In first case ,E=%fV",E)
14 //E=k*phi*N
15 N=1000; //speed in rpm
16 Kphi=E/N;
17 //a resistance R is connected in parallel with the
      series field which is called diverter
18 disp("when resistace R is added and new conditions")
19 I=20; //total current flowing
20 //current is equally devided between series field
      and diverter
21 Isel2=I/2;
22 //flux at 10A current is 20 percent of flux at 20A
      current
23 p=0.70; //percentage of flux
24 Kphi1=p*Kphi;
25 E1=(V-((Ia*Ra)+(Isel2*Rse)));
26 printf("Induced emf=%fV",E1)
27 //new speed is N1
28 N1=E1/(p*Kphi)
29 printf("\nN1=%frpm",N1)

```

Scilab code Exa 2.24 Calculate the fullyload speed of the motor

```

1 //Calculate the fully-load speed of the motor
2 //Chapter 2
3 //Example 2.24
4 //page 128
5 clear;
6 clc;
7 disp("Example 2.24")
8 V=200;.....//motor runs in
    volts
9 Ia=15;.....//current taken
    in amperes
10 Ra=1;.....//motor
    resistance in ohms
11 E1=V-(Ia*Ra);
12 printf("resistance when 1ohm=%fV",E1)
13 R=5;.....//resistance
14 E2=V-(Ia*(Ra+R))
15 printf("\nResistance when 5ohms connected in series=%fV",E2)
16 N1=800;.....//speed of motor
    in rpm
17 N2=N1*(E2/E1);
18 printf("\nspeed at which motor will run when
    resistance is 5ohms=%frpm",N2)

```

Scilab code Exa 2.25 Calculate the ampere turns for each commutating pole

```

1 //Calculate the ampere turns for each commutating
    pole
2 //Chapter 2
3 //Example 2.25
4 //page 135
5 clear;

```

```

6 clc;
7 disp("Example 2.25")
8 P=8; ..... //pole
9 Z=107;.....//generator with
   slots
10 Ia=1000;.....//current containing in
    amperes
11 Bag=0.32;.....//gap flux density in
    Wb/m^2
12 lg=0.012;.....//interpole air
    gap in meters
13 pi=3.14;
14 Mu=(4*pi*10^-7)
15 AT(((Ia*Z)/(2*P))+((Bag*lg)/Mu));
16 printf("current for each commutating pole=%f",AT)

```

Scilab code Exa 2.26 Estimating the number of turns needed on each commutating pole

```

1 //Estimating the number of turns needed on each
   commutating pole
2 //Chapter 2
3 //Example 2.26
4 //page 135
5 clear;
6 clc;
7 disp("Example 2.26")
8 Bag=0.3;.....//flux
   density in the interpole air gap in Wb/m^2
9 Ia=200000/200;.....//armature
   current in amperes
10 printf("Armature current=%f",Ia)
11 Z=540;.....//Number of armature
   conductors

```

```

12 Zt=540/2;..... //Number
    armature winding turns
13 printf("\nNumber armature winding turns=%f",Zt)
14 A=6;..... //the winding lap
15 Ap=Zt/A;..... //Number of armature
    turns per parallel path
16 printf("\nNumber of armature turns per parallel path
    =%f",Ap)
17 P=6;..... //pole
18 Np=((Ia*Ap)/P);
19 printf("\nNumber of armature ampere turns per pole=
    %f",Np)
20 lg=0.01;..... //inter pole
    air gap in meters
21 pi=3.14;
22 Mu=(4*pi*10^-7)
23 Nipg=((Bag*lg)/Mu);..... //Air
    gap
24 printf("\nampere turns for the air gap=%f",Nipg)
25 NipI=(Np+Nipg);..... ////
    total interpole ampere
26 printf("\nTotal interpole ampere turns=%f",NipI)
27 Nip=(NipI/Ia);
28 printf("\nNumber of turns needed on each commutating
    pole=%f",Nip)

```

Scilab code Exa 2.27 Calculating the efficiency of motor

```

1 //Calculating the efficiency of motor
2 //Chapter 2
3 //Example 2.27
4 //page 128
5 clear;

```

```

6 clc;
7 disp(" Example 2.27")
8 N=960; ..... // speed in rpm
9 F=23; ..... // effictive load in
   kgf
10 r=45/2; ..... // radius of
   the drum
11 printf(" radius of the drum=%fcm" ,r)
12 pi=3.14;
13 OP=(2*pi*N*F*r*9.81)/(60*100);
14 printf("\noutput power=%fW" ,OP)
15 Vi=230; ..... //motor input in volts
16 Ci=28; ..... //input current in
   amperes
17 IP=(Vi*Ci);
18 printf("\ninput power =%fW" ,IP)
19 Effi=(OP/IP)*100;
20 printf("\nEfficiency of the motor=%fpercent" ,Effi)

```

Scilab code Exa 2.29 Calculate the efficiency of machine when running as generator

```

1 //Calculate the efficiency of machine when running
   as generator and motor
2 //Chapter 2
3 //Example 2.29
4 //page 145
5 clear;
6 clc;
7 disp(" Example 2.29")
8 I=440; ..... //input at no-load in
   watt
9 V=220; ..... //voltage in volts
10 Ic=I/V; ..... //input current at no-

```

```

        load in amperes
11 i=1; ..... //input current in amperes
12 A=2; ..... //current in amperes
13 C=A-i;..... //armature current at no-
    load in amperes
14 L=I-(((C)^2)*0.5)+(V*C));..... //iron ,
    friction and windage losses in watt
15 a=40;..... //motor current in amperes
16 OP=(V*a);
17 Ra=0.5;
18 Effi=(OP*100)/(OP+((a+i)^2)*Ra)+(V*i)+L)
19 printf("Efficiency as a generator when delivering 40
    A at 220V=%fpercent",Effi)
20 Eff=((OP-((a-i)^2)*Ra)-(V*C)-L)/OP)*100;
21 printf("\nEfficiency as a motor when taking 40A from
    at 220V=%fpercent",Eff)

```

Scilab code Exa 2.30 Calculating the efficiency of the generator at full load and

```

1 //Calculating the efficiency of the generator at
    full load and at half load
2 //Chapter 2
3 //Example 2.30
4 //page 147
5 clear;
6 clc;
7 disp("Example 2.30")
8 V=400;..... //motor in volts
9 Rf=200;..... //field
    resistance in ohms
10 If=V/Rf;..... //current in
    amperes
11 i=5;..... //current at no

```

```

        load in amperes
12 IP=V*i;..... //motor input at
      no load
13 Ia=3;..... //aramture
      current in amperes
14 Ra=0.5;..... //armature
      resistance in ohms
15 L=IP-(((Ia)^2)*Ra)-(V*If);..... ////
      iron , friction and windage in losses in watt
16 printf("iron , friction and windage in losses=%fW",L)
17 At=50;..... ..////
      armature total current in amperes
18 A=At-2;..... ....////
      armature current in amperes
19 Ls=((A)^2)*Ra)+(V*If)+L;..... ////
      Losses
20 Eff=(((V*At)-Ls)/(V*At))*100;
21 printf("\nEfficiency of full load=%fpercent",Eff)
22 // flux is constant
23 E1=V-(Ia*Ra);..... //induced
      emf in the armature at no load
24 E2=V-(A*Ra);..... //induced
      emf in the armature at full load
25 // since N1/N2=E1/E2
26 percentload=(1-(E2/E1))*100;
27 printf("\nPercentage change in speed from no load to
      full load=%fpercent",percentload)

```

Scilab code Exa 2.31 Calculate the efficiency of machine

```

1 //Calculate the efficiency of machine
2 //Chapter 2
3 //Example 2.31

```

```

4 //page 148
5 clear;
6 clc;
7 disp("Example 2.31")
8 Ra=0.5; ..... //armature resistance in
      ohms
9 Rf=750; ..... //field circuit resistance in
      ohms
10 V=500; ..... //voltage in volts
11 If=V/Rf; ..... //current in
      amperes
12 l=3; ..... //line current in
      amperes
13 i=2.33; ..... //current in motor
      in amperes
14 I=0.67; ..... //current i amperes
15 L=(V*l)-(((i)^2)*Ra)-(V*I); .....
      //Iron , friction and windage losses
16 O=20; ..... //generator
17 OP=(O*1000)/V; ..... //output current of
      the generator under loaded condition in amperes
18 Ia=I+OP; ..... //output in amperes
19 Effi=(O*1000*100)/((O*1000)+(((Ia)^2)*Ra)+(V*I)+L);
20 printf("efficiency of the machine=%fpercent",Effi)

```

Scilab code Exa 2.32 Calculate the appox efficiency of each machine

```

1 //Calculate the appox. efficiency of each machine
2 //Chapter 2
3 //Example 2.32
4 //page 149
5 clear;
6 clc;

```

```

7 disp("Example 2.32")
8 Ig=25;.....//current of generator in
    amperes
9 I=30;.....//current in motor in
    amperes
10 Il=I-Ig;.....//current in amperes
11 Ra=0.25;.....//resistance in ohms
12 G1=((Ig)^2)*Ra;.....//loss in generator
    in watt
13 M=((I)^2)*Ra;.....//loss in motor in
    watt
14 T=G1+M;.....//total loss in watt
15 V=100;.....//voltage in volts
16 P=V*Il;.....//power supplied from mains in
    watt
17 L=P-T;.....//iron , friction and windages
    losses in the two machines in ohms
18 l=L/2;.....//iron , friction and
    windages losses in each machines in ohms
19 IP=I*V;.....//input
20 Eff=((IP-M-l)/IP)*100;
21 printf("Efficiency of the motor=%fpercent",Eff)
22 OP=Ig*V;.....//output
23 Effi=((OP)/(OP+G1+l))*100;
24 printf("\nEfficiency of the generator=%fpercent",
    Effi)

```

Scilab code Exa 2.33 Calculate the appox efficiency of each machine

```

1 //Calculate the appox. efficiency of each machine
2 //Chapter 2
3 //Example 2.33
4 //page 150

```

```

5 clear;
6 clc;
7 disp("Example 2.33")
8 V=440;.....//voltage in volts
9 P=200*1000;.....//power in watt
10 Ig=P/V;.....//rated current of each machine
    in amperes
11 //assume losses to be equal
12 I=90;.....//addition currnet supply
13 Effi=sqrt(Ig/(Ig+I))*100;
14 printf("approximate efficiency=%fpercent",Effi)

```

Scilab code Exa 2.34 Calculate the efficiencies of the generator at full load

```

1 //Calculate the efficiencies of the generator at full
   load
2 //Chapter 2
3 //Example 2.34
4 //page 150
5 clear;
6 clc;
7 disp("Example 2.34")
8 Ig=2000;.....//output
   current of generator in amperes
9 I=380;.....//Input current
   from supply mains in amperes
10 Effi=sqrt(Ig/(Ig+I))*100;.....//
   Efficiency of generator assuming equal
   efficiencies of the two machines
11 printf("Efficiencies of the generator at full load
   assuming equal efficiencies=%fpercent",Effi)
12 S=22;.....//Shunt field
   current of generator

```

```

13 G=Ig+S;.....//Armature current of
               generator in amperes
14 R=0.01;.....//Resistance
               of the armature circuit of each machine in ohms
15 Gc=((G)^2)*R;.....//copper loss
               in armature circuit of generator in W
16 V=500;.....//Voltage in
               volts
17 L=V*S;.....//loss in the
               field circuit of the generator in W
18 T=Ig+I;.....//total current
               supply in amperes
19 Sf=17;.....///
               shunt field current of motor in amperes
20 A=T-Sf;.....//armature
               current in motor in amperes
21 Lc=((A)^2)*R;.....//loss in
               armature circuit of motor in amperes
22 Lf=V*Sf;.....//loss in
               the shunt field circuit of motor in W
23 Tin=V*I;.....//total input to motor
               and generator in W
24 Ml=Tin-(Gc+L+Lc+Lf);.....//iron ,
               friction and windage loss in both machines in W
25 Me=Ml/2;.....//iron ,
               friction and windage loss in each machine in W
26 p=1000;.....//power in kW
27 OP=(Ig*V)/p;.....//full load
               output of the generator
28 Eff=(p*100)/(p+((Gc+L+Me)/1000));
29 printf("\nEfficiency of the generator at full load=
               %fpercent",Eff)

```

Chapter 3

Transformers

Scilab code Exa 3.1 calculating number of turns and primary and secondary currents

```
1 // calculating number of turns ,primary and secondary  
  currents and value of flux  
2 //Chapter 3  
3 //Example 3.1  
4 //page 196  
5 clear;  
6 clc;  
7 disp(" Example 3.1")  
8 kVA=500;           //rating  
9 V1=11000;          //primary voltage in volts  
10 V2=400;           //secondary voltage in  
    volts  
11 N2=100;           //number of turns in  
    secondary winding  
12 f=50;             //frequency in hertz  
13 N1=(V1*N2)/V2;   //number of turns in  
    primary winding  
14 printf("number of turns in primary winding ,N1=%  
    %dturns",N1)  
15 I1=(kVA*1000)/V1;  
16 I2=(kVA*1000)/V2
```

```

17 printf("\nprimary current ,I1=%fA",I1)
18 printf("\nsecondary current ,I2=%fA",I2)
19 E1=V1;
20 phi=E1/(4.44*f*N1)
21 printf("\nmaximum flux in the core=%fWb",phi)

```

Scilab code Exa 3.2 calculating number of primary and secondary turns

```

1 //calculating number of primary and secondary turns
2 //Chapter 3
3 //Example 3.2
4 //page 196
5 clear;
6 clc;
7 disp("Example 3.2")
8 V1=6600; //primary voltage in volts
9 V2=230; //secondary voltage in
           volts
10 f=50; //frequency in hertz
11 Bm=1.1; //flux density in Wb/m^2
12 A=(25*25*10^(-4)); //area of the core in m^2
13 phi=Bm*A
14 printf("flux=%fWb",phi)
15 E1=V1;
16 E2=V2;
17 N1=E1/(4.44*f*phi);
18 N2=E2/(4.44*f*phi);
19 printf("\nnumber of turns in primary winding ,N1=%dturns",N1)
20 printf("\nnumber of turns in secondary winding ,N2=%dturns",N2)

```

Scilab code Exa 3.3 calculating induced emf and maximum flux density

```
1 //calculating induced emf and maximum flux density
2 //Chapter 3
3 //Example 3.3
4 //page 197
5 clear;
6 clc;
7 disp("Example 3.3")
8 V1=230;           //primary voltage in volts
9 f=50;             //frequency in hertz
10 N1=100;           //number of primary turns
11 N2=400;           //number of secondary turns
12 A=250*10^(-4);    //cross section area of
                      //core in m^2
13 disp("since at no-load E2=V2")
14 E2=(V1*N2)/N1;
15 printf("induced secondary winding ,E2=%dV" ,E2);
16 phi=E2/(4.44*f*N2);
17 Bm=phi/A;
18 printf("\nMaximum flux density in the core=%fWb/m^2
" ,Bm)
```

Scilab code Exa 3.4 calculating induced emf and maximum flux density

```
1 //calculating induced emf and maximum flux density
2 //Chapter 3
3 //Example 3.3
```

```

4 //page 197
5 clear;
6 clc;
7 disp("Example 3.3")
8 kVA=40;           //rating of the transformer
9 V1=2000;          //primary side voltage in
                    volts
10 V2=250;          //secondary side voltage in
                    volts
11 R1=1.15;         //primary resistance in ohms
12 R2=0.0155;       //secondary resistance in
                    ohms
13 R=R2+(((V2/V1)^2)*R1)
14 printf("Total resistance of the transformer in terms
        of the secondary winding=%fohms",R)
15 I2=(kVA*1000)/V2;
16 printf("\nFull load secondary current=%dA",I2)
17 printf("\nTotal resistance load on full load=%fVolts
        ",(I2*R))
18 printf("\nTotal copper loss on full load=%fWatts",((I2)^2*R))

```

Scilab code Exa 3.5 Calculating the current and power factor of the primary circuit

```

1 //Calculating the current and power factor of the
    primary circuit
2 //Chapter 3
3 //Example 3.5
4 //page 206
5 clear;
6 clc;
7 disp("Example 3.5")
8 I2=300;.....//Secondary current

```

```

    in amperes
9 N1=1200;                                //number of primary
    turns
10 N2=300;                                 //number of
    secondary turns
11 I0=2.5;                                  //load current in
    amperes
12 I1=(I2*N2)/N1;
13 phi0=acosd(0.2);
14 phi2=acosd(0.8);
15 I1c=(I1*cosd(phi2))+(I0*cosd(phi0));
16 I1s=(I1*sind(phi2))+(I0*sind(phi0));
17 I=sqrt(I1c^2+I1s^2);
18 phi=atand(I1s/I1c)
19 printf("primary power factor=%fdegrees",cosd(phi));

```

Scilab code Exa 3.6 Calculating the value of primary current

```

1 // Calculating the value of primary current
2 // Chapter 3
3 // Example 3.6
4 // page 207
5 clear;
6 clc;
7 disp("Example 3.6")
8 I0=1.5;                                //no-load current
9 phi0=acosd(0.2)
10 I2=40;                                   //secondary current in
    amperes
11 phi2=acosd(0.8)
12 r=3;                                     //ratio of primary and
    secondary turns
13 I1=I2/r;

```

```

14 I1c=(I1*cosd(phi2))+(I0*cosd(phi0));
15 I1s=(I1*sind(phi2))+(I0*sind(phi0));
16 I=sqrt(I1c^2+I1s^2);
17 printf("I1=%fA",I)

```

Scilab code Exa 3.7 Calculating the magnetising current and core loss and flux

```

1 // Calculating the magnetising current ,core loss and
   flux
2 //Chapter 3
3 //Example 3.7
4 //page 208
5 clear;
6 clc;
7 disp("Example 3.7")
8 V1=230;           //voltage in volts
9 f=50;             //frequency of supply in
                   hertz
10 N1=250;           //number of primary turns
11 I0=4.5;           //no-load current in amperes
12 phi0=acosd(0.25);
13 Im=I0*sind(phi0)
14 printf("magnetising current ,Im=%fA",Im);
15 Pc=V1*I0*cosd(phi0);
16 printf("\nCore loss=%dW",Pc)
17 disp("neglecting I^2R loss in primary winding at no-
      load")
18 E1=V1;
19 phi=E1/(4.44*f*N1);
20 printf("\nMaximum value of flux in the core=%fWb",
      phi)

```

Scilab code Exa 3.8 Calculating the current and power factor of the primary circuit

```
1 // Calculating the current and power factor of the
   primary circuit
2 // Chapter 3
3 // Example 3.8
4 // page 209
5 clear;
6 clc;
7 disp("Example 3.8")
8 I2=30;.....//Secondary current in
               amperes
9 I0=2;          //load current in
               amperes
10 V1=660;        //primary voltage in
                  volts
11 V2=220;        //secondary voltage
                  in volts
12 I1=(I2*V2)/V1;
13 phi0=acosd(0.225);
14 phi2=acosd(0.9);
15 I1c=(I1*cosd(phi2))+(I0*cosd(phi0));
16 I1s=(I1*sind(phi2))+(I0*sind(phi0));
17 I=sqrt(I1c^2+I1s^2);
18 phi=atand(I1s/I1c)
19 printf("I1=%fA",I)
20 printf("\nprimary power factor=%fdegrees",cosd(phi))
;
```

Scilab code Exa 3.9 Calculating magnetising current and primary current and primary

```
1 // Calculating magnetising current ,primary current
   and primary power factor
2 //Chapter 3
3 //Example 3.9
4 //page 210
5 clear;
6 clc;
7 disp("Example 3.9")
8 phi_m=7.5*10^(-3);                                //maximum
   flux
9 f=50;                                              // frequency in hertz
10 N1=144;                                            //number of primary
   turns
11 N2=432;                                            //number of
   secondary turns
12 kVA=0.24;                                          // rating of
   transformer
13 E1=(4.44*phi_m*f*N1)
14 V1=E1;
15 printf("V1=%dV",V1)
16 I0=(kVA*1000)/V1;
17 phi0=acosd(0.26);
18 Im=I0*sind(phi0);
19 printf("\nIm=%fA",Im);
20 V2=(E1*N2)/N1
21 printf("\nV2=%fV",V2)
22 disp("At a load of 1.2kVA and power factor of 0.8
   lagging")
23 kVA=1.2;
24 phi2=acosd(0.8);
```

```

25 I2=(kVA*1000)/V2;
26 I=(I2*N2)/N1;
27 I1c=(I*cosd(phi2))+(I0*cosd(phi0));
28 I1s=(I*sind(phi2))+(I0*sind(phi0));
29 I=sqrt(I1c^2+I1s^2);
30 printf("\nI1=%fA",I);
31 phi=acosd(((I*cosd(phi2))+(I0*cosd(phi0)))/I);
32 printf("\nprimary power factor=%flagging",cosd(phi))

```

Scilab code Exa 3.10 Calculating primary current and primary power factor

```

1 // Calculating primary current and primary power
   factor
2 //Chapter 3
3 //Example 3.10
4 //page 211
5 clear;
6 clc;
7 disp("Example 3.10")
8 V1=6600;                                //primary voltage in
   volts
9 V2=240;                                  //secondary voltage in
   volts
10 kW1=10;                                 //power
11 phi1=acosd(0.8);
12 I2=50;                                   //current in amperes
13 kW3=5;                                   //power
14 phi2=acosd(0.7)
15 kVA=8;                                    //rating
16 phi4=acosd(0.6)
17 I1=(kW1*1000)/(cosd(phi1)*V2);
18 I3=(kW3*1000)/(1*V2);
19 I4=(kVA*1000)/V2;

```

```

20 Ih=((I1*cosd(phi1))+(I2*cosd(phi2))+I3+(I4*cosd(phi4
    ))));
21 Iv=((I1*sind(phi1))+(I2*sind(phi2))-(I4*sind(phi4)))
    ;
22 I5=sqrt((Ih^2)+(Iv^2))
23 printf("I5=%dA",I5)
24 Ip=(I5*V2)/V1;
25 printf("\nThe current drawn by the primary from 6600
    Vmains is equal to ,Ip=%fA",Ip);
26 phi=atand(Iv/Ih);
27 printf("\npower factor=%flagging",cosd(phi))

```

Scilab code Exa 3.11 Calculating equivalent impedance referred to primary

```

1 // Calculating equivalent impedance referred to
   primary
2 //Chapter 3
3 //Example 3.11
4 //page 212
5 clear;
6 clc;
7 disp("Example 3.11")
8 kVA=100;           // rating of the transfromer
9 N1=400;            // number of primary turns
10 N2=80;             // number of secondary
    turns
11 R1=0.3;           // primary resistance in
    ohms
12 R2=0.01;           // secondary resistance
    in ohms
13 X1=1.1;           // primary leakage
    reactance in ohs
14 X2=0.035;          // secondary leakage

```

```

        reactance in ohms
15 Rr2=(((N1/N2)^2)*R2)
16 printf("R2=%f ohms",Rr2);
17 Xx2=((N1/N2)^2)*X2;
18 printf("\nX2=%f ohms",Xx2);
19 Ze=sqrt((R1+Rr2)^2+(X1+Xx2)^2);
20 printf("\nEquivalent impedance=%f",Ze);

```

Scilab code Exa 3.12 Calculating equivalent impedance referred to primary

```

1 //Calculating equivalent impedance referred to
   primary
2 //Chapter 3
3 //Example 3.12
4 //page 216
5 clear;
6 clc;
7 disp("Example 3.11")
8 f=50;                      //frequency in hertz
9 r=6;                        //turns ratio
10 R1=0.90;                   //primary resistance in ohms
11 R2=0.03;                   //secondary resistance in ohms
12 X1=5;                      //primary reactance in ohms
13 X2=0.13;                   //secondary reactance in ohms
14 I2=200;                    //full-load current
15 Re=(R1+(R2*r^2));
16 printf("equivalent resistance referred to primary ,Re
   =%fohms",Re);
17 Xe=(X1+(X2*r^2));
18 printf("\nequivalent reactance referred to primary ,
   Xe=%fohms",Xe);
19 Ze=sqrt(Re^2+Xe^2);
20 printf("\nequivalent impedance referred to primary ,

```

```

        Ze=%fohms" ,Ze) ;
21 Ii2=r*I2;
22 printf("\nsecondary current referred to primary side
        =%fA" ,Ii2);
23 printf("\n(a)Voltage to be applied to the high
        voltage side=%dvolts" ,(Ii2*Ze));
24 printf("\n(b)Power factor=%f" ,(Re/Ze));

```

Scilab code Exa 3.13 Calculate current and power input

```

1 //Calculate current and power input
2 //Chapter 3
3 //Example 3.13
4 //page 216
5 clear;
6 clc;
7 disp("Example 3.13")
8 R1=0.21;                                //primary resistance in
                                             ohms
9 X1=1;                                     //primary reactance in
                                             ohms
10 R2=2.72*10^(-4);                        //secondary resistance
                                              in ohms
11 X2=1.3*10^(-3);                         //secondary reactanced
                                              in ohms
12 V1=6600;                                  //primary voltage in
                                              volts
13 V2=250;                                   //secondary voltage
                                              in volts
14 r=V1/V2;                                  //turns ratio
15 Re=R1+(r^2*R2);
16 printf("Equivalent resistance referred to primary
        side=%fohms" ,Re);

```

```

17 Xe=X1+(r^2*X2);
18 printf("\nEquivalent reactance referred to primary
      side=%f ohms",Xe);
19 Ze=sqrt(Re^2+Xe^2);
20 printf("\nequivalent impedance referred to primary ,
      Ze=%f ohms",Ze);
21 V=400;                                // voltage in volts
22 I1=V/Ze;
23 printf("\nI1=%f",I1);
24 printf("\nPower input=%fW", (I1^2*Re));

```

Scilab code Exa 3.14 Calculate current and power input

```

1 //Calculate current and power input
2 //Chapter 3
3 //Example 3.14
4 //page 217
5 clear;
6 clc;
7 disp("Example 3.14")
8 N1=90;                      //number of primary turns
9 N2=180;                      //number of secondary turns
10 R1=0.067;                   //primary resistance in ohms
11 R2=0.233;                   //secondary resistance in
      ohms
12 printf("Primary winding resistance referred to
      secondary side=%f ohms", (R1*(N2/N1)^2))
13 printf("\nsecondary winding resistance referred to
      primary side=%f ohms", (R2*(N1/N2)^2))
14 printf("\nTotal resistance of the transformer
      referred to primary side=%f ohms", ((R1*(N2/N1)^2)
      +(R2*(N2/N1)^2)))

```

Scilab code Exa 3.15 Calculate percentage regulation

```
1 //Calculate percentage regulation
2 //Chapter 3
3 //Example 3.15
4 //page 217
5 clear;
6 clc;
7 disp("Example 3.15")
8 kVA=30;                                // rating of the transformer
9 V1=6000;                                 //primary voltage in volts
10 V2=230;                                  //secondary voltage in volts
11 R1=10;                                   //primary resistance in ohms
12 R2=0.016;                               //secondary resistance in
                                           ohms
13 Xe=23;                                  //total reactance referred
                                           to the primary
14 phi=acosd(0.8);                         //lagging
15 Re=(R1+((V1/V2)^2*R2))
16 printf("equivalent resistance ,Re=%f ohms" ,Re)
17 I2dash=(kVA*1000)/V1;
18 V2dash=5847;
19 Reg=((I2dash*((Re*cosd(phi))+(Xe*sind(phi))))*100)/
      V2dash;
20 printf("\npercentage regulation=%f percent" ,Reg)
```

Scilab code Exa 3.16 Calculating secondary voltage and voltage regulation

```

1 // Calculating secondary voltage and voltage
   regulation
2 //Chapter 3
3 //Example 3.16
4 //page 218
5 clear;
6 clc;
7 disp("Example 3.16")
8 kVA=10;                                //rating of the transformer
9 V1=2000;                                 //primary voltage in volts
10 V2=400;                                  //secondary voltage in volts
11 R1=5.5;                                  //primary voltage in ohms
12 R2=0.2;                                  //secondary voltage in ohms
13 X1=12;                                   //primary reactance in ohms
14 X2=0.45;                                 //secondary reactance in
   ohms
15 //assuming (V1/V2)=(N1/N2)
16 Re=R2+(R1*(V2/V1)^2);
17 printf("equivalent resistance referred to the
   secondary=%f ohms",Re);
18 Xe=X2+(X1*(V2/V1)^2);
19 printf("equivalent reactance referred to the
   secondary=%f ohms",Xe);
20 Ze=sqrt(Re^2+Xe^2);
21 printf("equivalent impedance referred to the
   secondary=%f ohms",Ze);
22 phi=acosd(0.8);
23 V1=374.5;
24 printf("\nVoltage across the full load and 0.8 p.f
   lagging=%fV",V1);
25 reg=((V2-V1)*100)/V1;
26 printf("\npercentage voltage regulation=%f percent",
   reg);

```

Scilab code Exa 3.17 Calculating regulation

```
1 //Calculating regulation
2 //Chapter 3
3 //Example 3.17
4 //page 219
5 clear;
6 clc;
7 disp("Example 3.17")
8 kVA=80;                                //rating of the transformer
9 V1=2000;                                 //primary voltage in volts
10 V2=200;                                  //secondary voltage in volts
11 f=50;                                    //frequency in hertz
12 Id=8;                                    //impedance drop
13 Rd=4;                                    //resistance drop
14 phi=acosd(0.8)
15 I2Ze=(V2*Id)/100;
16 I2Re=(V2*Rd)/100;
17 I2Xe=sqrt(I2Ze^2-I2Re^2)
18 reg=((I2Re*cosd(phi))+(I2Xe*sind(phi)))*(100/V2)
19 printf("percentage regulation=%fpercent",reg)
20 pf=I2Xe/sqrt(I2Re^2+I2Xe^2)
21 printf("\nPower factor for zero regulation=%f(%
leading)",pf)
```

Scilab code Exa 3.19 Calculating the efficiency and voltage regulation

```
1 //Calculating the efficiency and voltage regulation
2 //Chapter 3
3 //Example 3.19
4 //page 225
5 clear;
6 clc;
```

```

6 disp("Example 3.19")
7 kVA=50; //rating of the
   transformer
8 V1=3300; //open circuit
   primary voltage
9 Culoss=540; //copper loss from
   short circuit test
10 coreloss=460; //core loss from open
   circuit test
11 V1sc=124; //short circuit
   primary voltage in volts
12 I1sc=15.4; //short circuit
   primary current in amperes
13 Psc=540 //short circuit
   primary power in watts
14 phi=acosd(0.8)
15 effi=(kVA*1000*cosd(phi)*100)/((kVA*1000*cosd(phi))+
   Culoss+coreloss)
16 printf("From the open-circuit test , core-loss=%dW" ,
   coreloss);
17 printf("\nFrom short circuit test , copper loss=%dW" ,
   Culoss);
18 printf("\nThe efficiency at full-load and 0.8
   lagging power factor=%f" ,effi);
19 Ze=V1sc/I1sc;
20 Re=Psc/I1sc^2;
21 Xe=sqrt(Ze^2-Re^2);
22 V2=3203;
23 phi2=acosd(0.8);
24 phie=acosd(Culoss/(V1sc*I1sc));
25 reg=(V1sc*cosd(phie-phi2)*100)/V1;
26 printf("\nVoltage regulation=%dpercent" ,reg)

```

Scilab code Exa 3.20 Calculate voltsge to be applied

```
1 //Calculate voltsge to be applied//Chapter 3
2 //Example 3.20
3 //page 226
4 clear;
5 clc;
6 disp("Example 3.20")
7 kVA=100;
8 V1=6600;           //primary voltage in volts
9 V2=330;           //secondary voltage in
                    volts
10 f=50;             //frequency in hertz
11 V1sc=100;         //short circuit
                    primary voltage in volts
12 I1sc=10;          //short circuit
                    primary current in amperes
13 Psc=436;          //short circuit
                    primary power in watts
14 Ze=V1sc/I1sc;
15 Re=Psc/I1sc^2;
16 phi=acosd(0.8);
17 Xe=sqrt(Ze^2-Re^2);
18 printf("\nTotal resistance=%f ohms",Re);
19 printf("\nTotal impedance=%f ohms",Ze)
20 Il=(kVA*1000)/V1;
21 V1dash=(sqrt(((V1*cosd(phi))+(Il*Re))^2+((V1*sind(
    phi)+(Il*Xe))^2));
22 printf("\nfull voltage current ,V1=%dV",V1dash)
```

Scilab code Exa 3.21 Calculate circuit constants and efficiency

```

1 //Calculate circuit constants and efficiency //
    Chapter 3
2 //Example 3.21
3 //page 227
4 clear;
5 clc;
6 disp("Example 3.21")
7 V2=500;                      //secondary voltage in volts
8 V1=250;                      //primary voltage in short
                                circuit test in volts
9 I0=1;                         //current in short circuit test
                                in amperes
10 P=80;                        //core loss in watt
11 Psc=100;                     //power in short circuit
                                test in watts
12 Vsc=20;                      //short circuit voltage in
                                volts
13 Isc=12;                      //short circuit current in
                                amperes
14 phi0=acosd(P/(V1*I0));
15 printf("From open circuit test , cos(phi0)=%f",cos(
    phi0));
16 Ic=I0*cosd(phi0);
17 printf("\nLoss component of no-load current , Ic=%fA",
    Ic)
18 Im=sqrt(I0^2-Ic^2);
19 printf("\nMagnetising current , Im=%fA",Im);
20 Rm=V1/Ic;
21 Xm=V1/Im;
22 Re=Psc/(Isc^2);
23 Ze=Vsc/Isc;
24 Xe=sqrt(Ze^2-Re^2);
25 printf("\n\nEquivalent resistance referred to
    secondary=%f ohms",Re);
26 printf("\n\nEquivalent reactance referred to secondary=
    %f ohms",Xe);
27 printf("\n\nEquivalent impedance referred to secondary=
    %f ohms",Ze);

```

```

28 K=V2/V1;                                // turns ratio
29 printf("\n\nEquivalent resistance referred to primary
      =%f ohms", (Re/K^2));
30 printf("\nEquivalent reactance referred to primary=
      %f ohms", (Xe/K^2));
31 printf("\nEquivalent impedance referred to primary=
      %f ohms", (Ze/K^2));
32 V=500;                                    // output in volts
33 I=10;                                     // output current in
                                             amperes
34 phi=acosd(0.80);
35 effi=(V*I*cosd(phi)*100)/((V*I*cosd(phi))+P+((I)^2*
      Re));
36 printf("\nEfficiency=%f percent", effi);

```

Scilab code Exa 3.22 Calculate efficiency

```

1 //Calculate efficiency //Chapter 3
2 //Example 3.22
3 //page 231
4 clear;
5 clc;
6 disp("Example 3.22")
7 kVA=200;                                  //Rating of the transformer
8 Pin=3.4;                                   //power input to two
                                             transformer in watt
9 Pin2=5.2;
10 coreloss=Pin;                            //core loss of two
                                             transformers
11 phi=acosd(0.8);
12 printf("\nCore loss of two transformer=%fkW", Pin)
13 printf("\nCore loss of each transformer=%fkW", (Pin
      /2))

```

```

14 printf("\nFull load copper loss of the two
         transformer=%fkW",Pin2)
15 printf("Therefore , full load copper loss of each
         transformer=%fkW", (Pin2/2));
16 effi=(kVA*cosd(phi)*100)/((kVA*cosd(phi))+(Pin/2)+(Pin2/2))
17 printf("\nFull load efficiency at 0.8 p.f. lagging=
         %fpercent",effi);

```

Scilab code Exa 3.24 Calculate efficiency of transformer

```

1 //Calculate efficiency of transformer //Chapter 3
2 //Example 3.24
3 //page 233
4 clear;
5 clc;
6 disp("Example 3.24")
7 kVA=50;                                // rating of the
                                             transformer
8 V1=6360;                                // primary voltage
                                             rating
9 V2=240;                                  // secondary
                                             voltage rating
10 pf=0.8
11 coreloss=2;                            // core loss in kilo
                                             watt from open circuit test
12 Culoss=2;                             // copper loss at
                                             secondary current of 175A
13 I=175;                                 // current in
                                             amperes
14 I2=(kVA*1000)/V2;
15 printf("Full load secondary current ,I2=%fA",I2);
16 effi=(kVA*pf*100)/((kVA*pf)+coreloss+(Culoss*(I2/I))

```

```
    ^2))  
17 printf("\nEfficiency=%fpercent",effi)
```

Scilab code Exa 3.25 Calculate efficiency of transformer

```
1 //Calculate efficiency of transformer //Chapter 3  
2 //Example 3.25  
3 //page 234  
4 clear;  
5 clc;  
6 disp("Example 3.25")  
7 kVA=500;                      //rating of the transformer  
8 R1=0.4;                         //resistance in primary  
9 R2=0.001;                        //resistance in secondary  
10 V1=6600;                        //primary voltahe in volts  
11 V2=400;                          //secondary voltage in volts  
12 ironloss=3;                     //iron loss in kilowatt  
13 pf=0.8;                          //power factor lagging  
14 I1=(kVA*1000)/V1;  
15 printf("\nPrimary winding current=%fA",I1);  
16 I2=(I1*V1)/V2;  
17 printf("\nSecondary winding current=%fA",I2);  
18 Culoss=((I1^2*R1)+(I2^2*R2));  
19 printf("\nCopper losses in the two winding=%fWatts",  
       Culoss);  
20 effi=(kVA*pf*100)/((kVA*pf)+ironloss+(Culoss/1000));  
21 printf("\nEfficiency at 0.8 p.f=%fpercent",effi);
```

Scilab code Exa 3.26 Calculate efficiency of transformer

```
1 //Calculate efficiency of transformer //Chapter 3
2 //Example 3.26
3 //page 234
4 clear;
5 clc;
6 disp("Example 3.26")
7 kVA=400;                                // rating of the
                                             transformer
8 ironloss=2;                            //iron loss in kilowatt
9 pf=0.8;                                 //power factor
10 kW=240;                                //load in kilowatt
11 kVA1=kW/pf;
12 disp("Efficiency is maximum when , core-loss=copper-
      loss")
13 coreloss=ironloss;
14 disp("Maximum efficiency occurs at 240kw,0.8 power
      factor , i.e., at 300kVA load")
15 C1300=coreloss;
16 C1400=(C1300*(kVA/kVA1)^2);
17 pf1=0.71;                               //power factor for full load
18 effi=(kVA*pf1*100)/((kVA*pf1)+coreloss+C1400);
19 printf("\nEfficiency at full-load and 071 power
      factor=%dpercent",effi);
20 pf2=1                                    //maximum efficiency
                                             occurs at unity power factor
21 MAXeffi=(kVA1*pf2*100)/((kVA1*pf2)+coreloss+C1300)
22 printf("\nMaximum efficiency at 300kVA and unity
      power factor=%fpercent",MAXeffi);
```

Scilab code Exa 3.27 Calculate efficiency of transformer

```
1 //Calculate efficiency of transformer //Chapter 3
2 //Example 3.27
3 //page 235
4 clear;
5 clc;
6 disp("Example 3.27")
7 kVA=40;                                // rating of the
                                             transformer
8 coreloss=450;                           //core-loss in watts
9 Culoss=800;                            //copper loss in watt
10 pf=0.8;                               //power factor of the
                                             load
11 FLeffi=(kVA*pf*100)/((kVA*pf)+((coreloss+Culoss)
/1000));
12 printf("Full-load efficiency=%fpercent",FLeffi);
13 disp("For maximum efficiency , Core loss=copper loss
")
14 Culoss2=coreloss;                      //for maximum
                                             efficiency
15 n=sqrt(Culoss2/Culoss);
16 kVA2=n*kVA;                           //load for maximum
                                             efficiency
17 MAXeffi=(kVA2*pf*100)/((kVA2*pf)+((coreloss+Culoss2)
/1000));
18 printf("\nValue of maximum efficiency=%fpercent",
MAXeffi);
```

Scilab code Exa 3.28 Calculate current in different parts of winding of autotransformer

```
1 //Calculate efficiency of transformer //Chapter 3
2 //Example 3.29
3 //page 236
4 clear;
5 clc;
6 disp("Example 3.29")
7 kVA=50;                                // rating of the
                                              transformers
8 I1=250;                                 // primary current in
                                              amperes
9 Re=0.006;                               // total resistance
                                              referred to the primary side
10 ironloss=200;                           //iron loss in watt
11 Culoss=(I1^2*Re);                     //copper loss in watt
12 pf=0.8;                                //power factor lagging
13 printf("Full-load copper loss=%fW",Culoss);
14 TL1=((Culoss+ironloss)/1000);
15 printf("\nTotal loss on full load=%fkW",TL1);
16 TL2=((((Culoss*(1/2)^2))+ironloss)/1000)
17 printf("\nTotal loss on half load=%fkW",TL2);
18 effi1=(kVA*pf*100)/((kVA*pf)+TL1);
19 printf("\nEfficiency at full load ,0.8 power factor
      lagging=%f percent",effi1)
20 effi2=((kVA/2)*pf*100)/(((kVA/2)*pf)+TL2);
21 printf("\nEfficiency at half load ,0.8 power factor
      lagging=%f percent",effi2)
```

Scilab code Exa 3.29 Calculate efficiency of transformer

```
1 //Calculate efficiency of transformer //Chapter 3
2 //Example 3.30
3 //page 237
4 clear;
5 clc;
6 disp("Example 3.30")
7 kVA=10;                                // rating of the
                                              transformers
8 V1=400;                                  // primary voltage in
                                              volts
9 V2=200;                                  // secondary voltage in
                                              volts
10 f=50;                                    // frequency in hertz
11 MAXeffi=0.96;                           // maximum efficiency
12 output1=(kVA*0.75);                     // output at 75% of full
                                              load
13 input1=(output1/MAXeffi);
14 printf("\nInput at 75 percent of full load=%fkW",
      input1);
15 TL=input1-output1;
16 printf("\nTotal losses=%fkW",TL);
17 Pi=TL/2;
18 Pc=TL/2;
19 disp("Maximum efficiency occurs at 3/4th of full
      load")
20 Pc=Pi/(3/4)^2;
21 printf("\nThus, total losses on full load=%fW",((Pc+
      Pi)*1000));
22 pf=0.8;                                  // power factor lagging
23 effi=(kVA*pf*100)/((kVA*pf)+(Pc+Pi));
```

```
24 printf("\nEfficiency on full load. 0.8 power factor  
lagging=%fpercent",effi)
```

Scilab code Exa 3.30 Calculate efficiency of transformer

```
1 // Calculate voltage regulation of transformer //  
    Chapter 3  
2 //Example 3.31  
3 //page 237  
4 clear;  
5 clc;  
6 disp("Example 3.31")  
7 kVA=500;                                // rating of the  
    transformers  
8 V1=3300;                                    // primary voltage in  
    volts  
9 V2=500;                                     // secondary voltage in  
    volts  
10 f=50;                                       // frequency in hertz  
11 MAXeffi=0.97;  
12 x=0.75;                                     // fraction of full load  
    for maximum efficiency  
13 pf1=1;  
14 output1=(kVA*x*pf1*1000);  
15 printf("Output at maximum efficiency=%dwatts",  
    output1);  
16 losses=((1/MAXeffi)-1)*output1;  
17 printf("\nThus, at maximum efficiency,\n    losses=%fW",losses)  
18 Culoss=losses/2;  
19 printf("\nCopper losses at 75 percent of full load=%dW",Culoss);  
20 CulossFL=Culoss/x^2;
```

```

21 printf("\nCopper losses at full load=%dW", CulossFL);
22 Re=CulossFL/(kVA*1000);
23 Ze=0.1; // equivalent
24 Xe=sqrt(Ze^2-Re^2);
25 phi=acosd(0.8);
26 reg=((Re*cosd(phi))+(Xe*sind(phi)))*100;
27 printf("\npercentage regulation=%f percent",reg);

```

Scilab code Exa 3.32 Calculate current in different parts of winding of autotransformer

```

1 // Calculate current in different parts of winding of
   autotransformer// Chapter 3
2 //Example 3.32
3 //page 240
4 clear;
5 clc;
6 disp("Example 3.32")
7 V1=230; //primary voltage of auto
   -transformer
8 V2=75; //secondary voltage of
   auto-transformer
9 r=(V1/V2); //ratio of primary to
   secondary turns
10 I2=200; //load current in amperes
11 I1=I2/r;
12 printf("Primary current ,I1=%fA",I1);
13 printf("\nLoad current ,I1=%fA",I2);
14 printf("\ncurrent flowing through the common portion
   of winding=%fA", (I2-I1));
15 printf("\nEconomy in saving in copper in percentage=
   %fpercent", (100/r));

```

Chapter 4

Three Phase Induction Machines

Scilab code Exa 4.1 to calculate synchronous speed and speed of rotro for slip con

```
1 //Calculating synchronous speed and speed of a rotor
2 //Chapter 4
3 //Example 4.1
4 //page 288
5 clear;
6 clc;
7 disp("example 4.1");
8 f=50;    //frequency
9 p=6;    // number of poles
10 V=400; //voltage supply
11 S=4;    //percentage slip
12 Ns=(120*f)/p; //synchronous speed
13 printf("Synchronous speed ,Ns=%d \n",Ns);
14 Nr=(1-(S/100))*Ns;
15 printf("speed of rotor with slip 4 percent ,Nr is %d
    rpm \n",Nr);
```

Scilab code Exa 4.2 to find out rotor running at higher slip

```
1 //determining rotor running at high slip
2 //Chapter 4
3 //Example 4.2
4 //page 288
5 clear;
6 clc;
7 disp("example 4.2");
8 f=50;      //frequency
9 V=400;    //voltage supply
10
11 p=2;
12 printf("when P=2, Synchronous speed ,Ns=%d \n",((120*
13 f)/p));
13 p=4;
14 printf("when P=2, Synchronous speed ,Ns=%d \n",((120*
15 f)/p));
15 p=6;
16 printf("when P=2, Synchronous speed ,Ns=%d \n",((120*
17 f)/p));
17 p=8;
18 printf("when P=2, Synchronous speed ,Ns=%d \n",((120*
19 f)/p));
20 disp("for Nr to be 1440 , Ns will be 1500, thus p=4")
21 Ns=1500;Nr1=1440;
22 S1=((Ns-Nr1)/Ns)*100;
23 printf("slip=%d\n",S1);
24 disp("for Nr to be 940 , Ns will be 1000, thus p=6")
25 Ns=1000;Nr2=940;
26 S2=((Ns-Nr2)/Ns)*100;
```

```
26 printf("slip=%d\n",S2);
27 if S1>S2 then
28     disp("motor running at 1440 rpm is running at
higher slip")
29 elseif S2>S1
30     disp("motor running at 940 rpm is running at
higher slip")
```

Scilab code Exa 4.3 calculating slip and number of poles

```
1 //Calculating synchronous speed and speed of a rotor
2 //Chapter 4
3 //Example 4.3
4 //page 289
5 clear;
6 clc;
7 disp("example 4.3");
8 disp("induction motor is to be run at 1440 rpm")
9 P=10;      //poles of alternator
10 N=600;    //speed of alternator
11 f=(P*N)/120 //frequency
12 printf("frequency=%d",f);
13 disp("when P=2");p=2
14 Ns=(120*f)/p; //synchronous speed
15 printf("Synchronous speed ,Ns=%d \n",Ns);
16 disp("when P=4");p=4;
17 Ns=(120*f)/p; //synchronous speed
18 printf("Synchronous speed ,Ns=%d \n",Ns);
19 //speed of rotor(1440) is less than synchronous
speed 1500, therefore P=4
20 disp("speed of rotor(1440) is less than synchronous
speed 1500, therefore P=4\n")
21 Ns=1500;
```

```
22 Nr=1440;
23 S=((Ns-Nr)/Ns)*100
24 printf("\nslip is %d percent and number of poles is
4",S)
```

Scilab code Exa 4.4 Calculate frequency of rotor induced emf

```
1 //Calculate frequency of rotor induced emf
2 //Chapter 4
3 //Example 4.4
4 //page 293
5 clear;
6 clc;
7 disp("Example 4.4")
8 Nr=1440;           //rotor speed in rpm
9 f=50;              //frequency in hertz
10 //calculating Ns for values of P=2,4,6,8 etc
11 //by checking P=4
12 P=4;
13 Ns=(120*f)/P;    //Synchronous speed
14 S=(Ns-Nr)/Ns;    //slip
15 Fr=S*f;          //rotor frequency
16 printf("Rotor frequency=%dHz",Fr)
```

Scilab code Exa 4.5 Calculating the speed of running motor and its slip

```
1 //Calculating the speed of running motor and its
   slip
2 //Chapter 4
```

```

3 //Example 4.5
4 //page 294
5 clear;
6 clc;
7 disp("Example 4.5")
8 f=50; ..... //induction motor frequency
    in hertz
9 fr=1.5; ..... //rotor frequency in hertz
10 S=fr/f; ..... //slip
11 P=8; ..... //pole
12 Ns=(120*f)/P;
13 printf("synchronous speed=%frpm" ,Ns)
14 Nr=Ns-(S*Ns);
15 printf("\nmotor running speed=%frpm" ,Nr)
16 S1=S*100;
17 printf("\nslip percent=%fpercent" ,S1)

```

Scilab code Exa 4.6 Calculating the speed of rotating magnetic field

```

1 //Calculate rotor current and phase difference
2 //Chapter 4
3 //Example 4.7
4 //page 297
5 clear;
6 clc;
7 disp("Example 4.7")
8 E20=100;           //induced emf in volts
9 R2=0.05;           //rotor resistance in ohms
10 X20=0.1;          //rotor reactance in ohms
11 E20p=E20/sqrt(3);
12 disp("When S=0.04")
13 S=0.04;
14 I2=(S*E20p)/sqrt(R2^2+(S*X20)^2)

```

```

15 printf("I2=%dA", I2);
16 phi2=acosd(R2/(sqrt(R2^2+(S*X20)^2)));
17 printf("\nPhase angle between rotor voltage and
    rotor current=%f degrees", phi2);
18 disp("When S=1")
19 S=1;
20 I2=(S*E20p)/sqrt(R2^2+(S*X20)^2)
21 printf("I2=%dA", I2);
22 phi2=acosd(R2/(sqrt(R2^2+(S*X20)^2)));
23 printf("\nPhase angle between rotor voltage and
    rotor current=%f degrees", phi2);

```

Scilab code Exa 4.7 Calculate rotor current and phase difference

```

1 //Calculate rotor current and phase difference
2 //Chapter 4
3 //Example 4.7
4 //page 297
5 clear;
6 clc;
7 disp("Example 4.7")
8 E20=100;           //induced emf in volts
9 R2=0.05;           //rotor resistance in ohms
10 X20=0.1;          //rotor reactance in ohms
11 E20p=E20/sqrt(3);
12 disp("When S=0.04")
13 S=0.04;
14 I2=(S*E20p)/sqrt(R2^2+(S*X20)^2)
15 printf("I2=%dA", I2);
16 phi2=acosd(R2/(sqrt(R2^2+(S*X20)^2)));
17 printf("\nPhase angle between rotor voltage and
    rotor current=%f degrees", phi2);
18 disp("When S=1")

```

```
19 S=1;
20 I2=(S*E20p)/sqrt(R2^2+(S*X20)^2)
21 printf("I2=%dA",I2);
22 phi2=acosd(R2/(sqrt(R2^2+(S*X20)^2)));
23 printf("\nPhase angle between rotor voltage and
rotor current=%f degrees",phi2);
```

Scilab code Exa 4.8 Calculating the running speed and frequency of the rotor magnet

```
1 //Calculating the running speed and frequency of the
   rotor magnet current
2 //Chapter 4
3 //Example 4.8
4 //page 298
5 clear;
6 clc;
7 disp("Example 4.8")
8 f=50;.....//frequency of induction motor
9 P=4;.....//pole
10 Ns=(120*f)/P;
11 S=3;.....//slip percent
12 Nr=Ns-((Ns*S)/100)
13 fr=(S*f)/100;
14 printf("synchronous speed=%frpm",Ns)
15 printf("\nspeed of running motor=%frpm",Nr)
16 printf("\nrotor frequency=%fHz",fr)
```

Scilab code Exa 4.9 Calculating the running speed and frequency of the rotor magnet

```

1 // Calculating the running speed and frequency of the
   rotor magnet current
2 // Chapter 4
3 // Example 4.9
4 // page 299
5 clear;
6 clc;
7 disp("Example 4.9")
8 fr=2; ..... //frequency of
   motor induced emf in hertz
9 f=50; ..... //frequency of
   induction motor in hertz
10 S=(fr/f)*100; ..... //slip percent
11 P=6; ..... //pole
12 Ns=(120*f)/P;
13 Nr=Ns-((Ns*S)/100);
14 printf("percentage slip=%fpercent",S)
15 printf("\nrotor speed=%frpm",Nr)

```

Scilab code Exa 4.10 Calculating the frequency of the rotor current

```

1 // Calculating the frequency of the rotor current
2 // Chapter 4
3 // Example 4.10
4 // page 299
5 clear;
6 clc;
7 disp("Example 4.10")
8 P=12; ..... //pole
9 f=50; ..... //frequency of induction
   motor in hertz
10 Nr=485; ..... //induction motor
   speed in rpm

```

```

11 Ns=(120*f)/P;
12 S=(Ns-Nr)/Nr;
13 fr=S*f;
14 printf(" frequency of rotor current=%fHz" ,fr)

```

Scilab code Exa 4.11 Calculating the rotor current

```

1 //Calculating the rotor current
2 //Chapter 4
3 //Example 4.11
4 //page 299
5 clear;
6 clc;
7 disp("Example 4.11")
8 E20=100;.....//induced
    emf of induction motor at standstill in volts
9 E20p=E20/sqrt(3);.....//induced
    emf per phase in volts
10 S=0.40;.....//slip
11 E2=S*E20p;.....//rotor
    induced emf at slip S in volts
12 printf("Rotor induced emf at a slip E2=%fV" ,E2);
13 R2=0.4;.....//resistance
    per phase in ohms
14 X20=2.25;.....//standstill
    resistance per phase in ohms
15 Z2=sqrt((R2)^2+(S*X20)^2);.....///
    rotor impedance at slip S in ohms
16 printf("\nRotor impedance at a slip S, Z2=%fohms" ,Z2
    )
17 I=E2/Z2;
18 printf("\nrotor current=%fA" ,I)

```

Scilab code Exa 4.12 Calculate power developed and efficiency

```
1 //Calculate power developed and efficiency
2 //Chapter 4
3 //Example 4.12
4 //page 308
5 clear;
6 clc;
7 disp("Example 4.12")
8 S=0.03;           //slip
9 SI=50;            //stator input in kilowatts
10 SL=2;             //stator loss in kilowatts
11 RI=SI-SL;         //rotor input in kilowatts
12 RIL=S*RI;          //rotor I^2R loss
13 //rotor core loss can be neglected at 3percent slip
14 PDR=RI-RIL;        //power developed by the
                      rotor
15 printf("Power developed by the rotor=%fkW",PDR);
16 FWL=1;             //friction and windage loss in
                      kilowatt
17 OP=PDR-FWL;        //output power
18 printf("\nOutput power=%fkW",OP);
19 effi=(OP*100)/SI;
20 printf("\nEfficiency of the motor=%f percent",effi)
```

Scilab code Exa 4.13 Calculating the rotor loss and rotor speed

```
1 //Calculating the rotor loss and rotor speed
```

```

2 //Chapter 4
3 //Example 4.13
4 //page 309
5 clear;
6 clc;
7 disp(" Example 4.13")
8 f=50; ..... //frequency of induction
               motor in hertz
9 hp=20;           //horse power
10 ph=3;           //Three phase supply
11 P=4;            //number of poles
12 losses=500;     //friction and vintage
                   losses
13 printf("Output of the motor=%fW", (hp*735.5))
14 Pd=(hp*735.5)+losses;           //power developed
                   in watt
15 printf("\nPower developed by the rotor=%dW", Pd);
16 s=0.04;           //slip
17 rotorloss=(s*Pd)/(1-s);
18 printf("\nRotor I^2R-loss=%fW", rotorloss);
19 Ns=(120*f)/P;
20 printf("\nNs=%drpm", Ns);
21 Nr=Ns*(1-s);
22 printf("Nr=%drpm", Nr);

```

Scilab code Exa 4.14 Calculating standstill rotor reactance

```

1 //Calculating standstill rotor reactance
2 //Chapter 4
3 //Example 4.14
4 //page 310
5 clear;
6 clc;

```

```

7 disp("Example 4.14")
8 f=50; ..... //frequency of induction
    motor in hertz
9 P=6;           //number of poles
10 ph=3;         //Three phase supply
11 R2=0.1;       //rotor resistance in
    ohms
12 Ns=(120*f)/P;
13 printf("Syncronous speed ,Ns=%drpm" ,Ns);
14 Nr=940;       //rotor speed in rpm
15 S=(Ns-Nr)/Ns;
16 printf("\nSlip ,S=%f" ,S);
17 printf("\nstandstill rotor reactance ,X20=%fohms" ,(R2
    /S));

```

Scilab code Exa 4.15 Calculating new full load speed

```

1 //Calculating new full load speed
2 //Chapter 4
3 //Example 4.15
4 //page 310
5 clear;
6 clc;
7 disp("Example 4.15")
8 f=50; ..... //frequency of induction
    motor in hertz
9 P=4;           //number of poles
10 Nr=1440;      //rotor speed in rpm
11 R2=0.1;       //rotor resistance in
    ohms
12 X20=0.6;      //rotor standstill
    resistance in ohms
13 Ns=(120*f)/P;

```

```

14 printf(" Synchronous speed=%drpm" ,Ns) ;
15 S1=(Ns-Nr)*(100/Ns) ;
16 printf(" Full-load slip with rotor resistance ,R2 i.e .
           S1=%f" ,S1) ;
17 disp("on adding extra resistance 0.1ohm")
18 //on solving we get S2=0.08
19 S2=0.08 ;
20 Nr2=Ns*(1-S2) ;
21 printf("\nNew rotor speed=%drpm" ,Nr2) ;

```

Scilab code Exa 4.16 Calculating starting torque

```

1 // Calculating starting torque
2 //Chapter 4
3 //Example 4.16
4 //page 311
5 clear;
6 clc;
7 disp(" Example 4.16")
8 f=50;                                //frequency in hertz
9 P=4;                                    //number of poles
10 R2=0.04;                               //rotor resistance in
                                         ohms
11 Ns=(120*f)/P;
12 printf(" Syncronous speed=%drpm" ,Ns) ;
13 Nr=1200;                                //rotor speed at maximum
                                         torque in rpm
14 S=(Ns-Nr)/Ns;
15 printf("\nSlip at maximum torque=%f" ,S) ;
16 X20=R2/S;
17 //starting torque is developed when S=1
18 //r=(Tst/Tm)
19 r=(R2/(R2^2+X20^2))*(2*X20) ;

```

```
20 printf("\nTherefore , starting torque is %fpercent of  
the maximum torque", (r*100));
```

Scilab code Exa 4.18 Calculating external resistance

```
1 //Calculating external resistance  
2 //Chapter 4  
3 //Example 4.18  
4 //page 313  
5 clear;  
6 clc;  
7 disp("Example 4.18")  
8 P=4;                                //number of poles  
9 f=50;                                 //frequency in hertz  
10 ph=3;                                //three phase supply  
11 R2=0.25;                             //rotor resistance in  
   ohms  
12 Nr=1440;                            //rotor speed in rpm  
13 Ns=(120*f)/P;  
14 S1=(Ns-Nr)/Ns;  
15 printf("S1=%f", S1);  
16 Nr2=1200;                            //rotor speed when external is added  
17 S2=(Ns-Nr2)/Ns;  
18 //torque remains constant ,we get the relation R2'=R2  
   *(S2/S1)  
19 R2dash=R2*(S2/S1)  
20 printf("\nExtra resistance to be connected in the  
motor circuit=%fohms", (R2dash-R2))
```

Scilab code Exa 4.20 Calculating full load rotor loss and rotor input and output torque

```
1 //Calculating full load rotor loss and rotor input  
and output torque  
2 //Chapter 4  
3 //Example 4.20  
4 //page 311  
5 clear;  
6 clc;  
7 disp(" Example 4.20")  
8 hp=20;  
9 P=4;                                //number of poles  
10 f=50;  
11 S=0.03;                             //slip  
12 MS0=hp*735.5;                      //motor shaft output  
13 losses=0.02*MS0;                    //friction and windage  
loss in watts  
14 Pd=MS0+losses;                     //power developed  
by the rotor in watts  
15 RCL=(S*Pd)/(1-S);                  //rotor I^2*R loss  
16 printf(" rotor copper loss=%fW",RCL);  
17 Ri=Pd+RCL;                         //rotor iron  
loss is neglected  
18 printf("\nRotor input=%fW",Ri);  
19 Ns=(120*f)/P;  
20 Nr=Ns*(1-S)*(1/60);                //rotor speed  
in rps  
21 OT=MS0/(2*3.14*Nr);               //output torque in Nm  
22 printf("\noutput torque=%fNm",OT)
```

Scilab code Exa 4.21 Calculating the slip and rotor copper loss and the output horsepower

```

1 // Calculating the slip , rotor copper loss ,the output
   horse power and efficiency
2 //Chapter 4
3 //Example 4.21
4 //page 316
5 clear;
6 clc;
7 disp("Example 4.21")
8 f=50; ..... //frequency of induction
   motor in hertz
9 P=6; ..... //pole
10 Ns=(120*f)/P;
11 Nr=975; ..... //induction motor
   running speed in rpm
12 S=(Ns-Nr)/Ns;
13 printf("the slip=%f",S)
14 Pin=40; ..... //power input to stator
   in kW
15 S1=1; ..... //stator losses in kW
16 Rin=Pin-S1; ..... //output from stator in
   kW
17 Rc=S*Rin;
18 printf("\nrotor copper losses=%fkW",Rc)
19 l=2; ..... //total losses in kW
20 p=Rin-Rc-l; ..... //output power in kw
21 HP=(p*1000)/735.5;
22 printf("\noutput horse output=%fHP",HP)
23 in=40; ..... //input in kW
24 effi=(p/in)*100;
25 printf("\nefficiency=%fpercent",effi)

```

Scilab code Exa 2.22 Calculate the value of resistance

```

1 //Calculate the value of resistance
2 //Chapter 2
3 //Example 2.22
4 //page 126
5 clear;
6 clc;
7 disp("Example 2.22")
8 V=440;           //primary voltage in volts
9 Ia=50;           //armature current in amperes
10 Ra=0.2;          //armature resistance in ohms
11 N=600;           //speed in rpm
12 E=V-(Ia*Ra);    //emf induced in volts
13 %E=K*phi*N=K1*Ia*N
14 K1=E/(Ia*N);
15 //we have the relation T=Kt1*Ia^2, T1=Kt1*Ia1^2
16 //when torque is half, say torque be T1
17 //T1=T/2. r=T/T1
18 r=2;
19 Ia1=sqrt(Ia^2/r);
20 printf("Ia1=%fA",Ia1);
21 //extra resistance R is introduced in the circuit
22 N1=400;
23 E1=(K1*Ia1*N1);
24 R=((V-E1)/Ia1)-Ra;
25 printf("\nvalue of extra resistance added=%fohms",R)

```

Scilab code Exa 4.22 Calculating the slip and rotor speed and mechanical power developed

```

1 // Calculating the slip ,rotor speed ,mechanical power
   developed ,rotor copper loss per phase and
   resistance per phase
2 //Chapter 4

```

```

3 //Example 4.22
4 //page 316
5 clear;
6 clc;
7 disp("Example 4.22")
8 f=50; ..... // frequency of
    induction motor in hertz
9 P=6; ..... // pole
10 Ns=(120*f)/P;
11 printf("synchronous speed=%frpm" ,Ns)
12 fr=120/60; ..... // rotor
    frequency
13 S=fr/f;
14 printf("\nthe slip=%f" ,S)
15 Nr=Ns-(Ns*S);
16 printf("\nrotor speed=%frpm" ,Nr)
17 Rin=80; ..... // rotor input in kW
18 Rc=S*Rin; ..... // Rotor copper loss in
    kW
19 Ph=3; ..... // number of
    phases
20 Rcp=(Rc/Ph)*1000; ..... // loss per
    phase in watt
21 p=((Rin-Rc)*1000)/735.5;
22 printf("\nmechanical power developed=%fhp" ,p)
23 Ir=60; ..... // rotor current in
    amperes
24 R2=Rcp/(Ir)^2;
25 printf("\nrotor resistance per phase at rotor
    current 60A=%fohms" ,R2)

```

Scilab code Exa 4.23 Calculating additional resistance required

```

1 //Calculating additional resistance required
2 //Chapter 4
3 //Example 4.23
4 //page 320
5 clear;
6 clc;
7 disp("Example 4.23")
8 // we know  $(T_s/T_m) = ((2*a)/(1+a^2))$ 
9 //where  $a=(R_2/X_{20})$ 
10 //at starting condition since  $T_m=T_s$ 
11 disp("At starting condition since  $T_m=T_s$ ")
12 a=1           //we obtain from the relations
13 R2=0.05;          //circuit resistance in
                     ohms
14 X2=0.4;           //standstill reactance in
                     ohms
15 r=(a*X2)-R2;      //r is the extra that is
                     added to the rotor circuit
16 printf("extra resistance added , r=%f ohms" , r)

```

Scilab code Exa 4.24 Calculate speed of motor and maximum torque

```

1 //Calculate speed of motor and maximum torque
2 //Chapter 4
3 //Example 4.24
4 //page 321
5 clear;
6 clc;
7 disp("Example 4.24")
8 V=400;           //supply voltage in volts
9 f=50;            //frequency in hertz
10 P=6;             //number of poles
11 ph=3;            //three phase supply

```

```

12 R2=0.03;           // rotor resistance in ohms
13 X20=0.4;           // rотор reactance in ohms
14 Nr=960;            // full load speed in rpm
15 Ns=(120*f)/P;
16 printf(" synchronous speed=%drpm" ,Ns)
17 S=(Ns-Nr)/Ns;      // corresponding slip
18 //maximum torque Tm occurs at S=(R2/X20)
19 //we get Tm=k/(2*X20)
20 a=R2/X20;
21 // r=Tm/T
22 r=(a^2+S^2)/(2*a*S);
23 Sm=(R2/X20);
24 printf("\nSlip at maximum torque ,Sm=%f" ,Sm);
25 //corresponding speed
26 Nr2=Ns*(1-Sm);
27 printf("\nRotor speed at maximum torque=%drpm" ,Nr2)

```

Scilab code Exa 4.25 Calculate starting current

```

1 //Calculate starting current
2 //Chapter 4
3 //Example 4.25
4 //page 321
5 clear;
6 clc;
7 disp("Example 4.25")
8 V=400;           //supply voltage in volts
9 f=50;            //frequency in hertz
10 P=4;             //number of poles
11 ph=3;            //three phase supply
12 S=0.04;
13 If=30;           //Full load current in
                     amperes

```

```

14 Isc=6*If;
15 // let r be the ratio of starting torque nd full load
   torque , r=Ts/Tf
16 r=(Isc/If)^2*S;
17 //Tf=Tm is produced when voltage is Vm
18 Vm=sqrt(V^2/r);
19 printf("\nvoltage at maximum torque=%fvolts",Vm);
20 Is=6*If*(Vm/V);
21 printf("\nFull-load current at 333.3 volts is=%fA",
   Is)

```

Scilab code Exa 4.26 Calculate starting line current and starting torque

```

1 //Calculate starting line current and starting
   torque
2 //Chapter 4
3 //Example 4.26
4 //page 330
5 clear;
6 clc;
7 disp("Example 4.26")
8 V=400;           //supply voltage in volts
9 f=50;            //frequency in hertz
10 Id=75;          //current taken when delta
   -connected in amperes
11 printf("current taken when delta-connected=%dA",Id);
12 Is=Id/3;         //current taken when
   star-connected in amperes
13 printf("\ncurrent taken when star-connected=%dA",Is)
   ;
14 //Tfl be the full load torque
15 //r=Ts/Tfl
16 r=1.5;

```

```
17 //since voltage becomes (1/sqrt(3)) when star  
    connected  
18 //torque is directly proportional to square of  
    voltage  
19 printf("\nStarting torque with winding star  
connected=%f times of Tfl", (r/3));
```

Scilab code Exa 4.28 Calculate starting torque

```
1 //Calculate starting torque  
2 //Chapter 4  
3 //Example 4.28  
4 //page 333  
5 clear;  
6 clc;  
7 disp("Example 4.28")  
8 ph=3;  
9 //rotor copper loss=slip*rotor input  
10 //Tst= starting torque  
11 //Tfl=torque at full load  
12 //Ist/Ifl=r  
13 r=6;  
14 S=0.04  
15 printf(" At slip=0.04")  
16 printf("\nFor direct-on-line starting , (Tst/Tfl)=%f"  
      ,((r^2*S)));  
17 //phase current in start is (1/sqrt(3)) times the  
    phase current in delta  
18  
19 printf("\nFor direct-on-line starting , (Tst/Tfl)=%f"  
      ,((r/sqrt(3))^2*S));
```

Scilab code Exa 4.29 Calculate full load speed

```
1 //Calculate full load speed
2 //Chapter 4
3 //Example 4.29
4 //page 334
5 clear;
6 clc;
7 disp("Example 4.29")
8 V=400;                                // voltage in volts
9 f=50;                                   // frequency in hertz
10 P=4;                                    //number of poles
11 //r1=(Ts/Tfl)
12 r1=1.6;
13 //r2=(Tm/Tfl)
14 r2=2;
15 //r3=(Ts/Tm)=(2*a)/(1+a^2)
16 r3=0.8;
17 //on solving , we get a=0.04 ,
18 a=0.04;
19 Sm=0.04;      // slip at maximum torque
20 printf("Slip at maximum torque ,Sm=%f" ,Sm)
21 Ns=(120*f)/P;                         //synchronous speed in rpm
22 Nr=Ns*(1-Sm)                           //rotor speed in rpm
23 //r2=(a^2+Sfl^2)/(2*a*Sfl)
24 Sfl=0.01;
25 Nr2=Ns*(1-Sfl);
26 printf("\nfull load speed ,Nr=%drpm" ,Nr2)
```

Scilab code Exa 4.30 Calculate full load rotor loss and rotor input and output torque

```
1 //Calculate full load rotor loss and rotor input and
   output torque
2 //Chapter 4
3 //Example 4.30
4 //page 345
5 clear;
6 clc;
7 disp("Example 4.30")
8 hp=20;                      //power in horsepower
9 f=50;                        //frequency in hertz
10 P=4;                         //number of poles
11 Ns=(120*f)/P;               //synchronous speed
12 printf(" Synchronous speed ,Ns=%drpm" ,Ns);
13 S=0.04;                      //slip
14 Nr=Ns*(1-S);
15 OP=hp*735.5;
16 printf("\nOutput power=%fW" ,OP);
17 OT=OP/(2*3.14*(Nr/60));
18 printf("\nOutput torque=%fNm" ,OT);
19 FL=0.02*OP;                  //Friction and windage loss
20 PD=OP+FL;
21 printf("\nPower developed by the rotor=%fW" ,PD);
22 //from relation , (rotor I^2R-loss=S*Rotor input) we
   get following relation
23 RL=(S*PD)/(1-S);
24 printf("\nRotor I^2R-loss=%fW" ,RL);
25 RI=RL/S;
26 printf("\nRotor input=%dW" ,RI)
```

Scilab code Exa 4.31 Calculate full load rotor loss and rotor input and output torque

```
1 //Calculate full load rotor loss and rotor input and
   output torque
2 //Chapter 4
3 //Example 4.31
4 //page 347
5 clear;
6 clc;
7 disp("Example 4.31")
8 P=4;                      //number of poles
9 f=50;                     //frequency in hertz
10 V=230;                    //voltage in volts
11 hp=5;                     //power in horsepower
12 Ib=15;                    //current in block rotor test
   in amperes
13 output=hp*735.5;          //output in watts
14 //in block rotor test: power input=Full=load I^2R
   losses=735W
15 FL1=735;                  //Full-load
   I^2R losses
16 printf("Full-load I^2R losses=%fW",FL1);
17 Re=FL1/(3*Ib^2);
18 Io=6.3;                   //current in no load
   condition in amperes
19 lossNL=(3*(Io)^2*Re);    //I^2R loss at no-load
   condition
20 printf("\nI^2R loss at no-load=%fW",lossNL);
21 PiNL=275;                 //power input at no-load
22 printf("\nCore loss plus friction and windage loss=
   %dW", (PiNL-lossNL));
23 TL=FL1+(PiNL-lossNL);
```

```
24 effi=(output*100)/(output+TL);
25 printf("\nEfficiency=%fpercent",effi)
```

Scilab code Exa 4.32 Calculate full load efficiency

```
1 //Calculate full load efficiency
2 //Chapter 4
3 //Example 4.32
4 //page 347
5 clear;
6 clc;
7 disp("Example 4.32")
8 Vl=415;           //voltage in volts
9 I1=50;            //line current in amperes
10 R1=0.5;           //resistance of stator
    winding per phase in ohms
11 pf=0.85;          //power factor
12 S=0.04;
13 IFL=(sqrt(3)*Vl*I1*pf)           //input to the motor
    on full load
14 printf("Input to the motor on full load=%dW",IFL);
15 I1=I1/sqrt(3);
16 SLFL=(3*I1^2*R1)           //Stator I^2R loss on
    full load
17 printf("\nStator I^2R loss on full load=%dW",SLFL);
18 //given ratio of stator core loss friction and
    windage loss be r=(r1:r2)
19 r1=3;
20 r2=2;
21 TL=1500;           //total loss
22 SCL=(r1*TL)/(r1+r2);           //stator core loss
23 FWL=(r2*TL)/(r1+r2);           //Friction and
    windage loss
```

```

24 SL=SLFL+SCL; // total stator
    loss
25 SI=IFL; // Stator input
26 Pa=SI-SL; // power
    transferred through the air-gap=input to the
    rotor
27 RI=Pa
28 RL=S*RI; // rotor losses
29 TRL=FWL+RL; // total rotor
    losses
30 OP=RI-TRL; // Output power
    at the shaft
31 effi=(OP*100)/SI;
32 printf("\nEfficiency=%f percent",effi)

```

Scilab code Exa 4.33 Calculating the rotor current at slip 3 precent and when the

```

1 // Calculating the rotor current at slip 3 precent
    and when the rotor develops maximum torque
2 //Chapter 4
3 //Example 4.33
4 //page 351
5 clear;
6 clc;
7 disp("Example 4.33")
8 E20=100;.....//induced emf
    between slip terminals in volts
9 E20p=E20/sqrt(3);.....//induced
    emf per phase in volts
10 printf("induced emf per phase=%fV",E20p)
11 S=3/100;.....//slip
12 R2=0.2;.....//resistance
    in ohms

```

```

13 X20=1;.....// standstill
    resistance in ohms
14 I2=(S*E20p)/sqrt((R2)^2+(S*X20)^2)
15 printf("\nrotor current at slip 0.03 =%fA per phase"
    ,I2)
16 Sm=R2/X20;
17 I2m=(Sm*E20p)/sqrt((R2)^2+(Sm*X20)^2)
18 printf("\nrotor current when the rotor develops
    maximum torque=%fA per phase",I2m)

```

Scilab code Exa 4.34 Calculating the rotor current at slip 3 percent and when the

```

1 //Calculating the rotor current at slip 3 percent
    and when the rotor develops maximum torque
2 //Chapter 4
3 //Example 4.34
4 //page 352
5 clear;
6 clc;
7 disp("Example 4.34")
8 E20=120;.....//induced emf of motor
    at standstill in volts
9 E20p=120/sqrt(3);.....//induced emf
    per phase
10 f=50;.....//frequency of
    the motor in hertz
11 R2=0.2;.....//Rotor
    Resistance per phase
12 X20=1;.....//Standstill resistance in ohms
13 P=4;.....//pole
14 I=16;.....// 
15 S=(I*R2)/sqrt((E20)^2-(I*X20)^2);

```

```

16 Ns=(120*f)/P;
17 printf("Synchronous speed=%frpm" ,Ns)
18 Nr=Ns-(Ns*S)
19 Sm=R2/X20;
20 Nr=Ns-(Ns*Sm)
21 I2=(Sm*E20p)/sqrt((R2)^2+(Sm*X20)^2)
22 printf("\nrotor current at maximum torque=%fAper
Phase" ,I2)
23 Pi=(3*((I2)^2)*R2)/Sm;
24 printf("\nRotor input for the three phase=%fW" ,Pi)

```

Scilab code Exa 4.35 Calculate the circuit elements

```

1 //Calculate the circuit elements
2 //Chapter 4
3 //Example 4.35
4 //page 356
5 clear;
6 clc;
7 disp("Example 4.35")
8 R1dc=0.01;                                //DC resistance in
                                              ohms
9 V=400;                                     //voltage in volts
10 r=1.5;                                    //ratio of ac to dc
                                              resistance
11 R1=r*R1dc;                                //AC resistance in ohms
12 //at no-load
13 Io=20;                                     //no-load current in
                                              amperes
14 SL=(3*Io^2*R1);                           //I^2R loss in the stator
                                              phases in watts
15 FWL=300;                                   //Friction and windage loss
                                              in watts

```

```

16 TL=1200; // total losses=no-load
    power input in watts
17 CL=TL-(SL+FWL); //core loss in watt
18 CLp=CL/sqrt(3); //core loss per phase
19 Vp=V/sqrt(3); //voltage per phase
20 Rm=(Vp^3)/CL; //motor resistance
21 pf=CL/(Vp*Io);
22 phi0=acosd(pf);
23 Xm=Vp/(Io*sind(phi0)); //motor
    reactance
24 //Under blocked rotor test
25 Vb=100; //voltage in volts
26 Isc=45; //current in amperes
27 Vbp=100/sqrt(3); //voltage per phase in
    volts
28 P=2750; //power supplied in watts
29 Ze=Vbp/Isc; //Motor impedance
    referred to stator side in ohms
30 Re=P/(3*Isc^2);
31 R2=Re-R1; //rotor resistance referred
    to stator side
32 Xe=sqrt(Ze^2-Re^2);
33 //assuming X1=X2
34 X2=Xe/2
35 X1=X2;
36 printf("Thus the elements of the equivalent circuit
    are:");
37 printf("\nRm=%f ohms", Rm);
38 printf("\nXm=%f ohms", Xm);
39 printf("\n\nR1=%f ohms", R1);
40 printf("\nrotor resistance referred to stator side,
    R2=%f ohms", R2);
41 printf("\nequivalent resistance referred to stator
    side ,Re=%f ohms", Re);
42
43 printf("\n\nX1=%f ohms", X1);
44 printf("\nrotor reactance referred to stator side ,X2
    =%f ohms", X2);

```

```
45 printf("\nequivalent reactance referred to stator  
side ,Xe=%fohms" ,Xe);
```

Chapter 5

Three Phase Synchronous Machines

Scilab code Exa 5.1 To calculate distribution factor

```
1 //caption- for calculating distribution factor
2 //Chapter 5
3 //example 5.1
4 //page 424
5 clear;
6 clc;
7 disp("example 5.1");
8 printf("\n");
9 slots=18;
10 p=2;           //number of poles
11 ph=3;          //three phase winding
12 SA=(360/slots); //slot angle
13 m=slots/(p*ph); //m=number of slots per pole per
phase
14 printf("number of slots per pole per phase ,m=%d\n",m
);
15 printf("emfs of the oils of each phase will have a
time-phase difference of %d degree mechanical \n
",SA);
```

```
16 k_d=sind((m*SA)/2)/(m*sind(SA/2));
17 printf(" distribution factor=%f",k_d);
```

Scilab code Exa 5.2 To calculate distribution factor

```
1 //chapter 5
2 //example 5.2
3 //page 425
4 clear;
5 clc;
6 disp("example 5.2")
7 printf("\n");
8 slots=36;           //number of slots
9 poles=4;            //number of poles
10 ph=3;              //single layer three phase winding
11 SP=slots/ph;       //number of slots per phase
12 printf("number of slots per phase= %d\n",SP);
13 m=SP/poles;         //number of slots per pole per phase
14 printf("number of slots per pole per phase,m=%d\n",m
)
15 SA_m=360/slots;    //slot angle mechanical
16 SA_e=(poles/2)*SA_m //slot angle electrical
17 printf("slot angle= %d degree electrical\n",SA_e)
18 k_d=sind((m*SA_e)/2)/(m*sind(SA_e/2));
19 printf(" distribution factor= %f",k_d)
```

Scilab code Exa 5.3 To calculate pitch factor

```
1 //chapter 5
```

```

2 //example 5.3
3 //page 426
4 clear;
5 clc;
6 disp("example 5.3");
7 printf("\n");
8 slots=48;           //number of slots
9 poles=4;            //4-pole machine
10 ph=3;              //3-phase machine
11 SA=360/slots;     //slot angle
12 printf("total number of slots= %d\n",slots);
13 printf("slot angle= %f degree mechanical\n",SA);
14 //coil span is 11 slot pitches
15 //12 slots subtend 180 degrees, short pitched by 1
   slot
16 Bta=1*180/12;
17 k_p=cosd(Bta/2);
18 printf("pitch factor=%f",k_p)

```

Scilab code Exa 5.4 To calculate the rms value of induced EMF

```

1 //chapter 5
2 //example 5.4
3 //page 426
4 clear;
5 clc;
6 disp("example 5.4");
7 printf("\n");
8 slots=72;           //number of slots
9 P=8;                //number of poles
10 ph=3;               //3-phase machine
11 N=750;              //speed of machine in rpm
12 //winding is made with 36 coils having 10 turns

```

```

13 Fp=0.15;           //flux per pole
14 fre=(P*N)/120;
15 NCp=36/ph;        //nmber of coils per phase
16 T=NCp*10;          //number of turns per phase
17 k_p=1;              //since full pitched pitch factor is 1
18 printf("flux per pole=%fWb\n",Fp)
19 printf("number of turns per phase=%d\n",T);
20 printf("pitch factor=%f\n",k_p);
21 m=slots/(P*ph);   //slots per pole per phase
22 SA_m=360/slots;  //slot angle mechanical
23 SA_e=(P/2)*SA_m;
24 k_d=sind((m*SA_e)/2)/(m*sind(SA_e/2));
25 printf("distribution factor=%f\n",k_d);
26 E=4.44*Fp*fre*T*k_d*k_p;
27 printf("RMS vale of emf induced per phase=%fV\n",E)

```

Scilab code Exa 5.5 Calculating useful flux per pole

```

1 //chapter 5
2 //example 5.5
3 //page 427
4 clear;
5 clc;
6 disp("example 5.5");
7 disp("E(line to line)= 440V");
8 E_l=440;           //line-to-line voltage
9 E_p=E_l/(sqrt(3));
10 N=750;             //speed in rpm
11 fre=50;            //frequency
12 P=(120*fre)/N;
13 printf("P= %d\n",P);
14 printf("E(per phase)= %dV\n",E_p);
15 ph=3;               //3-phase machine

```

```

16 m=2;           //number of slots per pole per phase
17 slots=m*P*ph;        //total number of stator slots
18 SA_m=360/slots;      //slot angle mechanical
19 SA_e=(P/2)*SA_m;     //slot angle electrical
20 k_p=1;             //assuming full pitch
21 printf("slot angle= %d degree electrical\n",SA_e);
22 printf("pitch factor=%f\n",k_p);
23 k_d=sind((m*SA_e)/2)/(m*sind(SA_e/2));
24 printf("distribution factor= %f\n\n",k_d);
25 //2 slots per pole per phase
26 NSp=2*P;            //number of slots per phase
27 NTc=4;              //number of turns per coil
28 T=8*NTc;            //number of turns per phase
29 Fp=E_p/(4.44*fre*T*k_d*k_p);
30 printf("flux per pole= %fWb\n",Fp);

```

Scilab code Exa 5.6 To calculate the frequency and induced EMF

```

1 //chapter 5
2 //example 5.6
3 //page 428
4 clear;
5 clc;
6 disp("example 5.6");
7 printf("\n");
8 slots=144;      //number of slots
9 ph=3;           //3-phase machine
10 P=16;          //number of poles
11 Cp=10;          //number of conductors per slot
12 Fp=0.03;        //flux per pole
13 Ns=375;         //synchronous speed
14 fre=(Ns*P)/120; //frequency
15 printf("frequency=%d\n\n",fre);

```

```

16 m=slots/(P*ph);           //number of slots per pole per
                           phase
17 printf("number of slots per pole per phase ,m= %d\n"
         ,m);
18 SA_m=360/slots;          //slot angle mechanical
19 SA_e=(P/2)*SA_m;          //slot angle electrical
20 k_p=1                     //no short pitching
21 printf("short pitch= %d\n",k_p);
22 k_d=sind((m*SA_e)/2)/(m*sind(SA_e/2));
23 printf("distribution factor= %f\n",k_d);
24 T=(slots*10)/(2*ph);
25 printf("number of turns per phase ,T= %d\n",T);
26 E=4.44*Fp*fre*T*k_d*k_p;
27 printf("RMS value of induced emf per phase ,E= %fV\n"
         ,E);
28 printf("induced emf across the linesis %fV \n", (sqrt
         (3)*E));

```

Scilab code Exa 5.7 Finding the number of armature conductors

```

1 //chapter 5
2 //example 5.7
3 //page 428
4 clear;
5 clc;
6 disp("example 5.7");
7 printf("\n");
8 slots=90;           //number of slots
9 P=10;                //number of poles
10 ph=3;               //3-phase machine
11 fre=50;              //frequency
12 Fp=0.16;             //flux per pole
13 E_l=11000;            //line voltage

```

```

14 SA_m=360/slots; //machanical slot angle
15 SA_e=(P/2)*SA_m; //electrical slot angle
16 m=slots/(ph*P);
17 printf("slot angle=%d degree elecrica\n",SA_e)
18 printf("number of slots per pole per phase ,m=%d\n",m
    );
19 k_p=1; //assuming full pitch
20 printf("pitch factor=%d\n",k_p);
21 k_d=sind((m*SA_e)/2)/(m*sind(SA_e/2));
22 printf("distribution factor=%f\n\n",k_d);
23 E_p=E_1/sqrt(3);
24 T=E_p/(4.44*Fp*fre*k_p*k_d);
25 printf("total number of armature conductors ,Z= %d"
    ,(2*T));

```

Scilab code Exa 5.8 To calculate induced EMF per phase

```

1 //chapter 5
2 //example 5.8
3 //page 429
4 clear;
5 clc;
6 disp("example 5.8");
7 disp("P=6      , f=50");
8 P=6;
9 f=50;
10 Sp=12;           //slots per pole
11 Cs=4;            //conductors per slot
12 Fp=1.5;
13 TS=Sp*P
14 printf("total number of slots=%d\n",TS);
15 printf("total number of slots per phase= %d\n", (TS
    /3));

```

```

16 printf("total number of conductors per phase= %d\n",
17 ((TS*Cs)/3));
18 T=((TS*Cs)/3)/2;
19 m=(TS/(P*3));
20 printf("number of slots per pole per phase ,m= %d\n",
21 m);
22 SA_m=360/TS; //slot angle mechanical
23 SA_e=(P/2)*SA_m;
24 k_d=sind((m*SA_e)/2)/(m*sind(SA_e/2));
25 printf("distribution factor=%f\n\n",k_d);
26 disp("coil pitch is 5/6 of full-pitch");
27 printf("\n");
28 btheta=180-(5/6)*180; //short pitch angle
29 printf("short pitch angle= %d degrees\n",btheta)
30 k_p=cosd(btheta/2);
31 printf("pitch factor= %f \n",k_p);
32 E=4.44*Fp*f*T*k_d*k_p;
33 printf("induced per phase= %fV\n",E)

```

Scilab code Exa 5.9 To find the voltage regulation

```

1 //chapter 5
2 //example 5.9
3 //page 439
4 clear;
5 clc;
6 disp("example 5.9");
7 printf("\n");
8 OP=500000; //output power
9 V_l=3300; //line voltage
10 I_l=OP/(sqrt(3)*V_l); //line current
11 printf("line current= %fA\n",I_l);

```

```

12 // for star connected alternator , line current is
   equal to phase current
13 I_a=I_1;
14 pf=0.8;           //power factor
15 phi=acosd(pf);
16 R_a=0.3;          //synchronous resistance
17 X_s=4;            //synchronous reactance
18 V_p=V_1/sqrt(3);
19 printf("phase voltage= %fV\n",V_p)
20 E=sqrt((V_p*cosd(phi)+I_a*R_a)^2+(V_p*sind(phi)+I_a*
   X_s)^2);
21 printf("induced emf= %f V/Phase\n",E )
22 PR=((E-V_p)*100)/V_p;
23 printf("percentage regulation= %f percent\n",PR);

```

Scilab code Exa 5.10 To calculate voltage regulation

```

1 //chapter 5
2 //example 5.10
3 //page 440
4 disp("example 5.10")
5 clear;
6 clc;
7 V=2000;
8 V_oc=500;          //open circuit voltage
9 I_sc=100;           //short circuit current
10 I_a=100;
11 R_s=0.8;           //armature resistance
12 Z_s=V_oc/I_sc;    //synchronous impedance
13 printf("Z_s= %d ohm\n",Z_s);
14 X_s=sqrt(Z_s^2-R_s^2);
15 printf("X_s= %f ohm\n",X_s);
16 pf=1;

```

```

17 phi=acosd(pf);
18 disp("At unity power factor");
19 printf("\n");
20 E=sqrt((V*cosd(phi)+I_a*R_s)^2+(V*sind(phi)+I_a*X_s)
^2);
21 printf("induced emf= %fV\n",E);
22 R=((E-V)*100)/V;
23 printf("regulation= %f percent\n",R);
24 clear pf;
25 pf=0.71;
26 phi=acosd(pf);
27 disp("At 0.71 lagging power factor");
28 printf("\n");
29 E=sqrt((V*cosd(phi)+I_a*R_s)^2+(V*sind(phi)+I_a*X_s)
^2);
30 printf("induced emf= %fV\n",E);
31 R=((E-V)*100)/V;
32 printf("regulation= %fpercent\n",R);
33 clear pf;
34 pf=0.8;
35 phi=acosd(pf);
36 disp("At 0.8 leading power factor");
37 printf("\n");
38 E=sqrt((V*cosd(phi)+I_a*R_s)^2+(V*sind(phi)-I_a*X_s)
^2);
39 printf("induced emf= %fV\n",E);
40 R=((E-V)*100)/V;
41 printf("regulation= %fpercent\n",R);

```

Scilab code Exa 5.11 To calculate internal voltage drop

```

1 //chapter 5
2 //example 5.11

```

```

3 //page 441
4 clear;
5 clc;
6 disp("example 5.11");
7 printf("\n");
8 disp(" field excitation current=10A");
9 V_oc=900;           //induced emf on open circuit
10 I_sc=150;          //short circuit current
11 Z_s=V_oc/I_sc;    //synchronous impedance
12 printf("synchronous impedance ,Z_s= %d ohm\n",Z_s);
13 I_a=60;
14 printf("internal voltage drop when the load current
      is 60amp= %d V", (I_a*Z_s));

```

Scilab code Exa 5.12 To calculate percentage change in terminal voltage

```

1 //chapter 5
2 //example 5.12
3 //page 441
4 clear;
5 clc;
6 disp("example 5.12");
7 KVA=2000;
8 V=6600;           //rating
9 V_p=6600/sqrt(3);
10 I_a=(KVA*1000)/(sqrt(3)*V);
11 R_a=0.4;          //armature resistance
12 X_s=4.5          //synchronous reactance
13 pf=0.8;
14 phi=acosd(pf);
15 printf("\nV/phase= %dV \n",V_p)
16 E=sqrt((V_p*cosd(phi)+I_a*R_a)^2+(V_p*sind(phi)+I_a*
      X_s)^2)

```

```

17 printf("E= %f V per phase\n",E);
18 R=((E-V_p)*100)/V_p;
19 printf("percentage change in terminal voltage= %f
percent",R);

```

Scilab code Exa 5.13 To calculate regulation on full load power factor loading and

```

1 //chapter 5
2 //example 5.13
3 //page 442
4 clear;
5 clc;
6 disp("example 5.13");
7 printf("\n");
8 KVA=1200;           //output power
9 printf("output power=%d\n",KVA)
10 V_l=3300;          //line voltage
11 R_a=0.25;          //armature resistance
12 I_l=(KVA*1000)/(sqrt(3)*V_l);    //line current
13 //for star connected I_l=I_a
14 I_a=I_l;
15 V_p=V_l/sqrt(3);
16 printf("V per phase= %dV\n",V_p)
17 //field current of 40A produces short circuit
   current of 200A and open circuit emf 1100
18 v_l=1100;
19 i_s=200;
20 Z_s= v_l/(sqrt(3)*i_s);      //synchronous impedance
21 printf("Synchronous impedance ,Zs=%f ohm\n",Z_s)
22 X_s=sqrt(Z_s^2-R_a^2);      //synchronous reactance
23 disp("(a) for 0.8 lagging power facor");
24 pf=0.8;
25 phi=acosd(pf);

```

```

26 E=sqrt((V_p*cosd(phi)+I_a*R_a)^2+(V_p*sind(phi)+I_a*
X_s)^2)
27 printf(" induced emf ,E=%f V\n",E);
28 R=((E-V_p)*100)/V_p;
29 printf(" regulation=%f percent\n\n",R);
30 clear pf;
31 pf=0.8;
32 phi=acosd(pf);
33 disp("(b) For leading power factor load")
34 E=sqrt((V_p*cosd(phi)+I_a*R_a)^2+(V_p*sind(phi)-I_a*
X_s)^2)
35 printf(" induced emf ,E= %f V\n",E);
36 R=((E-V_p)*100)/V_p;
37 printf(" regulation=%f percent",R);

```

Scilab code Exa 5.14 To calculate terminal voltage for same excitation and load cu

```

1 //chapter 5
2 //example 5.14
3 //page 443
4 clear;
5 clc;
6 disp(" example 5.14");
7 disp(" star connected alternator")
8 printf("\n");
9 KVA=1500;           //rating
10 ph=3;              //3-phase
11 V_l=6600;          //voltage
12 Ra=0.4;            //armature resistance
13 Xs=6;              //reactance
14 Ia=(KVA*1000)/(sqrt(3)*V_l);
15 printf(" Full-load current= %d A\n",Ia);
16 V=V_l/sqrt(3);

```

```

17 printf("Voltage per phase=%d V\n",V);
18 disp(" for 0.8 lagging power factor");
19 pf=0.8;           //power factor
20 phi=acosd(pf);
21 E=sqrt((V*cosd(phi)+Ia*Ra)^2+(V*sind(phi)+Ia*Xs)^2)
22 printf("induced emf=%f V\n\n",E);
23 disp("then at 0.8 leading power factor");
24 Vt=4743; //solved manually
25 printf("terminal Voltage , line-to-line=%d V\n", (sqrt
(3)*Vt))

```

Scilab code Exa 5.15 to find the power factor of alternator B

```

1 //chapter 5
2 //example 5.15
3 //page 450
4 clear;
5 clc;
6 disp("example 5.15");
7 L=8000;           //load
8 La=5000;
9 pf=0.8;
10 phi=acosd(pf);
11 printf("\ntan phi= %f\n",tand(phi));
12 disp("FOR ALTERNATOR A");
13 pf_a=0.9;
14 phi_a=acosd(pf_a);
15 printf("\ntan phi_a= %f\n",tand(phi_a));
16 disp(" reactive load=active load*tan phi");
17 disp(" Active load=8000kW");
18 printf("reactive load= %d KVAr\n", (8000*tand(phi_a)
));
19 disp(" Active Load A=5000kW\n");

```

```

20 printf("Reactive load A= %dkVAr\n", (5000*tand(phi_a
    )));
21 printf("Active load of B= %dkW\n", L-La);
22 a=((8000*tand(phi))-(5000*tand(phi_a)));
23 printf("Reactive load of B= %dkVAr\n", a);
24 B=a/(L-La);
25 phi_b=atand(B);
26 printf("phi_b= %f\n", phi_b)
27 printf("Power Factor of B= %f", cosd(phi_b));

```

Scilab code Exa 5.16 To calculate armature current and power factor

```

1 //chapter 5
2 //example 5.16
3 //page 451
4 clear;
5 clc;
6 disp("example 5.16")
7 V=6600;
8 ph=3; //3-phase alternators
9 power=10000; //total load
10 disp("Two alternators in parallel connection");
11 pf=0.8;
12 Ia=438; //armature current
13 Il=(power*1000)/(sqrt(3)*V*pf); //load current
14 printf("load current= %fA\n\n", Il);
15 phi=acosd(pf);
16 Ac=(Il*cosd(phi));
17 Rc=(Il*sind(phi));
18 printf("Active component of current= %fA\n", Ac);
19 printf("Reactive component of current= %fA\n", Rc);
20 printf("Current supplied by each alternator=%fA\n", (
    Il/2));

```

```

21 printf("Active component of current supplied by each
         alternator= %fA\n", (Ac/2));
22 printf("Reactive component of current supplied by
         each alternator= %fA\n\n", (Rc/2));
23 disp("Since steam supply is same, the active
         component remain the same");
24 RI1=sqrt(Ia^2-(Ac/2)^2);
25 printf("Reactive component of I1= %dA\n", RI1);
26 RI2=(Rc-RI1);
27 printf("reactive component of I2= %fA\n", RI2);
28 I2=sqrt((Ac/2)^2+(RI2)^2);
29 printf(" I2= %fA\n", I2);
30 phi_2=atand(RI2/(Ac/2));
31 printf("phi 2= %f degrees\n", phi_2);
32 printf("cos phi 2= %f", cosd(phi_2));

```

Scilab code Exa 5.17 To determine KVA rating and power factor

```

1 //chapter 5
2 //example 5.17
3 //page 455
4 clear;
5 clc;
6 disp("example 5.17");
7 disp("power factor of existing load is 0.8 lagging")
     ;
8 pf=0.8; //power factor
9 phi=acosd(pf);
10 printf("phi= %d degree\n", phi);
11 L=800; //load
12 kVAr1=(L*tand(phi));
13 printf("kVAr1= %d \n", kVAr1);
14 disp("output for the synchronous motor is 200kW");

```

```

15 output=200;
16 efficiency=0.9;
17 kW=(output/efficiency);
18 printf("Input to the synchronous motor= %fkW\n",kW);
19 TL=(L+kW); // total load
20 printf("Total load on the system= %fkW\n",TL);
21 disp("overall power factor of the load is to be
      raised to 0.92 lagging");
22 pf=0.92;
23 phi=acosd(pf);
24 kVAr2=(TL*tand(phi));
25 printf("kVAr2=%f\n",kVAr2);
26 kVAr=kVAr1-kVAr2;
27 printf("lagging kVAr of synchronous codenser= %f\n",
      kVAr);
28 printf("leading kVAr supplied by the motor= %f\n",
      kVAr);
29 phi=atand(kVAr/kW);
30 printf("phi= %d degree\n\n",phi);
31 printf("Power factor of the synchronos motor= %f
      leading \n",cosd(phi));
32 printf("KVA rating of the synchronous motor= %f", (kW
      /cosd(phi)));

```
